

Contents

Introduction	E
Manual operation	M
Coordinate system and dimensioning	K
Programming with HEIDENHAIN plain-language dialog	P
Programming in ISO format	D
Touch-probe system	A
External data transfer via the V.24/RS-232-C interface	V
Technical description, specifications, subject index	T

Brief description of the control	E2
Switching on the control unit/Traversing the reference points	E4
Operating modes and screen displays	E6
Supplementary operating modes	E8

Control system in brief

TNC 355

Control type

The HEIDENHAIN TNC 355 is a 4-axis contouring control system. Axes X, Y and Z are linear axes; the fourth axis is provided for the attachment of an optional rotary table or use as an additional linear axis. The fourth axis can be connected or disconnected as required. The programming of cycles and a contour is possible with the 4th axis only under certain conditions.

The four-axis contouring control permits:

- linear interpolation of any 3 axes,
- circular interpolation of 2 linear axes.

Complex contours can also be produced with the aid of parameter programming.

An additional 5th axis permits spindle orientation. This feature allows accurate positioning of the spindle, when using the TS 510/TS 511 infrared probing system, for example, or for certain tool change systems.

Program entry

Programs may be entered either

- in HEIDENHAIN plain-language interactive dialog
- or in standard ISO 6983 format.

All interactive dialog prompts, input values, machining programs and error messages are displayed on the control screen. The program memory can accommodate up to 32 programs with a total of 3,100 blocks. The machining program can be either keyed in or entered "electronically" via the data interface. In "Transfer block-wise" mode, machining programs can be transferred from an external storage medium and run simultaneously.

The TNC 355 allows you to enter or edit a program while another program is running.

External data storage

HEIDENHAIN provides the FE 401 floppy disk unit for external storage of programs. The floppy disk unit uses 3 1/2" diskettes for data storage. The unit is equipped with two interfaces, making it possible to connect a peripheral device, such as a printer, in addition to the TNC.

Control system in brief

TNC 355

Program test

In "Test run" mode, the TNC checks machining programs without moving the machine slides. Any errors in the program are displayed in the form of plain-language messages. Graphic program simulation provides another option for testing the program. Machining procedures can be simulated on the three main axes with a constant tool axis using a cylindrical end mill.

Upward compatibility

Programs created on the TNC 145, TNC 150 or on the TNC 151/TNC 155 can also be run on the TNC 355. The control system adapts the input data to the TNC 355. Thus an existing TNC 145/TNC 150/TNC 151/TNC 155 program library can also be used for the TNC 355.


Changing buffer batteries

The buffer battery is the voltage source for the memory containing the machine parameters and for the control system program memory, in case the external voltage supply is switched off. It is located beneath the cover on the front panel of the control unit.

It is time to replace the battery when the message:
= EXCHANGE BUFFER BATTERY =
is displayed.


The three buffer batteries are located behind a P6 screw cap in the power supply unit of the LE 355.

Besides the batteries, the TNC 355 also employs accumulators on the calculator circuit board to secure memory contents. This permits the mains power to be switched off in order to change batteries. The accumulators will retain memory contents without batteries for about 2 weeks, and are loaded only when the TNC is switched on.




Operating modes and screen displays


Manual operation



Electronic handwheel



Positioning – manual data input



Operating modes and screen displays

Program run – full sequence (HEIDENHAIN dialog)



Operating mode, error messages — PROGRAM RUN/FULL SEQUENCE

Current program block — 15 L X+182,000

Position display (large characters) — ACTL X - 180,910
Y + 285,736
Z + 165,538
C + 180,000

Display: Program running — x

Status displays — DATUM X = 102,600 Y = 22,659
Z = 101,000 C = 0,000
ROT X = 20,000 SCL 1,000000
CO X = 35,000 Y = 3,000
TI C S 201 F 0 H03

Program run – full sequence (ISO format)



Operating mode, error messages — PROGRAM RUN/FULL SEQUENCE

Current block — N130 G29 X

Subsequent blocks — N140 G01 G40 G80 Z+1 F9999 H03 X
N150 G75 P01 +1 P02 +20 P03 +2
P04 40 P05 10.5 P06 100 X
N160 G79 X
N170 G11 R+30 H+155 X
N180 G75 P01 -U P02 +30 P03 +3
P04 40 P05 25 P06 100 X

Position display — ACTL X = 180,910 Y = 285,736
Z = 165,538

Display: Program running —

Status displays — F 0

Programming and editing



Operating mode, error messages — PROGRAMMING AND EDITING

Dialog line — COORDINATES

Current block — S5 D X+65,000 Y+42,000
OR= R F M
S7 CO X+24,000 Y+12,000

Position display — ACTL X + 24,000 Y + 12,000
Z + 10,000

Status displays — S9 RND R10,000 F 0 H05

Supplementary operating modes


Introduction

In addition to the main operating modes, the TNC 355 provides a number of **supplementary operating modes**, or MOD* functions.


The supplementary modes are selected by pressing the **MOD** key. When this key is pressed, the first MOD function "Vacant blocks" is displayed on the dialog line.

You can use the   keys to page forward and backward through the MOD function menu.



You can page forward with the **MOD** key.

Exit the supplementary mode function by pressing the  key.

* MOD is a shortened form of the word "mode".



Restrictions

While a program is running in modes  or , only the following supplementary operating modes can be selected:

- position display size (large or small characters)
- vacant blocks

The following supplementary operating modes can be selected while the message = POWER INTERRUPTED = is displayed on the screen:

- code number
- user parameters
- NC software number
- PLC software number

Vacant blocks

The MOD function "Vacant blocks" indicates the number of blocks still available in program memory.

When programming in ISO format, the number of available characters (bytes) is displayed.

Sample display:



VACANT BLOCKS = 1178

Supplementary operating modes

How to select and exit MOD functions

Select function

Operating mode _____      

Initiate dialog _____ 

VACANT BLOCKS = 1974

Select MOD functions via editing keys



or

by paging (forward only) with the MOD key.




Exit function

LIMIT X+ = X+ 350.000




Exit supplementary mode.




Press the  key to transfer numerical entries to memory before exiting MOD functions.

Supplementary operating modes

Changeover mm/inch

You can use the MOD function "mm/inch" to determine whether the control system displays position data in millimetres or inches. Press the  key to change from inch to mm and vice versa. When this key is pressed, the control system switches to the alternate measuring unit.


You can recognize whether the current display is in mm or inches by noting the number of decimal places following the decimal point:
 X 15.789 mm display
 X 0.6216 inch display




Position data display

The type of position data displayed on the screen can be selected via the MOD function "position display":

- current actual position display: **ACTL**
- distance from reference points: **REF**
- difference between current nominal and actual positions (trailing error or lag): **LAG**
- Current nominal position calculated by control system: **NOML**



- Display of distance to go to nominal position (difference between programmed nominal and current actual position): **DIST**




Clamped axes are identified by a decimal point behind the axis designation.

Supplementary operating modes

Changeover mm/inch

Select MOD function.  

CHANGE MM/INCH

The control displays position data in mm, you want to change to inch:  Changeover.


Change from inch to metric in the same way.

Position display

Select MOD function.  


PROGRAM RUN/SINGLE BLOCK
POSITION DISPLAY

NOML X... Y...

To change the display back to "actual position":  Changeover.
(Press repeatedly until ACTL appears.)

PROGRAM RUN/SINGLE BLOCK
POSITION DISPLAY



ACTL X... Y...

To change the display back to "nominal position":  Changeover.
(Press repeatedly until NOML appears.)

Follow the same procedure to change the position data display to REF, LAG and DIST.

Supplementary operating modes

Position display large/small

You can change the height of the characters in the position display on the screen in  "Program run/single block" or  "Program run/full sequence" (automatic) modes.
In the case of small-character display, the screen displays four program blocks (preceding, current, next and block after next); with large-character display, only the current block is shown.



If you are programming in ISO format, position data cannot be displayed in large characters because program blocks may be longer than two lines.

Block number increment

If you are programming in ISO format, you can determine the interval between block numbers via the MOD function "Block number increment". If the increment is 10, for example, blocks will automatically be numbered as follows:
N10
N20
N30
etc.
Block increments may lie within a range of 0 – 99.

Baud rate

The MOD function "Baud rate" is used to determine the data transmission speed for the interface (see "Baud rate entry").

V.24- interface

The interface can be switched to the following operating modes via the MOD function "V.24 interface":

- magnetic tape operation (ME)
- floppy disk operation (FE)
- EXT-operation with other external devices. (see "V.24 interface – definition").

Supplementary operating modes

Position display
large/small

Select MOD function "Position display large/
small":



PROGRAM RUN/SINGLE BLOCK
POSITION DISPLAY LARGE/SMALL

```
17 L X... Y...
18 L X... Y...
19 CC X... Y...
20 C X... Y...
-----
ACTL X... Y...
     Z... C...
```

To switch position display to large:



PROGRAM RUN/SINGLE BLOCK

```
18 L X... Y...
ACTL X...
     Y...
     Z...
     C...
```

Follow the same procedure to switch from
large to small display.

Block number
increment
(ISO only)

Select MOD function "Block number incre-
ment":



BLOCK NO. INCREMENT =




Enter increment for block numbers.

Transfer entry to memory.

Supplementary operating modes

Software limits

Using the MOD function "Limits", you can confine tool traverse to specified limits, to prevent collisions with certain workpieces, for example. Maximum traverse ranges are defined by software limit switches. Traverse range limits are determined on each axis consecutively in + and - directions, based on the reference point. For this reason, the position display must be switched to REF when defining the limiting positions.



Supplementary operating modes

Setting the software limits



Operating mode _____  or 

Switch position display to REF to set traverse range limits.

Select MOD function "Limits".



LIMIT X+ = +30 000.000

Use the external axis direction buttons or the electronic handwheel to move to the limiting position.

Program position indicated, e.g. -10.000



Enter X-value.

Transfer to memory.

LIMIT X+ = -10.000

Select next MOD function "Limits":



LIMIT X- = -30 000.000

Use the external axis direction buttons or the electronic handwheel to move to the limiting position.

Program position indicated, e.g. -70.000



Enter X-value.

Transfer to memory.

LIMIT X- = -70.000

Follow the same procedure to limit remaining traverse ranges.



If you decide not to limit the traverse ranges, enter the values +30 000.000 or -30 000.000 for the corresponding axes.

Supplementary operating modes

NC software number

This MOD function displays the software number of the TNC control system.

Sample display:

NC: SOFTWARE NUMBER 234 020 01

PLC software number

This MOD function displays the software number of the integrated PLC.

Sample display:

PLC: SOFTWARE NUMBER 234 601 01

User parameters

This MOD function provides the user with access to up to 16 machine parameters. User parameters are defined by the machine manufacturer, who can also provide you with further information.

Code number

With this MOD function, code numbers can be used to select a special procedure for "reference point approach" or to cancel the "edit/erase protection" for programs (see appropriate chapter).

Supplementary operating modes

User parameters

Select MOD function "User parameters".



USER PARAMETERS



Transfer MOD function.

USER PAR.1 = 0 *



Select desired user parameter.

* The dialog text is determined by the machine manufacturer. The above message is displayed if no dialog text has been defined.



Change parameter if required.



Transfer entry to memory.

Exit user parameter function

To exit the MOD function "User parameters":



Exit MOD function.

Notes:




Handwriting practice lines on a page:

- Line 1: A solid top line, a dashed middle line, and a solid bottom line.
- Line 2: A solid top line, a dashed middle line, and a solid bottom line.
- Line 3: A solid top line, a dashed middle line, and a solid bottom line.
- Line 4: A solid top line, a dashed middle line, and a solid bottom line.
- Line 5: A solid top line, a dashed middle line, and a solid bottom line.
- Line 6: A solid top line, a dashed middle line, and a solid bottom line.
- Line 7: A solid top line, a dashed middle line, and a solid bottom line.
- Line 8: A solid top line, a dashed middle line, and a solid bottom line.
- Line 9: A solid top line, a dashed middle line, and a solid bottom line.
- Line 10: A solid top line, a dashed middle line, and a solid bottom line.

Operating mode: "Manual operation"	M1
Operating mode: "Electronic handwheel"	M2
Jog positioning	M4


Manual operation

Operating mode: "Manual operation"

In "Manual operation" mode , the machine axes can be moved via the external axis direction buttons **X** **Y** **Z** **IV**.

Jog mode


The machine axis is moved as long as the appropriate external axis direction button is pressed. The machine axis stops immediately when the axis direction button is released. Multiple axes may be traversed simultaneously in jog mode.



Continuous operation


If an axis direction button and the external start button are pressed **at the same time**, the selected machine axis will continue to move after the button is released. Movement can be **stopped** by pressing the external stop button.



In the  operation mode, the **X** **Y** **Z** **IV** buttons are used to define the workpiece datum (see "Workpiece datum").

Feed rate

The traversing speed (feed rate) can be set via the control system's **internal feed rate override**.
The specified feed rate is displayed on the screen.




Spindle speed

Spindle speed can be adjusted via the **TOOL CALL** key (see "TOOL CALL").
With analogue output, the programmed spindle speed can be altered via the spindle override function while the program is running.



Your machine tool manufacturer or supplier can tell you whether your machine operates with coded or analogue output for spindle speeds.



Miscellaneous functions

You can enter miscellaneous functions via the **STOP** key (see "Program stop").


Manual operation

Operating mode: "Electronic handwheel"

Versions

The control unit can be equipped with an electronic handwheel that can be used for machine set-up, for example. The electronic handwheel is available in two versions:

- **HR 150:** 1 handwheel for integration in machine control panel.
- **HR 250:** 1 handwheel in portable unit



Interpolation factor

The interpolation factor determines the distance traversed per handwheel revolution (see chart at right).


Interpolation factor	Distance traversed per revolution in mm
1	10.0
2	5.0
3	2.5
4	1.25
5	0.625
6	0.313
7	0.156
8	0.078
9	0.039
10	0.020


Operation

Versions HR 150 and HR 250:

Use the **X** **Y** **Z** **IV** axis keys of the control unit to select machine axes for the handwheel.

The axis being controlled by the electronic handwheel is highlighted on the screen.




In  mode, the machine axes can also be moved by means of the external axis direction buttons **X** **Y** **Z** **IV**.



Manual operation.

Operation mode: "Electronic handwheel"

Operation
HR 150/
HR 250



The tool can now be moved in positive or negative Y-direction by means of the electronic handwheel.

Manual Operation

Jog Positioning


Jog Positioning

Jog positioning can be activated via the integrated PLC. This makes it possible to enter a step measure additionally in the operation mode "electronic handwheel". When an axis direction key is pressed the corresponding axis moves by the distance that was entered.

Manual Operation

Entering the dimension increment

Entering the
dimension
increment



Notes:



Cartesian coordinates	K1
Polar coordinates	K2
The fourth axis	K4
Allocation of the coordinate system	K5
Setting the workpiece datum	K6
Absolute/incremental dimensions	K10

Coordinate system and dimensioning


Introduction

An NC machine cannot process a workpiece automatically unless all the machining operations are completely defined by the NC program. The nominal positions of the tool, relative to the workpiece, must be defined in the NC program. A reference system, a system of coordinates, is required to define the nominal tool positions. The TNC allows you to use either rectangular or polar coordinates, depending on how the workpiece is dimensioned.

Rectangular or Cartesian * coordinate system

A rectangular coordinate system is formed by two axes in the plane and by three axes in space. These axes intersect at a single point and are perpendicular to one another. The point where the axes intersect is called the origin or zero point of the coordinate system. The axes are identified by the letters X, Y and Z. Imaginary scales, the zero points of which coincide with the zero point of the coordinate system, are located on the axes. The arrow indicates the positive direction of the scales.

* Named for the French mathematician René Descartes, referred to in Latin as Renatus Cartesius (1596 – 1650)



Example


Any point on a workpiece can be described with the aid of the Cartesian coordinate system by indicating the appropriate X, Y and Z coordinates:

P1 $\left. \begin{array}{l} X = 20 \\ Y = 0 \\ Z = 0 \end{array} \right\}$ abbreviated: P1 (20; 0; 0)

P2 (20; 35; 0)

P3 (40; 35; -10)


P4 (40; 0; -20)



Coordinate system and dimensioning

Coordinate data

The Cartesian coordinate system is particularly suitable if the production drawing is dimensioned "rectangularly".
In the case of workpiece with circular elements or angular dimensions, it is often more convenient to define positions in polar coordinates.



Polar coordinates

The polar coordinate system is used to define points in a plane. The point of reference is the pole (the zero point of the coordinate system) and one direction (reference axis for the specific angle)

Points are described as follows:
By indicating the polar coordinate radius **PR** (distance between pole and point P1) and by the angle **PA** formed between the reference direction (in the illustration, the + X-axis) and the connecting line pole-to-point P1.


A is the abbreviation for angle.

The polar coordinate angle PA is entered in degrees (°), in decimal notation.

Input range for linear interpolation:
absolute or incremental -360° to $+360^\circ$

Input range for circular interpolation:
absolute or incremental -5400° to $+5400^\circ$

PA positive: angle specified counterclockwise
PA negative: angle specified clockwise




Input range

Angular reference axis

The angular reference axis (0° -axis) is
the +X-axis in the X, Y plane,
the +Y-axis in the Y, Z plane,
the +Z-axis in the Z, X plane.

The prefix sign for the angle PA can be determined with the aid of the illustration at the right.




Coordinate system and dimensioning

Example

Point	Polar coord. radius PR	Polar coord. absolute	Angle PA incremental
P1	30	60°	60°
P2	30	120°	60°
P3	30	180°	60°
P4	30	240°	60°
P5	30	300°	60°
P6	30	360°	60°

The polar coordinate system is particularly suitable for describing points on a workpiece if the production drawing contains primarily angles, as shown in the example at right.




Relative tool movement

When machining a workpiece, it makes no difference whether the **tool** moves on a stationary workpiece, or whether the **workpiece** moves while the tool remains stationary.

Only the relative tool/workpiece movement is important when creating a program.

This means, for example:


If the worktable of the milling machine, together with the clamped workpiece, moves to the left, the movement of the tool, relative to the workpiece, is to the right. If the table moves upward, the relative tool movement is down. The tool actually moves only when the headstock moves; thus machine movement always corresponds to the relative tool movement.



Correlation of machine slide movement and the coordinate system

Two factors must be determined before the control system can properly interpret workpiece coordinates in the machining program:

- which slide will move parallel to which coordinate axis (correlation of machine axis and coordinate axis)
- what relationship exists between the position of the machine slides and the coordinate data in the program.




The three main axes

The allocation of the three workpiece coordinate axes to the machine axes has been defined by the ISO 841 standard for various machine tools. The direction of traverse can be easily noted by applying the "right-hand rule".


Coordinate system and dimensioning

The fourth axis

If a fourth axis is used, the machine manufacturer will determine whether it controls a **rotary table** or an additional **linear axis** (e.g. a controlled quill) and how the axis is identified on the screen. An additional linear axis moving parallel to the X-, Y- or Z-axis is referred to as the U-, V- or W-axis.





When programming the movement of a rotary table, the angle of table rotation on the A-, B- or C-axis is indicated in degrees ($^{\circ}$). (decimal notation). In this case, we refer to an A-, B- or C-axis movement, meaning a rotation about the X-, Y- or Z-axis.




Coordinate system and dimensioning

Allocation of the coordinate system

The position of the machine coordinate system is determined as follows:
The machine slide is moved over a defined position, the reference position (also called the reference point). When this point is traversed, the encoder issues an electrical signal, the reference signal, to the control system. Once this signal is received, the control system assigns a given coordinate value to the reference point. The procedure is repeated for all machine slides in order to define the position of the machine's coordinate system.



The reference points must be traversed after every interruption of the power supply, which causes the correlation between the coordinate system and the machine slide position to be lost. All operating options are disabled until the reference points are traversed. Once the reference points have been traversed, the control system "recognizes" the previous workpiece datum (see next chapter) and the software limit switches again.




Coordinate system and dimensioning

Setting the workpiece datum


Setting the workpiece datum

To avoid unnecessary calculating effort, the workpiece datum is located at that point on the workpiece on which workpiece dimensions are based. For reasons of safety, the workpiece datum is almost always located at the "highest" point of the workpiece on the tool axis.




Setting the workpiece datum in the machining plane with an optical contour scanner

Approach the desired workpiece datum and reset the indicator for both axes of the machining plane to zero.



With a centring device

Move to a known position, e.g. to the centre of a hole, with the aid of the centring device. Then enter the coordinates of the hole centre into the control system (in this case $X = 40$ mm, $Y = 40$ mm). This defines the location of the workpiece datum.




Coordinate system and dimensioning

Setting the workpiece datum


With edge finder or tool

Move the tool to the workpiece reference surfaces. When the tool contacts the surface, set the actual value display for the corresponding axis to the value of the tool radius, with a negative prefix sign (in this case e.g. $X = -5 \text{ mm}$, $Y = -5 \text{ mm}$).



Setting the workpiece datum on the tool axis by tool contact with the workpiece surface

Move the zeroing tool to the workpiece surface. When the tool contacts the surface, set the actual value display for the tool axis to zero. If contact with the workpiece surface is not desired, place a thin piece of sheet metal of known thickness (approx. 0.1 mm) between the tool tip and the workpiece. Enter the thickness of the sheet metal (e.g. $Z = 0.1 \text{ mm}$) instead of zero.



With preset tools

If preset tools are used, i.e. if tool lengths are known in advance, probe the workpiece surface with any of the tools. To assign the value "0" to the surface, specify the length L of the tool, with a positive prefix sign, as actual value of the tool axis. If the workpiece surface has a value other than zero, enter the following actual value:


$$(\text{actual value } Z) = (\text{tool length } L) + (\text{position of surface})$$

Example:

Tool length $L = 100 \text{ mm}$

Position of workpiece surface = $+ 50 \text{ mm}$

Actual value $Z = 100 \text{ mm} + 50 \text{ mm} = 150 \text{ mm}$




Coordinate system and dimensioning

Setting the workpiece datum

REF-values

In setting the workpiece datum, defined numerical values, called "REF-values", are assigned to the reference points. These values are automatically saved by the control system. This makes it possible to find the previously defined workpiece datum after an interruption of power, by simply traversing the reference points.



Coordinate system and dimensioning

Setting the workpiece datum



Setting the workpiece datum





Operating mode _____ 

The workpiece datum cannot be set unless the actual position is displayed.
Select this display via the MOD function if required.



Dialog initiation _____ 

DATUM SET X =		Specify value for X-axis.
		Press ENTER.



Dialog initiation _____ 

DATUM SET Y =		Specify value for Y-axis.
		Press ENTER.

Dialog initiation _____ 

DATUM SET Z =		Specify value for Z-axis.
		Press ENTER.



Dialog initiation _____ 

DATUM SET C =		Specify value for 4 th axis.
		Press ENTER.

Depending on the specified machine parameters, the 4th axis is identified and displayed as A, B, C or U, V or W.



If the dialog for setting the datum was initiated inadvertently and you do not wish to set the datum, proceed as follows:

- if programming in HEIDENHAIN format, press .
- if programming in standard ISO format, press .

Coordinate system and dimensioning


Absolute/incremental dimensions

Dimensioning

Dimensions in workpiece drawings are indicated either in absolute or in incremental (chain) dimensions.


Absolute dimensions

Absolute dimensions in the machining program are based on a fixed, absolute point, the zero point of the coordinate system (corresponds to the workpiece datum).



Incremental dimensions

Incremental dimensions in the machining program are based on the previous programmed nominal position of the tool.




Program creation and program entry	Introduction	P1
	Program management	P6
	Tool compensation	P12
	Workpiece contour	P19
	· Contouring keys	P20
	· Entering Cartesian coordinates	P20
	· Entering polar coordinates	P22
	· Tool path compensation	P26
	· Straight lines	P36
	· Circles	P44
	· Helix	P60
	Contour approach and departure	P62
	Subroutines and program part repetition	P70
	Program jump PGM CALL	P76
	Parameter programming	P78
	Canned cycles	P94
	· Machining cycles	P98
	· Coordinate conversions	P150
	· Other cycles	P158
	Program editing	P164
Test run	Testing a program	P170
	Parameter display	P170
Graphics	Defining a blank	P172
	Display modes	P174
Program run	Introduction	P188
	Interrupting and aborting a program run	P190
	Resuming program execution	P193
	Program run with background programming	P195
Paraxial machining	Programming via axis address keys	P197
	Playback programming	P200
	Positioning with MDI	P204
Machine parameters	Introduction	P208

Programming Introduction

Introduction

As in the case of conventional, manually operated machine tools, a work plan, called an "operation layout" is required for operations with a CNC machine tool. The operating sequence is the same in both cases.

While, in the case of the conventional machine, the individual steps are performed by the operator, the electronic control system of the CNC machine calculates the tool path, coordinates the feed motions of the machine slides and monitors spindle speed. The control system receives the data required to carry out these tasks from a **program** which has been entered in advance.



Program

The program is nothing more than a set of instructions, like the operation layout, compiled in a language that the control system can understand.

Programming

Programming is therefore the creation and entry of an operation layout in a language that can be understood by the control system.

Programming language

In the machining program, each **NC program block** corresponds to one step in the operation layout. A block is made up of **individual commands**.

Examples	
Programmed command	Meaning
Y-50.000	Move Y-axis slide to position -50.000.
F250	Move machine slide at feed rate of 250 mm/min.
TOOL CALL 1	Call compensation values for tool No. 1.


Programming Program

Program structure

A program for producing a workpiece can be divided into the following **sections**:

- Approach tool change position.
- Insert tool.
- Approach workpiece contour.
- Machine workpiece contour.
- Depart from workpiece contour.
- Approach tool change position.

Each program section is composed of individual program blocks.



Block number

The control system automatically assigns a block number to each block. The **block number** identifies the program block within the machining program.


The block number is maintained when a block is erased; the subsequent block takes the place (and the number) of the erased one.

7	L	Z-20.000			
8	L	X-12.000	R0 F9999	M03	
9	L	X+20.000	Y+60.000	R0 F9999	M
10	RND	R+5.000	RR F40		M
11	L	X+50.000	F20	Y+20.000	
12	CC	X-10.000	RR F40	Y+80.000	M
13	C	X+70.000	DR+	Y+51.715	
14	CC	X+150.000	RR F40	Y+80.000	M
15	C	X+90.000	DR+	Y+20.000	
16	L	X+120.000	RR F40	Y+20.000	M

Dialog prompting

Programming is dialog-prompted, meaning that the control system asks for the required information in plain language during program entry. The appropriate dialog sequence for each program block is initiated via the dialog-initiation key, e.g. **TOOL DEF** (the control system prompts the operator for the tool number, then for the tool length etc.).

Errors made while entering a program are also displayed in plain language. Incorrect entries can be corrected immediately, during program entry.




Programs are entered in "PROGRAMMING AND EDITING" mode



Programming

Responding to dialog prompts


Responding to dialog prompts

Every dialog prompt requires a response. The response is displayed in the highlighted field on the screen. Following the response to the dialog prompt, the entry is transferred to the program by pressing the  key.

The control system then issues the next dialog prompt.


“ENT” is an abbreviation for “ENTER”




Do not press  when programming an axis without a numerical value (e.g. for mirror-imaging).







Skipping dialog prompts

Certain entries do not change from block to block, e.g. feed rate or spindle speed. The corresponding dialog prompt does not require a response in this case and may be “skipped” by pressing .

Entries already displayed in the highlighted field will be deleted and the next prompt will appear on screen. The values programmed previously at the corresponding address will be valid when the program is run.



Terminating a block prematurely

By pressing the  key, the programming of positioning blocks, tool calls or the cycles “datum shift” and “mirror image” can be terminated prematurely. Following the last prompt, the  key can be used much in the same way as the  key to transfer data, or immediately following the next prompt, in the same way as .

The values programmed previously at the corresponding address will be valid when the program is run.

 is the symbol for a program block.



Programming

Entering numerical values

Entering numerical values

Numerical values are entered from the numeric keypad, which also features decimal point and prefix sign keys. Leading zeros in front of the decimal point may be omitted (the decimal point may be shown on the screen as a decimal comma).

Prefix signs may be entered before, during and after numerical entries.

Incorrectly entered numbers can be deleted by pressing the **CE** key before transferring them, and then re-entered correctly.



A zero is displayed in the highlighted field when the **CE** key is pressed.

Press the **NO ENTRY** key if you do not wish to enter data.



Notes:



Program management


Entering a new program

The control system can save and store up to 32 programs with a total of 3,100 program blocks. A machining program can contain up to 999 blocks.

To distinguish the various programs, each machining program must be identified by a **program number**.

Erase/edit protection

Programs can be protected from direct access (e.g. erasure or editing).



Directory

The dialog for entering or calling up a program number is initiated by pressing **PGM NR**.

A table, or **directory**, showing the programs stored in the TNC's memory is displayed on the screen.

The length of the program is indicated following the program number. In HEIDENHAIN plain-language format, this display shows the number of program blocks; in ISO format, the number of characters (bytes) is displayed.

The directory can be departed with **NO ENT** or **DEL**.



Calling an existing program



Programs that have already been entered are called via the program number. There are two ways of doing this:

- The programs stored in the control system are listed on the screen, by their program numbers. The most recently entered or called number is highlighted. The highlighted field, also called a cursor, can be moved around in the directory to the desired program number by means of the editing keys **↓**, **↑**, **←**, **→**. The program is called by pressing **ENT**.
- A program can also be called by typing the program number and pressing the **ENT** key.



Program management


Entering a new program number


Operating mode _____ 
 Dialog initiation _____ 

PROGRAM SELECTION


PROGRAM NUMBER =

Enter program number (max. 8 digits).

 Press ENT.

MM = ENT / INCH = NO ENT  for dimensions in mm

or

 for dimensions in inches

Sample display

0 BEGIN PGM 12345678 MM

1 END PGM 12345678 MM

The program number is 12345678; dimensions are in millimetres.
 When programming, the program is inserted between the BEGIN-block and the END-block.





Selecting an existing program number


Operating mode _____  or  or  or 
 Dialog initiation _____ 

PROGRAM SELECTION

PROGRAM NUMBER =


Select the program number using the highlighted cursor.

    Place cursor over desired number.

 Press ENT.

Or enter the program number.

Enter number.

 Press ENT.

Sample display

0 BEGIN PGM 8324 MM

1 L ...

The beginning of the selected program is displayed on screen.

Program management

Edit-protected programs

Erase/edit protection


After a program is compiled, it can be protected against erasure and editing. Erase/edit-protected programs are identified at the beginning and end by a "P".

A protected program cannot be erased or changed unless the erase/edit protection is removed. This is done by selecting the program and entering the code number 86 357.

Program management



Edit-protected programs

Entering
erase/edit
protection

Operating mode _____ 



Dialog initiation _____ 

PROGRAM SELECTION

PROGRAM NUMBER =  



Enter number of program to be protected.


Press ENT.

0 BEGIN PGM 22 MM  

Press key until dialog prompt PGM protection is displayed.

PGM PROTECTION

0 BEGIN PGM 22 MM  



Erase/edit protection is programmed.

Sample display

0 BEGIN PGM 22 MM **P**

"P" appears at end of line to identify erase/edit protection.

Notes:



Program management

Edit-protected programs

Cancelling
erase/edit
protection

Operating mode _____





Dialog initiation _____



PROGRAM SELECTION

PROGRAM NUMBER =

▶  Enter number of program from which protection is to be cancelled.


▶  Press ENT.

0 BEGIN PGM 22 MM **P** ▶  Select supplementary mode.

VACANT BLOCKS 2951 ▶  Select MOD function "Code number".

CODE NUMBER =

▶ Enter code number **86 357**.

▶  Erase/edit protection is cancelled.

Sample display

0 BEGIN PGM 22 MM

The "P" identifying the erase/edit protection disappears from display.

Programming the workpiece contour

Tool definition TOOL DEF


To enable the control system to calculate the tool path from the programmed workpiece contour, tool length and radius must be specified. These data are programmed in the TOOL DEFINITION feature.

Tool number

The compensation (or offset) values always refer to a certain tool, which is identified by a number. The possible entry values for the tool number depend on how the machine is equipped:


with automatic tool changer: 1– 99

without automatic tool changer: 1– 254.




Tool length

The **offset value** for tool length can be determined on the machine or on a tool presetter.

If the length compensation value is determined on the machine, the workpiece datum  should be defined first. The tool used to set the datum has a compensation value of "0" and is called the **zero tool**.

The **differences in length** of the remaining clamped tools, relative to the zero tool, are programmed as **tool length compensations**.





Prefix signs

If a tool is shorter than the zero tool, the difference is entered as a negative tool length compensation.

If a tool is longer than the zero tool, the difference is entered as a positive tool length compensation.

If a **tool presetter** is used, all tool lengths are already known. The compensation values are entered from a list, together with the correct prefixes.




If the tool length is determined on the machine, the difference in length can be entered and transferred to memory by pressing .

Programming tool compensation


Tool radius

The tool radius is always entered as a positive value, except in the case of radius compensation for playback programming.



When using drilling and boring tools, the value "0" can be entered for the tool radius.

Possible input range: $\pm 30\,000.000$.



A tool radius must be programmed if a machining program is to be checked with the aid of the TNC 155 graphics option.





Programming tool compensation

Central tool memory


Central tool memory

In the TNC 355 control system, a central tool memory can be activated via machine parameters.

The central tool memory is selected via program number "0" and modified, printed out and loaded in  "Programming and editing" mode. Data for up to 99 tools can be stored. The tool number, length, radius and location of each tool is entered





Tool changer with random-select feature

When using a tool changer with random select (variable tool location coding), the control system handles tool location management. The random select feature works like this: While one tool is being used for machining, the control system pre-selects the next tool to be used and exchanges the two tools at the programmed tool change. The control system records which tool number is stored at which location. The preselected tool is programmed via . (Length and radius can only be entered in program 0.)

Tools which due to their size require three locations may be defined as "special tools". A special tool is always deposited at the same defined location. A special tool is programmed by placing the cursor on the dialog prompt

SPECIAL TOOL?

and pressing .

For reasons of safety when using special tools the previous and subsequent locations should be cleared by positioning the cursor and pressing the  key; in place of the cleared location a * will appear.

"S" for special tool and "P" for place are only displayed if this function was selected via machine parameter.



When special tools are employed, P0 (spindle) or another place in the magazine must be vacant!

Transfer blockwise

In "Transfer blockwise" mode, compensation values can be called up from the central tool memory.

Programming tool compensation

Tool definition

Entering a tool compensation

Operating mode _____



Dialog initiation _____



TOOL NUMBER ?

Enter tool number.

Press ENT.



The tool number "0" should not be programmed under TOOL DEF. This number is allocated internally (see "TOOL CALL 0"). Tool length and radius can also be entered in playback mode (see "Tool compensation for playback").

TOOL LENGTH L ?

If tool length is known:

Enter compensation value or difference in length from zero tool.
with correct prefix.
Press ENT.

If tool length is determined on machine:

Transfer difference in length from zero tool.
Press ENT.

TOOL RADIUS R ?

Enter tool radius.
Press ENT.

Sample display

15 TOOL DEF 28 L + 15.780

R + 20.000

Tool No. 28 has the compensation value 15.780 for length and 20.000 for the radius.

Programming tool compensation

Tool call


TOOL CALL

TOOL CALL is used to access a new tool and the corresponding compensation values for length and radius.

In addition to the **tool number**, the control system must also know the spindle axis, in order to perform length compensation on the correct axis, or radius compensation in the proper plane.

The **spindle speed** is entered immediately following the spindle axis. If the specified speed is outside the range permitted for the machine, the error message = WRONG RPM = is displayed.


A TOOL CALL block ends the tool length and radius compensation. If only the spindle slewing speed is changed, then the compensation remains.



Tool change

Tool change occurs at a predefined **tool change position**. Thus the control system must move the tool to the **uncompensated nominal values** for the tool change positions. To do this, the compensation data for the tool currently in use must be cancelled.

This is done via the **TOOL CALL 0** function: The moves to the desired uncompensated nominal position are programmed in the next block. The tool change position can also be approached with M91, M92 (see "Auxiliary functions M") or via PLC positioning. Contact your machine manufacturer or supplier for information.




Program structure

Because the program run must be interrupted for a **manual tool change**, a program STOP command must be entered before TOOL CALL. The program run is then interrupted until the external start button is pressed.

The program STOP can be omitted only if a tool call is programmed merely for the purpose of changing slewing speed.

No programm STOP is required for an **automatic tool change**. The program run is resumed when the tool change is completed.






Programming tool compensation



Tool call/Program STOP

Entering a tool call command

Operating mode _____ 
 Dialog initiation _____ 

TOOL NUMBER ?  Enter tool number.
 Press ENT.

SPINDLE AXIS PARALLEL X/Y/Z ?  Enter spindle axis, e.g. Z.
 Spindle axis is X, Y, Z or IV if the IV axis is designated with U, V or W.

SPINDLE SPEED S IN RPM ?  Enter spindle speed (see chart next page).
 Press ENT.

Sample display



TOOL CALL 5 Z
S 125.000


Tool No. 5 is called. The spindle axis operates in the direction of the Z-axis. Spindle speed is 125 rpm.

Entering a programmed STOP

Operating mode _____ 
 Dialog initiation _____ 

AUXILIARY FUNCTION M ?

If auxiliary function is desired:  Enter auxiliary function.
 Press ENT.

No auxiliary function desired:  Press NO ENT.

Sample display

18 STOP
M

Program run interrupted in block 18.

No auxiliary function.

Tool call

Spindle speeds

Programmable spindle speeds (for coded output)

S in rpm	S in rpm	S in rpm	S in rpm	S in rpm
0	1	10	100	1000
0.112	1.12	11.2	112	1120
0.125	1.25	12.5	125	1250
0.14	1.4	14	140	1400
0.16	1.6	16	160	1600
0.18	1.8	18	180	1800
0.2	2	20	200	2000
0.224	2.24	22.4	224	2240
0.25	2.5	25	250	2500
0.28	2.8	28	280	2800
0.315	3.15	31.5	315	3150
0.355	3.55	35.5	355	3550
0.4	4	40	400	4000
0.45	4.5	45	450	4500
0.5	5	50	500	5000
0.56	5.6	56	560	5600
0.63	6.3	63	630	6300
0.71	7.1	71	710	7100
0.8	8	80	800	8000
0.9	9	90	900	9000

For coded output, spindle speeds must be within the range of standard values. If required, the control system will round off to the next higher standard value.

Programmable spindle speeds (for analogue output)

Programmed spindle speeds need not correspond to the values indicated in the table. Any desired spindle speed can be programmed, provided that it is not below the minimum speed and does not exceed the maximum speed of 99999.999 rpm.

With the "Spindle override" potentiometer, the programmed speed can be increased or decreased by the set %-value.




Contact your machine tool manufacturer or supplier to determine whether your machine operates with coded or analog spindle speed output.

Programming workpiece contours

Contour

The workpiece contour


Workpiece contours programmed with the TNC 355 consist of the contour elements **straight lines** and **arcs**.



Generating a workpiece contour

To generate a contour, the control system has to know the type and location of the individual contour elements. Because the next machining step is defined in each program block, it is sufficient to

- enter the **coordinates** of the next target position and
- specify **what** type of **path** (straight line, arc or spiral) the tool will follow to the target point.




Programming coordinates

The **path** to a given target point must be specified before the coordinates of the point can be programmed.

The path is programmed with one of the **contouring keys** (see next page). These keys also initiate the input dialog at the same time.

Incremental/absolute dimensions


To enter the coordinates of a point in **incremental dimensions**, first press the **I** key.





Programming workpiece contours


Contouring keys/Cartesian coordinates


Contouring keys


- 
Linear interpolation L
 ("Line"):
 The tool moves along a straight path. The end position of the straight line is programmed.


- 
Circular interpolation C
 ("Circle"):
 The tool moves along a circular path, or arc. The end position of the arc is programmed.

- 
Circle centre CC
 (also pole for programming polar coordinates):
 Used for programming the circle centre for circular interpolation or the pole for entering polar coordinates.




- 
Rounding corners RND
 ("Rounding"):
 The tool inserts an arc with tangential transitions into the adjacent contour. The radius of the arc and the contour elements of the corner to be rounded are to be programmed.

- 
Tangential arc CT
 ("Circle tangential"):
 The tool inserts an arc with a tangential transition onto the preceding contour element. Only the end position of the arc need be programmed.

- 
Circular interpolation CR
 ("Circle radius"):
 The tool moves along a circular path. The circle radius and the end position of the arc are to be programmed.

Cartesian coordinates

A maximum of three axes can be programmed with linear interpolation and two axes with circular interpolation, using the corresponding numerical values. If the fourth axis is used for a rotary table axis (A-, B- or C-axis) the control system bases the entered value on "°" (degrees).







Programming workpiece contours

Cartesian coordinates

Entering Cartesian coordinates

Dialog prompt:

COORDINATES ?		Select axis, e.g. X.
		Incremental – absolute?
	<input type="text"/>	Type numerical value.
		Enter next coordinate, e.g. Y, and third coordinate, if required (max. 3 axes).
		Press ENT.

When all **coordinates** have been entered:


Programming workpiece contours

Polar coordinates/Pole


Pole CC

In the polar coordinate system, the reference point for the polar coordinates is the pole.
The pole must be defined **before entering the polar coordinates**.


- There are three ways to define the pole:
- The pole is redefined by Cartesian coordinates. A CC block is programmed with the coordinates of the machining plane.



- The last nominal position is used as the pole. A blank CC block is programmed. The most recently programmed coordinates of the program are then used to define the pole.



- The pole has the coordinates programmed in the last CC block. The CC block may be omitted.



The pole can be programmed only in Cartesian coordinates.

CC in absolute dimensions: The pole is based on the workpiece datum.

CC in incremental dimensions: The pole is based on the previous nominal position of the tool.

Programming workpiece contours

Polar coordinates/Pole

Entering the pole

Operating mode _____



Dialog initiation _____



COORDINATES ?

If only one coordinate of the previous nominal position changes, the remaining coordinate need not be entered.

X	Select first axis, e.g. X.
I	Incremental – absolute?
□	Type numerical value.
Y	Select second axis, e.g. Y
I	Incremental – absolute?
□	Type numerical value.
ENT	Press ENT.



To use the last nominal position as the pole, press **NO ENT** or **END**. Both coordinates of the machining plane must be defined in the last positioning block.

Sample display 1

27 CC X + 10.000 IY + 45.000

The pole has the absolute X-coordinate 10.000 and the incremental Y-coordinate 45.000.

Sample display 2

92 L X + 20.500 Y + 33.000

R F M

93 CC


The pole in block 93 has the coordinates X 20.500 and Y 33.000.

Programming workpiece contours

Polar coordinates

Polar coordinates

If desired, points can also be defined by polar coordinates (polar coordinate radius PR, polar coordinate angle PA). Polar coordinates are always based on a given pole CC.




Incremental input

In the case of incremental data entry, the polar coordinate radius increases by the programmed value. An incremental polar coordinate angle IPA is based on the side of the last angle entered.

Example: The polar coordinates of point P1 are PR1 (absolute) and PA1 (absolute).

The polar coordinates of point P2 are PR2 (incremental) and PA2 (incremental). Only the **change in radius** for PR2 and the **change in angle** for PA2 are entered as numerical values.

Thus point P2 has the absolute values $PR = (PR1 + PR2)$ and $PA = (PA1 + PA2)$.






The input range for the incremental polar coordinate angle IPA is $\pm 5400^\circ$, which corresponds to 15 revolutions. For larger rotation angles, program a full circle followed by program part repetition.

Programming workpiece contours




Polar coordinates

Dialog
initiation




After pressing the contour function keys ,  and , the **P** key must be pressed to enter polar coordinates.

Entering
polar
coordinates

Dialog prompt:

POLAR COORDINATE RADIUS PR ?		Incremental – absolute?
		Enter polar coordinate radius PR to target point.
		Press ENT.

▼

POLAR COORDINATE ANGLE PA ?		Incremental – absolute?
		Enter angle PA to reference axis.
		Press ENT.

Programming workpiece contours


Radius compensation – Tool path compensation

Tool radius compensation

For automatic compensation of tool length and radius – as entered in the TOOL DEF blocks – the control system has to know whether the tool will be located to the left or right of the contour, or directly on the contour, based on the direction of feed


Tool path compensation

If the tool moves with path compensation, i.e. if the cutter axis moves with the programmed tool radius taken into account, it follows a path running parallel to and at a distance from the contour equal to the tool radius (equidistant).



Programming tool radius compensation

The radius compensation is programmed via the two-way switches **R⁻** and **R⁺**.




R0

If the tool is to move along the programmed contour, no radius compensation should be active in the positioning block.

RR

If the tool is to move to the **right** of the programmed contour, offset at a distance equal to the radius, press the **R⁺** key.



RL

If the tool is to move to the **left** of the programmed contour, offset at a distance equal to the radius, press the **R⁻** key.

Programming workpiece contours

Radius compensation

Programming
the radius
compensation

Dialog prompt:

TOOL RADIUS COMP.: RL/RR/NO COMP. ?

The tool should travel **left** of the programmed contour.



Enter RL.

The tool should travel **right** of the programmed contour.



Enter RR.

The tool should travel **on** the programmed contour.



Enter R0.

The tool radius compensation should be the same as in the previous block.



Enter R.



R0 and R have different meanings:

R0 Tool travels **on** the programmed contour.


R Radius compensation is same as in the previous block.

Programming workpiece contours

Tool path compensation

Path compensation on internal corners

After radius compensation is activated, the control system automatically computes on **internal corners** the **intersection S** of the contour-parallel (equidistant) path of the cutter. This prevents back-cutting on the contour on internal corners, and resulting damage to the workpiece.




Path compensation on external corners

If radius compensation has been programmed, the control system inserts a **transition arc** (blend) on external corners, which allows the tool to "roll" around the corner point.

In most cases, this guides the tool around the corner at a constant tool path feed rate. If the programmed feed rate is too high for the transition arc, the tool path feed rate is reduced (resulting in a more precise contour). The limit value is permanently programmed in the control system.


The automatic feed rate reduction can be disabled, if required, by programming the auxiliary function M90 (see "Feed rate").



Contour intersection compensation M97

If the tool radius is larger than the **contour shoulder**, the transition arc on external corners can cause damage to the contour. In this case the error message = TOOL RADIUS TOO LARGE = is displayed and the corresponding positioning block is not executed. Programming the auxiliary function **M97** prevents the insertion of a transition arc. The control system computes an additional **contour intersection S** and guides the tool over this point without damaging the contour.

The contour intersection compensation M97 is a non-modal command. It must be programmed in the same block as the external corner point.




Programming workpiece contours

Tool path compensation

Special cases with M97

Under some circumstances e.g. the intersection of a circle with a straight line, the control system is unable to find a contour intersection with tool path compensation using M97. The error message = TOOL RADIUS TOO LARGE = is displayed when the program is run.



Remedy

An auxiliary positioning block is inserted in the program that extends the end point of the arc by the length "0". The control system then performs a linear interpolation, resulting in the calculation of the intersection S.

Example

16 CC Circle centre
17 C Arc end point


```
18 L IX 0.000 IY 0.000
    R F M97
```

19 L Straight line

A straight element with length "0" was programmed in block 18
or:

```
18 L IX 0.001
    R F M97
```

A straight element of length 0.001 was programmed in block 18.




Constant feed rate on corners M90

At external corners the TNC normally reduces the feed rate, at internal corners the tool becomes stationary.

The reduction of the feed rate on corners can be cancelled with the auxiliary function M90, which, however, can cause a slight distortion of the contour. Increased acceleration can also occur, i.e. the maximum acceleration defined in the machine parameters can be exceeded.

This auxiliary function depends on the stored machine parameters (operation with trailing error). Contact your machine manufacturer to determine whether your control system operates in this way.



Programming workpiece contours


Tool path compensation

Terminating tool path compensation

The tool path compensation can be terminated with

- TOOL CALL
- STOP
- M98

The auxiliary function M98 in the positioning block for the last point on the contour causes the respective contour element to be completely machined. If an additional contour has been programmed, as shown in the example at the right, M98 will cause the tool to approach the first point on the contour with radius compensation and this contour will also be completely machined (see "Departure command").




Line milling with M98

Another potential application for M98: line milling with downfeed on Z.

Example

L	X+20.000 Y-10.000	
	RR F15999	M
L	Z-10.000	
	R F	M
L	Y+110.000	
	R F20	M98
L	Z-20.000	
	R F15999	M
L	Y+110.000	
	RL F20	M
L	Y-10.000	
	R F	M98



Notes:



A series of horizontal lines for writing, arranged in a repeating pattern of solid, dashed, and solid lines. The lines are evenly spaced and extend across the right side of the page, providing a guide for handwriting practice.

Programming workpiece contours

Feed rate F/Auxiliary function M

Feed rate


The **feed rate F**, i.e. the traversing speed of the tool along its path, is programmed in mm/min or 0.1 inch/min. If a rotary table is used (A-, B- or C-axis) the value is entered in degrees (°) per minute.

The **feed rate override**, located on the front panel of the control unit, can be used to vary the feed rate within a range of 0 to 150%.

The **maximum input values** (rapid traverse) for the feed rate are:

- 15.999 mm/min (as of software version 05: 2999 mm/min) or
- 6.299/10 inch/min (as of software version 05: 11810/10 inch/min).

The maximum feed rate of the individual machine axes is determined by the machine manufacturer via the machine parameters.




The current feed rate is indicated in the status display at the lower right of the screen. If this display is highlighted and the axes no longer move, the feed rate has not been enabled at the control unit interface. If this happens, contact your machine tool manufacturer or supplier.

Auxiliary function

You can program auxiliary (miscellaneous) functions that control special machine functions (e.g. "Spindle ON") and influence tool contouring characteristics. The auxiliary functions consist of the **address M** and a **code number**.

When programming these functions, it should be noted that certain M functions are active at the beginning of a block (e.g. M03: "Spindle ON – clockwise), while others (e.g. M05: "Spindle STOP") are active at the end of a block.

All available M functions are listed on the following pages




Programming workpiece contours

Entering the feed rate

Entering an auxiliary function


Entering
the feed rate

Dialog prompt:

FEED RATE ? F =	▶ <input type="text"/>	Type numerical value.
	▼ 	Press ENT.

Entering
an auxiliary
function

Dialog prompt:

AUXILIARY FUNCTION M ?	▶ <input type="text"/>	Type code.
	▼ 	Press ENT.

Auxiliary functions M

M functions affecting program run

M	Function	Active at block	
		beginning	ending
M00	Stop program run Spindle STOP Coolant OFF		•
M02	Stop program run Spindle STOP Coolant OFF Return to block 1		•
M03	Spindle ON: clockwise	•	
M04	Spindle ON: counterclockwise	•	
M05	Spindle STOP		•
M06	Tool change Stop program run (if req'd., depends on specified machine parameters) Spindle STOP		•
M08	Coolant ON	•	
M09	Coolant OFF		•
M13	Spindle ON: clockwise Coolant ON	•	
M14	Spindle ON: counterclockwise Coolant ON	•	
M30	same as M02		•
M89	Variable auxiliary function	•	
	– or –		
M89	Cycle call, modal (depends on specified machine parameters)		•
M90	Constant tool path feed rate at corners (see "Tool path feed rate")	•	
M91	within positioning block: Reference point substituted for workpiece datum	•	
M92	within positioning block: Specified workpiece datum replaced by position defined in machine parameters by machine manufacturer, e.g. tool change position	•	
M93	M-function assignment reserved by HEIDENHAIN	•	
M94	Reduction of displayed value for rotary table axis to below 360°	•	
M95	Modified approach characteristics (see "Approach statement M95")		•
M96	Modified approach characteristics (see "Approach statement M96")		•
M97	Contour intersection compensation on external corners		•
M98	End of contour compensation		•
M99	Cycle call		•

Auxiliary functions M

Variable auxiliary functions

Variable auxiliary functions are defined by the machine manufacturer and explained in the machine Operating Manual.


M	Function	Active at		M	Function	Active at	
		Block beginning	Block end			Block beginning	Block end
M01			•	M52			•
M07		•		M53			•
M10			•	M54			•
M11		•		M55		•	
M12			•	M56		•	
M15		•		M57		•	
M16		•		M58		•	
M17		•		M59		•	
M18		•		M60			•
M19			•	M61		•	
M20		•		M62		•	
M21		•		M63			•
M22		•		M64			•
M23		•		M65			•
M24		•		M66			•
M25		•		M67			•
M26		•		M68			•
M27		•		M69			•
M28		•		M70			•
M29		•		M71		•	
M31		•		M72		•	
M32			•	M73		•	
M33			•	M74		•	
M34			•	M75		•	
M35			•	M76		•	
M36		•		M77		•	
M37		•		M78		•	
M38		•		M79		•	
M39		•		M80		•	
M40		•		M81		•	
M41		•		M82		•	
M42		•		M83		•	
M43		•		M84		•	
M44		•		M85		•	
M45		•		M86		•	
M46		•		M87		•	
M47		•		M88		•	
M48		•					
M49		•					
M50		•					
M51		•					

Programming workpiece contours

Straight lines


Paraxial movement

If the tool moves, relative to the workpiece, along a straight path, parallel to a **machine axis**, the movement is referred to as **paraxial** positioning or machining.



2D linear interpolation

If the tool moves along a straight path in one of the **main planes** (XY, YZ, ZX), the movement is referred to as **2D linear interpolation**.




3D linear interpolation

If the tool moves relative to the workpiece along a straight path, with simultaneous movement of **all three machine axes**, the movement is referred to as **3D linear interpolation**.



Simultaneous movement of three machine axes along a straight path is not available on the export versions of the TNC 355 (see inside front cover).



Programming workpiece contours

Linear interpolation with a 4th axis

4th axis =
linear axis

In the case of linear interpolation using the 4th axis as a linear axis, the axis, together with the corresponding coordinate data, must be programmed in each NC block. This also applies even in cases where the coordinate does not change from one block to the other. If no 4th axis is specified, the control system will traverse the main axes of the machining plane.

Example: linear interpolation with X and V, tool axis Z.

= CORRECT =

11	L	X+0.000	V+0.000	
			RR F100	M
12	L	X+100.000	V+0.000	
			R F	M
13	L	X+150.000	V+70.000	
			R F	M

= INCORRECT =

11	L	X+0.000	V+0.000	
			RR F100	M
12	L	X+100.000		
			R F	M
13	L	X+150.000	V+70.000	
			R F	M

4th axis =
angular axis

In the case of linear interpolation using one linear and one angular axis, the TNC interprets the programmed feed rate as the tool path feed rate. In this case, the feed rate is based on the relative speed between the workpiece and the tool. Thus the control system computes a feed rate value for the linear axis F (L) and a feed rate value for the angular axis F (W), for each point on the path:

$$F(L) = \frac{F \cdot \Delta L}{\sqrt{(\Delta L)^2 + (\Delta W)^2}}$$

$$F(W) = \frac{F \cdot \Delta W}{\sqrt{(\Delta L)^2 + (\Delta W)^2}}$$

Key:


F = programmed feed rate

F (L) = linear component of feed rate (machine slide)

F (W) = angular component (rotary table)

ΔL = distance traversed by linear axis

ΔW = distance traversed by angular axis





Programming workpiece contours

Straight lines

Straight line L

To move the tool along a straight path from the starting position P1 to the target position P2: Program the target position P2 (nominal position) of the straight line.


The nominal position P2 can be programmed in either Cartesian or polar coordinates.




Programming workpiece contours


Linear interpolation/Cartesian coordinates

Entering data in Cartesian coordinates


Operating mode _____ 

Dialog initiation _____ 


COORDINATES ?  Select axis, e.g. X.

 Incremental – absolute?

Type numerical value.


 Enter next coordinate, e.g. Y and third coordinate if required (max. 3 axes).

...


When **all coordinates** of the target position have been entered:  Press ENT.

TOOL RADIUS COMP.: RL/RR/NO COMP. ?   Enter radius compensation if required


FEED RATE ? F = Enter feed rate if required.

 Press ENT.

AUXILIARY FUNCTION M ? Enter auxiliary function if required.

 Press ENT.



After coordinates have been entered, and if the remaining data are unchanged, positioning blocks can be shortened by pressing the  key.

Sample display

28 L X+20.000 IY+49.800

RL F100 M13

The tool moves to position X 20.000 (absolute) and Y 49.800 (incremental), with a radius offset to the left of the programmed contour, at a feed rate of 100 mm/min. Coolant flow starts at the beginning and the spindle rotates clockwise.

Notes:









Programming workpiece contours

Linear interpolation/Polar coordinates



Entering data
in polar
coordinates



Operating mode  _____
Dialog initiation   _____

POLAR COORDINATES RADIUS PR ? ▶  Incremental - absolute?
 Enter polar coordinate radius PR for end position of straight line.
 Press ENT.


POLAR COORDINATE ANGLE PA ? ▶  Incremental - absolute?
 Enter polar coordinate angle PA for end position of straight line.
 Press ENT.

TOOL RADIUS COMP.: RL/RR/NO CAMP. ? ▶   Enter radius compensation if required.

FEED RATE ? F = ▶  Enter feed rate if required.
 Press ENT.

AUXILIARY FUNCTION M ? ▶  Enter auxiliary function if required.
 Press ENT



After coordinates have been entered, and if the remaining data are unchanged, positioning blocks can be shortened by pressing the  key.

Sample display

39 LP PR+35.000 PA+45.000
R F M

The tool moves along a straight path to a position 35.000 from the previously defined pole CC; the polar angle is 45° (absolute). Radius compensation and feed rate are determined by the most recently programmed values. No auxiliary function.


Programming workpiece contours


Chamfers

Chamfers

Contour corners produced by the intersection of two straight lines can be provided with chamfers. The angle between the two lines is variable.


Entry

The chamfer is programmed with the  key by specifying the chamfer length L.



Program


Chamfers can be inserted only in a main plane (XY, YZ, ZX), i.e. the positioning block preceding and following the "chamfer" block must contain the two coordinates of the machining plane. If the machining plane is not clearly defined (e.g. positioning block with X ... Y ... Z ...), the error message = PLANE INCORRECTLY DEFINED = is displayed.






Programming workpiece contours


Chamfers

Entry

Operating mode _____ 

Dialog initiation _____ 

COORDINATES ?   Enter chamfer length L.

 Press ENT.

Sample display

88 L 7.500

A chamfer with side length $L = 7.500$ is inserted between the contour elements programmed in the preceding and subsequent blocks.






Programming workpiece contours


Circular interpolation/Circular path C

Circular interpolation


The control system controls two axes simultaneously in such a way that the tool, relative to the workpiece, follows the path of a circle or an arc

With the TNC 355, an arc can be programmed in four ways:

- via the circle centre and end position using the  and  keys.
- via the circle radius and end position using the  key.
- for arcs with tangential transitions at both ends, via the circle radius only, using the  key.
- for arcs joined tangentially to the preceding contour via the end position only, using the  key.




Circle centre CC

The circle centre CC must be programmed before the circular interpolation if the latter is programmed with the  key.


Two programming options are available:

- The circle centre CC is redefined by Cartesian coordinates.
- The coordinates programmed in the previous CC block are applied to the circle centre.

The input dialog for the circle centre is initiated with the  key (see "Pole").



- **CC in absolute dimensions:** the circle centre is based on the workpiece datum.
- **CC in incremental dimensions:** the circle centre is based on the previous nominal position of the tool.




Circular path C

To move the tool from the actual position P1 along a circular path to the target position P2: program only P2. The position P2 can be specified in either Cartesian or polar coordinates.

Direction of rotation

The **direction of rotation DR** for the circular path must be defined. The direction of rotation can be either positive DR+ (counterclockwise) or negative DR- (clockwise).



A compensated contour cannot be started with a circular path. Error message:
= PATH OFFSET INCORRECTLY STARTED =



Programming workpiece contours


Direction of rotation


Entry

Dialog prompt:


ROTATION CLOCKWISE: DR- ?


For clockwise rotation:


▶  Specify direction of rotation (-)

▶  Press ENT

For counterclockwise rotation:

▶  Specify direction of rotation (+).
(Press prefix key twice.)

▶  Press ENT.


▶  Press ENT.

Programming workpiece contours

Circular path C/Cartesian coordinates

Programming a circular path in Cartesian coordinates

When programming in Cartesian coordinates, make sure that starting position and target position (new nominal position) are located on the same circular path, i.e. that they are the same distance from the circle centre CC. Otherwise, the error message = CIRCLE END POS. INCORRECT = will be displayed.




Programming workpiece contours

Circular path C/Cartesian coordinates

Input in
Cartesian
coordinates

Operating mode 

Dialog initiation 



Sample display

```
87 C X+30.000 Y+48.000
DR+ RR F M
```

The tool moves along a circular path, in a positive direction of rotation (counterclockwise), with radius offset to the right of the contour, to position X 30.000 and Y 48.000. The feed rate is defined by the most recently programmed value. No auxiliary function.

Programming workpiece contours


Circular path C/Polar coordinates

Programming a circular path in polar coordinates



If the target position on the arc is programmed in polar coordinates, only the polar angle PA (absolute or incremental) is required to define the end position. The radius is already defined by the position of the tool and programmed circle centre CC

When programming a circular path in polar coordinates, the angle PA may be entered either as a positive or negative value. The angle PA indicates the end position of the arc. The direction of traverse DR can also be programmed as a positive or negative value. If the angle PA is specified in incremental dimensions, the prefixes of the angle and the direction of rotation should be identical. Based on the example at the right, both IPA and DR are negative.






If the tool is located at the pole or circle centre before circular interpolation begins, the error message
= ANGLE REFERENCE MISSING =
is displayed.



Programming workpiece contours

Circular path C/Polar coordinates



Input in
polar
coordinates



Operating mode _____ 
 Dialog initiation _____  **P**

POLAR COORDINATE ANGLE PA ? ▶  Incremental - absolute?
 Specify polar angle PA for circle target position.
 Press ENT.

ROTATION CLOCKWISE: DR- ? ▶  Specify direction of rotation.
 Press ENT.

TOOL RADIUS COMP.: RL/RR/NO COMP. ? ▶   Enter radius compensation if required.

FEED RATE ? F = ▶  Specify feed rate if required.
 Press ENT.

AUXILIARY FUNCTION M ? ▶  Enter auxiliary function if required.
 Press ENT.

Sample display


17 CP PA+60.000
DR- RL F M

The tool moves along a circular path in negative direction (clockwise), with radius offset, to the left of the programmed contour; the polar angle PA relative to the reference axis is 60°. The feed rate is defined by the most recently programmed value. No auxiliary function.

Programming workpiece contours

Circular path CR

Circular path CR

If the centre point of a circular path is not known, but the radius is specified, the circular path can be defined with the  key via


- end position
- radius and
- direction of rotation

End position

The end position can be programmed in Cartesian coordinates only.



The distance between the starting point and end position of the path should not exceed $2 \times R!$




Radius

Two geometrical solutions are available for the circular path described above (see illustration). These solutions depend on the size of the central angle β :

the smaller **arc 1** has a central angle $\beta < 180^\circ$, the larger **arc 2** has a central angle $\beta > 180^\circ$.


To program the **smaller arc** ($\beta < 180^\circ$), enter a **positive radius** (the prefix + can be omitted).

To program the **larger arc** ($\beta > 180^\circ$), enter a **negative radius**.



Direction of rotation

The direction of rotation DR indicates whether the circular path is concave or convex. In the illustration at the right, DR- produces a convex contour element, DR+ a concave contour element.




Programming workpiece contours


Circular path CR

Input


Operating mode _____ 


Dialog initiation _____ 

COORDINATES ?  Select axis, e.g. X.


 Incremental - absolute?

Type numerical value.


 Enter next coordinate, e.g. Y.


 Incremental - absolute?


Type numerical value.

 Press ENT.

CIRCLE RADIUS (SIGN) ? Specify circle radius with correct prefix.


 Press ENT.

ROTATION CLOCKWISE: DR- ?  Specify direction of rotation.


 Press ENT.

TOOL RADIUS COMP.: RL/RR/NO COMP. ?   Enter radius compensation if required.

FEED RATE ? F = Specify feed rate if required.

 Press ENT.

AUXILIARY FUNCTION M ? Specify auxiliary function if required.

 Press ENT.

Notes:



Programming workpiece contours

Circular path CR

Sample display

```
87 CR X+30.000 Y+48.000
R+ 10.000 DR+ RR F M
```

The tool moves along a circular path with a radius of 10.000, in a positive direction of rotation (center angle $P < 180^\circ$), with radius offset to the right of the programmed contour, to position X 30.000 and Y 48.000.

The feed rate is defined by the most recently programmed value. No auxiliary function.

Radii up to 30 m can be entered directly.


Radii up to 99 m can be executed if the radius is determined via Q-parameter programming (no input via keyboard).

Programming workpiece contours

Tangential arc

Arc with tangential connection


Programming a circular path is simplified considerably if the arc is connected tangentially to the contour. Only the **end position of the arc** need be entered to define the arc.



Requirements


The contour section to which the circular path is to be connected tangentially should be entered immediately before programming the tangential arc. If the contour section is missing, the following error message will be displayed:
= CIRCLE END POS. INCORRECT =

Both coordinates of the machining plane must be programmed in the positioning block preceding the tangential arc and in the positioning block for the tangential arc, otherwise, the error message:
= ANGLE REFERENCE MISSING =
will be generated.



Input

The end position of the circular path can be programmed either in **Cartesian coordinates** or in **polar coordinates**.


Initiate the dialog by pressing the  key or



Geometry

In the case of tangential transition to the contour, an **exact arc** is defined by the end position of the circular path.

Because the arc has a definite radius, a definite direction of rotation and a definite centre point, it is not necessary to program these data.










Programming workpiece contours

Tangential arc/Cartesian coordinates



Input



Operating mode 

Dialog initiation 

COORDINATES ?		Select axis, e.g. X.
		Incremental – absolute?
		Specify numerical value.
		Enter next coordinate, e.g. Y.
		Incremental – absolute?
		Specify numerical value.
		Press ENT.

TOOL RADIUS COMP.: RL/RR/NO COMP. ?	 	Enter radius compensation if required.
--	--	--

FEED RATE ? F =		Specify feed rate if required.
		Press ENT.

AUXILIARY FUNCTION M ?		Specify auxiliary function if required.
		Press ENT.



Sample display

20 CT X+15.800 Y+35.000
R F M

An arc is connected tangentially to the last programmed contour section. The coordinates of the end position of the arc are X 15.800 and Y 35.000.

Programming workpiece contours


Tangential arc/Polar coordinates

Input in
polar
coordinates



Indicating the target position in polar coordinates simplifies the programming of cams, for example.


Make sure the pole CC is defined before programming in polar coordinates.






Programming workpiece contours



Tangential arc/Polar coordinates


Input


Operating mode  _____
 Dialog initiation   _____



POLAR COORDINATE RADIUS PR ?   Incremental - absolute?



 Enter polar radius PR for the arc end position.
 Press ENT.

POLAR COORDINATE ANGLE PA ?   Incremental - absolute?

 Enter polar angle PA for the arc end position.
 Press ENT.

TOOL RADIUS COMP.: RL/RR/NO COMP. ?    Specify radius compensation if required

FEED RATE ? F = 
 Specify feed rate if required.
 Press ENT.

AUXILIARY FUNCTION M ? 
 Specify auxiliary function if required.
 Press ENT.

A full circle cannot be programmed.



Sample display

30 CTP PR+35.000 PA+90.000
 R F M

An arc is connected tangentially to the last programmed contour section. The end position of the circular path is 35.000 from the last defined pole CC; the polar coordinate angle is 90° (absolute).

Tool radius compensation and feed rate are defined by the previously programmed values. No auxiliary function.

Programming workpiece contours


Rounding corners

Rounding corners RND

Contour corners can be rounded by inserting circular arcs. The arc blends tangentially into the preceding and subsequent contour segments.

A rounding radius can be inserted at any corner created by the intersection of the following contour elements:

- straight line – straight line
- straight line – arc or arc – straight line
- arc – arc




Programming tip

The rounding radius can only be inserted in a **main plane**. For this reason, the **machining plane** must be the same in the positioning blocks preceding and following the RND block. Otherwise, the following error message will be generated when the program is run:
= PLANE INCORRECTLY DEFINED =

Programming

The rounding radius is programmed immediately following contour point P1, where the corner is located. The rounding radius and, if required, a reduced feed rate F for milling the rounded corner is entered.



15 straight line to P1 (X, Y)

16 RND R 15.000 F80

17 straight line to P2 (X, Y)




The feed rate for rounding corners is effective only in the block in which it is programmed. The previously programmed feed rate is effective again after the RND block.



The rounding radius should not be too large; it must "fit" between the contour elements. If the radius selected is too large, the error message
= ROUNDING RADIUS TOO LARGE =
will be displayed.



A positioning block containing the two coordinates of the machining plane must be programmed before and after an RND block.



Programming workpiece contours

Rounding corners



Contour elements that are located in the same machining plane must be programmed before and after an RND block.

Input

Operating mode _____



Dialog initiation _____



ROUNDING RADIUS R ?



Specify radius of corner arc.



Press ENT.

FEED RATE ? F =



Specify feed rate if required.



Press ENT.

Sample display

78 RND R 5.000

F 20

A corner arc with radius $R = 5.000$ is inserted between the block programmed previously and the one programmed subsequently. The feed rate for milling the rounded corner is 20 mm/min.

Programming workpiece contours

Helical interpolation


Helix

In the case of circular interpolation, two axes are moved simultaneously in such a way that a circle is described in a main plane (XY, YZ, ZX). If a linear movement of the third axis (tool axis) is superimposed on this circular interpolation, the tool will follow a helical (spiral) path.

Tool axis is X, Y, Z or IV if the IV axis is designated with U, V or W.

Helical interpolation can be used to produce large-diameter internal and external threads or lubricating grooves.

Helical interpolation is not available on the TNC 355 export versions (see inside front cover).



Input data

The helix can be programmed only in polar coordinates.

As in the case of circular interpolation, the **circle centre CC** must be defined **in advance**.

The total angle of rotation of the tool is indicated as the **polar angle PA in degrees**:

$$PA = \text{number of rotations} \times 360^\circ$$

Enter PA in incremental dimensions if the angle of rotation is greater than 360°.


Total height/depth is entered in response to the prompt **COORDINATES?**. The value depends on the desired pitch.

$$H = P \times A$$

H = total height/depth
 P = pitch
 A = number of turns

The total height/depth can also be entered in either absolute or incremental dimensions.

The input range for the incremental polar coordinate angle IPA is $\pm 5400^\circ$, which corresponds to 15 revolutions. For larger rotation angles, program a full circle followed by program part repetition.



Radius compensation

The value entered for radius compensation depends on:

- direction of rotation (CW/CCW)
- type of thread (internal/external)
- machining direction (pos./neg. axis direction)

Negative axis direction (-Z or -Y)

Thread	Rotation direction	Radius compens.	
		intern.	extern.
Left-hand thr.	DR+	RL	RR
Right-hand thr.	DR-	RR	RL

Positive axis direction (+Z or +Y)

Thread	Rotation direction	Radius compens.	
		intern.	extern.
Left-hand thr.	DR-	RR	RL
Right-hand thr.	DR+	RL	RR


Programming workpiece contours

Helical interpolation



Input



Operating mode 

Dialog initiation  


POLAR COORDINATE ANGLE PA ?  Incremental – absolute?
 Specify total angle of rotation in degrees.


POLAR COORDINATES ANGLE PA ?  Select infeed axis.

COORDINATES ?  Incremental – absolute?
 Specify height or depth.
 Press ENT.

ROTATION CLOCKWISE: DR- ?  Specify direction of rotation.
 Press ENT.

TOOL RADIUS COMP.: RL/RR/NO COMP. ?   Enter radius compensation.

FEED RATE ? F = Specify feed rate if required.
 Press ENT.

AUXILIARY FUNCTION M ? Specify auxiliary function if required.
 Press ENT.


Sample display


230 CP IPA+720.000 IZ+6.000
DR+ RL F100 M

The tool completes two full revolutions, moving counterclockwise along a helical path. Total height is 6 mm; resulting pitch is 3 mm. The tool travels with radius offset to the left of the contour, producing an internal thread.

Contour approach and departure on an arc

Approach and departure on an arc

Approaching and departing the contour along an arc-shaped path offers the advantage of a "smooth" tangential approach and departure. A smooth approach is programmed with the  key.




Approach

The tool moves to the starting position PS and then on to the location of the contour to be machined.

The positioning block for traverse to point PS should not contain a radius compensation (i.e. R0).

The positioning block for traverse to the first contour position P1 must contain a radius compensation (RR or RL).

Based on the data in the RND block, which follows the positioning block to contour position P1, the control system recognizes that a **tangential** approach to the contour is required.




Departure

The tool reaches the last contour position P4 and then moves on to the end position PE.

The positioning block for traverse to P4 must contain a radius compensation (RR or RL).

The positioning block for traverse to point PE should not contain a radius compensation (i.e. R0).

Based on the data in the RND block, which follows the positioning block to the final contour position P4, the control system recognizes that a **tangential** departure from the contour is required.



Contour approach and departure on an arc


Starting position

The starting position PS must be located in quadrant I, II or III.

The quadrants are formed by the starting direction (tangential direction in the case of an arc) in P1' and the corresponding perpendicular, which also intersects P1'. The workpiece will be damaged if the starting point is located in quadrant IV.

- P1 = first point on contour
- P1' = first compensated point on contour
- PS = starting position (with R0)
- RND1 = rounding radius for I, II
- RND2 = rounding radius for III, IV

The feed rate in the RND block is effective blockwise. After the RND block the previously programmed feed rate is active again.



Programming an approach

```
20 L X+100.000 Y+50.000
```

```
R0 F 15999 M
```

```
21 L X+65.000 Y+40.000
```

```
RR F 50 M13
```

```
22 RND R 10.000
```

```
F
```

```
23 L X+65.000 Y+100.000
```

```
R F M
```

Positioning block to starting position PS with R0.

Positioning block to first contour position P1 with radius compensation RR.

Circular path radius for tangential approach.

Positioning block to next contour position P2.



If no feed rate is programmed for tangential approach in the RND block, then the feed rate of the next positioning block is already effective in the RND block.

Programming a departure

```
30 L X+50.000 Y+65.000
```

```
RR F 50 M
```

```
31 RND R 15.000
```

```
F
```

```
32 L X+100.000 Y+85.000
```

```
R0 F 15999 M00
```

Positioning block to last contour position P with radius compensation RR.

Circular path radius for tangential departure.

Positioning block or end position PE with R0.

Caution when entering F 15999! Danger of collision!



A positioning block containing the two coordinates of the machining plane must be programmed before and after an RND block.

Contour approach and departure in a straight line

Introduction


Approach and departure in a straight line

The tool is to approach the starting position PS and then proceed to the contour. After machining, the tool is to depart from the contour and move to end position PE.


Path angle α

Approach and departure characteristics depend on the path angle α . The path angle is the angle formed by the first or last contour element and the straight-line approach or departure path. In general, three variations are possible:


- Path angle α equals 180°



- Path angle α less than 180°



- Path angle α greater than 180°



Contour approach and departure in a straight line


Path angle α equals 180°

Path angle
 α equals 180°

If **path angle** α is equal to 180° , the starting and end positions are located on straight line extensions tangential to the first and last contour directions. The starting and end positions must be programmed **with radius compensation** (RL or RR).


Approach

The control system moves the tool in a straight line to the compensated position PS_k of the imaginary contour position PS and then follows the compensated path to position $P1_k$.



Departure

The control system moves the tool from compensated position $P5_k$ of contour position $P5$ to position PE_k , following the compensated path.



Contour approach and departure in a straight line


Path angle α greater than 180°

Path angle α greater than 180°

If α is greater than 180° , the starting and end positions must be programmed **with radius compensation** (RI or RR). The first and last contour positions are assumed to form an external corner. The control system executes a path compensation on external corners and inserts a transition arc (blend).


Approach

The control system considers starting position PS to be the first contour position. The tool moves to PSk and then to position P1k, following the compensated path.



Departure

The control system considers the end position PE to be the final contour position. The tool moves along the compensated path to end position PEk.



Contour approach and departure in a straight line


Path angle α less than 180°

Path angle
 α less than 180°

If α is less than 180° , the starting and end positions must be programmed **without radius compensation**, i.e. with R0. PS and PE are approached without path compensation.


Approach

The control system moves the tool in a straight line to the compensated position P1k of contour position P1.



Departure

The control system moves the tool in a straight line from compensated position P5k of contour position P5 to uncompensated position PE.



Contour approach and departure in a straight line

Approach command M96 for external corners

Departure command M98

Approach command M96 for external corners




The contour will be damaged if position PS was programmed without radius compensation and path angle α is greater than 180° .

With auxiliary function M96, the starting position PS is interpreted as a compensated contour position PSk. The tool moves along the compensated path to position P1k.

The auxiliary function M96 is programmed if the **approach angle α is greater than 180°** . M96 is programmed in the positioning block for P1.

M96 is always in effect if no path compensation is active at the beginning of the program.


Incomplete machining of the contour will result if M96 is programmed and path angle α is less than 180° .



Departure command M98

If the end position was programmed with radius compensation and the **departure angle α is less than 180°** , the contour will be incompletely machined.

If auxiliary function M98 is programmed in the positioning block to P, the tool moves directly to point Pk and then to compensated point PEk. The direction PE - PEk equals the last executed radius compensation, in this case P - Pk.




Terminating path compensation M98

If additional positions or contour points were programmed after PE, the required radius compensation direction depends on the direction of the next contour section.

M98 programmed in the positioning block to the final point on the contour causes the relevant contour element to be completed and, as shown in the example at the right, effects traverse with the last programmed radius compensation to the first point on the next contour.

The auxiliary function M98 is effective only in the block in which it is programmed. In the subsequent positioning block, M98 prevents the insertion of transition arcs on external corners and the calculation of path intersections on internal corners.



Contour approach and departure in a straight line

Tool at starting position


Approach command M95 for internal corners

Problems with approach angles α less than 180°



At the beginning of the program, the tool happens to be at the actual position PS and is to move to the nominal position P1 with radius compensation.


In this case, the control system interprets the random position PS as the compensated tool position PSk of an imaginary point on the contour and point P1k cannot be approached due to the path compensation.



Approach command M95 for internal corners

The auxiliary function M95 cancels the path compensation for the first positioning block. The tool moves without path compensation from position PS to the compensated contour point P1k.


Auxiliary function M95 is programmed if the approach angle α is less than 180° . M95 is programmed in the positioning block for P1.



M95 is active only at the beginning of the machining program. Use the function M98 (see "Terminating path compensation") to cancel path compensation blockwise within a machining program.



If M95 is programmed when the approach angle α is greater than 180° , the contour will be damaged.



Subroutines and program part repetition


Program markers (labels)

Labels

When programming, labels (program markers) with a specified number can be set to mark the start of a given program part, such as a subroutine.

You can then jump to these program markers while a program is running (e.g. to execute the subroutine in question).

Setting a label LBL SET


A label is set by pressing the  key.

Label number

You may choose label numbers from 0 to 254. The **label number 0** always marks the **end of a subroutine** (see "Subroutine"), and is therefore a return jump marker!

If you enter a label number that has already been set somewhere else in the program, the following error message will appear:
= LABEL NUMBER ALREADY ALLOCATED =

Calling up a label LBL CALL

Dialog is initiated by pressing the  key.

- Using LBL CALL,
- **subroutines** can be called up, and
 - **program part repetitions** can be programmed.


Label number


You may call up label numbers from 1 to 254

If you enter the number 0, the following error message will appear:
= JUMP TO LABEL 0 NOT PERMITTED =

Program part repetition REP

For **program part repetition**, respond to the question "REPEAT REP" by entering the desired number of repetitions.

For **calling up a subroutine**, respond to the question REP by pressing the  key.



Subroutines and program part repetition

Labels

Setting a label

Operating mode _____



Dialog initiation _____



LABEL NUMBER ?

Specify label number.

Press ENT.

Sample display

118 LBL 27

Label number 27 has been set in block 18.

Calling up a label

Operating mode _____



Dialog initiation _____



LABEL NUMBER ?

Specify label number to be called up

Press ENT.

REPEAT REP ?

If you want to enter a **program part repetition:**

Specify the number of repetitions.

Press ENT.

If you want to enter a **subroutine call:**

Press NO ENT.

Sample display 1

29 CALL LBL 5 REP 2/2

A program part will be repeated twice. The number after the slash indicates the number of repetitions still to be executed in the program run. It decreases by 1 after each repetition.

Sample display 2

218 CALL LBL 27 REP

The subprogram labelled 27 is called up (machining is continued at block 118, see above).

Subroutines and program part repetition


Program part repetition

Program part repetition

Program parts that have already been executed can be repeated upon completion of the program. This is referred to as a program loop or **program part repetition**.

The **beginning** of the program part which is to be repeated is marked with a **label number**. The end of the program part consists of a label number call **LBL CALL** and the programmed **number of program part repetitions REP**.

A program part can be repeated up to 65,534 times.



Program run


The control system executes the main program (together with the appropriate program part) up to the label number call.

Then it jumps to the specified program marker and the program part is repeated.

On the display screen, the number of remaining repetitions is reduced by 1: REP 2/1. After another jump, the program part is repeated a second time.

Once all programmed repetitions have been executed (display: REP 2/0), machining with the main program is resumed.


Altogether, the program part is always executed once more than the number of programmed repetitions.



Programming errors

If **no entry** is made (if you press the **NO ENT** key) in response to **REP** (number of repetitions), you will create a loop: the **label number call** will be **repeated 8 times**.

During the program run and in a test run, the following error message will appear on the display screen after the 8th repetition:
= EXCESSIVE SUBPROGRAMMING =



Subroutines and program part repetition

Subroutines


Subroutines

If a program part is required again at other points in the machining program, it can be marked as a subroutine.

The **beginning** of the subroutine is marked with any desired **label number**. The **end** of the sub-program is always designated by **label number 0**.

If the end of the subroutine is not marked by LBL 0, calling up the subroutine can result in excessive subroutine nesting, (see error message: EXCESSIVE SUBPROGRAMMING).

The subroutine is called up with LBL CALL, and can be called up at any location in the program (but not within the same subroutine). After execution of the subroutine, a return jump is made to the jump location in the main program.



Program run


The control system executes the main program until a subroutine is called up (CALL LBL 27 REP).

Then it jumps to the program marker which has been called up.

The subroutine is executed up to label number 0 (end of subroutine)

Then a jump is made back into the main program.


The main program continues at the block following the subroutine call.



If the subroutine is incorporated into the main program, as in the example above, it is run once during program execution without having to call it up.

A subroutine can only be executed once using a subroutine call! When calling up a program with LBL CALL, you must respond to the dialog prompt REPEAT REP? by pressing the **NO ENT** key.

If a repetition, e.g. REP 1/1, is programmed, the program section between the called-up label number and the command LBL CALL is carried out as a program part repetition. The program marker LBL 0 is not taken into account.




Subroutines and program part repetition

Nesting

Nesting

An additional subroutine or an additional program part repetition can be called up within a subroutine or a program part repetition. This procedure is referred to as nesting.


Program parts and **subroutines** can be nested up to 8 times, that is, the **nesting level** is 8. If the nesting level is exceeded, the following error message will appear:
= EXCESSIVE SUBPROGRAMMING =



Program run with repetition

The main program is executed up to the jump to LBL 17. The program part is repeated twice.

Then the control system continues executing the main program up to the jump to LBL 15. The program part is repeated once up to CALL LBL 17 REP 2/2; the nested program part is again run twice. Then, the previously programmed repetition is continued after CALL LBL 17.




Program run with sub-routines

The main program is executed until the jump command CALL LBL 17.

Then, the subroutine is executed from LBL 17 to the next subroutine call CALL LBL 53, etc. The subroutine nested at the lowest level is executed without interruption.

Before the end (LBL 0) of the final subroutine, a jump is made back to each preceding subroutine, until subsequently, the main program is reached.




Subroutines and program part repetition


Nesting

Subroutine within a subroutine

A subroutine cannot be written into an existing subroutine. Therefore, each subroutine in the example shown is only executed up to the first label number 0




In this case, subroutine 20 should be programmed at the end of the machining program. It is separated from the main program by STOP M02. Subroutine 20 is called up with CALL LBL 20 in subroutine 19.



Repetition of subroutines

It is possible to repeat subroutines with the aid of nesting

A subroutine is called up within a program part repetition. The subroutine call is the only block in the program part repetition. It is important to note that in a program run, the subroutine will be executed once more than the number of programmed repetitions.



Program Jump

Jump to another main program

The program management feature of the control system enables you to jump from one program to another.

Doing so enables:

- the creation of certain machining cycles (see "Cycle program call") in conjunction with parameter programming,
- or
- the saving of tool files.

Jumps are programmed with the  key.

If a program number is entered under which no program has been saved (e.g. CALL PGM 13), when you use the jump command to select the main program, the following error message will appear:

= PGM 13 UNAVAILABLE =



For program calls, no more than **four nesting levels** are permitted; that is, the nesting level is 4.

Program run example

The control system executes program 1 until the program call CALL PGM 28.


A jump is then made to program 28.

Program 28 is executed from beginning to end.

A jump is then made back to program 1

Execution of program 1 is continued from the block following the program call.

Jumps back into the original program cannot be programmed into a program which is called up (causes excessive subroutine nesting).



Program Jump

Input

Operating mode _____



Dialog initiation _____



PROGRAM NUMBER ?		Enter the number of the program to be called up.
		Press ENT.

Sample display

87 CALL PGM 28

In block 87, program 28 is called up and executed.



A program call can be programmed in the same manner as a cycle call, provided that the program number is specified in cycle definition 12.

This ensures that cycles created using parameter programming are handled in the same way as pre-programmed cycles (see "Cycle program call").

Parameters

Parameters

Numerical values in a program which correspond to units of measurement (coordinates or feed rate) can be replaced during program entry by a **variable parameter**, that is, by a "marker" for numerical values that are to be entered later or calculated by the control system. During program execution, the control system then uses the numerical value provided by parameter definition.



Q parameter cannot be switched from mm to inch or vice versa, since the Q values (\neq label numbers) of parameter comparisons are converted.

Setting parameters

Parameters are designated with the letter Q and a number between 0 and 99. Parameters can also be entered with a negative sign. Positive signs do not have to be programmed. Parameters are entered (set) by pushing the **Q** key.

Parameter definition

Certain numerical values can be assigned to parameters either directly or using mathematical and logical functions.


Parameter definition dialog is initiated by pressing the **Q DEF** key. The **FN parameter functions** in the chart are selected using the **↑** or the **↓** key.

Parameter definition example


By specifying parameters instead of coordinates in a linear interpolation, you can create contours, e.g. ellipses, that are defined by mathematical functions. The contour is formed by several individual linear sections (see "Ellipse programming example").



In parameter programming, a step in a calculation can take between 3 and 20 ms. In cases of complicated mathematical functions and high feed rates, the tool may stop on the contour.



FN 0:	ASSIGN
FN 1:	ADDITION
FN 2:	SUBTRACTION
FN 3:	MULTIPLICATION
FN 4:	DIVISION
FN 5:	SQUARE ROOT
FN 6:	SINE
FN 7:	COSINE
FN 8:	ROOT SUM OF SQUARES
FN 9:	IF EQUAL, JUMP
FN 10:	IF UNEQUAL, JUMP
FN 11:	IF GREATER THAN, JUMP
FN 12:	IF LESS THAN, JUMP
FN 13:	ANGLE
FN 14:	ERROR NUMBER
as of software version 05:	
FN 15:	PRINT



Parameters

Setting a parameter

Dialog prompt, e.g.

COORDINATES ?		Select axis, e.g. X.
		Press parameter key
		Enter parameter number.
		Enter sign if required.
	⋮	
		Press ENT.

Sample display

27 L X+Q13 Y-Q2
RF M

Parameter Q13 is the marker for the numerical value of the X-coordinate. Parameter Q2 is the marker for the negative value of the Y-coordinate. For example, Q13 is assigned a value of +40.000 and Q2 a value of +19.000. The tool will move to position P (X+40.000/Y-19.000)



The parameters must be defined before they are called up. Parameters not defined at the beginning of program run will automatically be assigned a value of 0.
In the above display example, the tool would traverse to the position X0/Y0.

Selecting a parameter function

Operating mode _____

Dialog initiation _____

FN 0: ASSIGN ?	or	select required parameter function.
If the required function is in the display, e.g.		
FN 9: IF EQUAL, JUMP		Press ENT.

The first dialog prompt appears in the display (see corresponding function for response).

Parameters

Parameter functions

FN 0: ASSIGN

The function FN 0: "ASSIGN" assigns either a **numerical value** or another **parameter** to a certain parameter. Assignment is designated by an "=" sign.

$$Q5 = 65.432$$

Display:

$$18 \text{ FN 0: } Q5 = + 65.432$$

FN 1: ADDITION

The function FN 1: "ADDITION" defines certain parameter as the **sum** of two parameters, two numerical values, or a parameter and a numerical value.

$$Q17 = Q2 + 5.000$$

Display:

$$12 \text{ FN 1: } Q17 = + Q2$$

$$+ \quad + 5.000$$

FN 2: SUBTRACTION

The function FN 2: "SUBTRACTION" defines a certain parameter as the **difference** between two parameters, two numerical values, or a parameter and a numerical value.

$$Q11 = 5.000 - Q34$$

Display:

$$94 \text{ FN 2: } Q11 = + 5.000$$

$$- \quad + Q34$$

FN 3: MULTIPLICATION

The function FN 3: "MULTIPLICATION" defines a certain parameter as the **product** of two parameters, two numerical values, or a parameter and a numerical value.

$$Q21 = Q1 \times 60.000$$

Display:

$$85 \text{ FN 3: } Q21 = + Q1$$

$$+ 60.000$$

FN 4: DIVISION

The function FN 4: "DIVISION" defines a certain parameter as the **quotient** of two parameters, two numerical values, or a parameter and a numerical value.
(**DIV**: abbreviation for division).

$$Q12 = Q2 / 62$$

Display:

$$73 \text{ FN 4: } Q12 = + Q2$$

$$\text{DIV} \quad + 62.000$$

FN 5: SQUARE ROOT

The function FN 5: "SQUARE ROOT" defines a certain parameter as the **square root** of a parameter or a numerical value.
(**SQRT**: abbreviation for square root).

$$Q98 = \sqrt{2}$$




Display:


$$69 \text{ FN 5: } Q98 = \text{SQRT} + 2.000$$



Parameters

Parameter functions



Program
input
Example: FN 1




Operating mode  _____
Dialog initiation   _____

FN 1: ADDITION  Press ENT to select function.



PARAMETER NUMBER FOR RESULT ?  Enter parameter number.
 Press ENT.




FIRST VALUE/PARAMETER ?

If a value is assigned:  Enter value
 Press ENT.

If a parameter is assigned:  Press parameter key.
 Enter parameter number.
 Press ENT.

SECOND VALUE/PARAMETER ?

If a value is assigned:  Enter value.
 Press ENT.

If a parameter is assigned:  Press parameter key.
 Enter parameter number.
 Press ENT.

Parameters

Parameter functions

Trigonometric functions

Sine and cosine functions establish a mathematical relationship between an angle and the side lengths of a right triangle. Trigonometric functions are programmed with

FN 6: sine, and


FN 7: cosine.

The parameter function FN13: "Angle" calculates the angle from sine and cosine values (see "Angle").

Defining trigonometric functions

$$\sin \alpha = \frac{\text{length of side opposite}}{\text{length of hypotenuse (longest side)}} = \frac{a}{c}$$


$$\cos \alpha = \frac{\text{length of side adjacent to}}{\text{length of hypotenuse (longest side)}} = \frac{b}{c}$$



Trigonometric functions in a right triangle

$$XP = R \times \cos \alpha$$

$$YP = R \times \sin \alpha$$



FN 6: Sine

The function FN 6: "Sine" defines a certain parameter as the **sine** of an angle (in degrees (°)). The angle can be a numerical value or a parameter.

$$Q10 = \sin Q8$$

Display:

$$113 \text{ FN 6: } Q10 = \text{SIN} + Q8$$

FN 7: Cosine

The function FN 7: "Cosine" defines a certain parameter as the **cosine** of an angle (in degrees (°)). The angle can be a numerical value or a parameter.

$$Q81 = \cos (- Q55)$$

Display:

$$911 \text{ FN 7: } Q81 = \text{COS} - Q55$$

Parameters


Parameter functions

Length of a segment

The parameter function FN 8: "Root sum of squares" is used to **calculate lengths of segments** (sides) in right triangles.

According to the Pythagorean Theorem:

$$a^2 + b^2 = c^2 \text{ or } c = \sqrt{a^2 + b^2}$$



FN 8: Root sum of squares

The function FN 8: "Root sum of squares" defines a certain parameter as the **square root** of the sum of two squared values or parameters.

(LEN = abbreviation for length).

$$Q3 = \sqrt{30^2 + Q45^2}$$

Display:

56 FN 8: Q3 = + 30.000

LEN + Q45

Parameters

Parameter functions

If-then jump

Parameter functions FN 9 through FN 12 can be used to compare a parameter with another parameter or with a numerical value.


Based on the result of this comparison, a jump (conditional jump) can be made to certain program marker (label).

The equations (or inequations) are:

- The first parameter is equal to a value or to a second parameter, e.g. $Q1 = Q2$
- The first parameter is not equal to a value or to a second parameter, e.g. $Q1 \neq Q2$
- The first parameter is greater than a value or than a second parameter, e.g. $Q1 > Q2$
- The first parameter is less than a value or than a second parameter, e.g. $Q1 < Q2$

If one of these equations is satisfied, a **jump** is made to a certain program marker. If the equation is not satisfied, the program continues with the next block.

=	equal
≠	unequal
>	greater than
<	less than



FN 9: If equal, then jump (go to)

When programming the function FN 9: "If equal, jump", a jump to a program marker is only made if a certain parameter is **equal to** another parameter or to a numerical value, then jump to LBL 30!

If: $Q2 = 360$,
Then jump to LBL 30!

Display:



```


47 FN 9: IF + Q2
EQU + 360.000 GOTO LBL 30
  
```

Parameters

Parameter functions

Input
Example FN 9

Operating mode 
Dialog initiation 



The on-screen displays are illustrated on the following page for the corresponding functions.

Parameters

Parameter functions

FN 10:
If **unequal**,
jump (go to)

When programming the function FN 10: "If unequal, jump", a jump to a program marker is only made if a certain parameter is **unequal to** another parameter or to a numerical value.

(NE = abbreviation for **not equal**).

If $Q3 \neq Q10$,
then jump to LBL 2!

Display:

38 FN 10: IF + Q3

NE + Q10 GOTO LBL 2

FN 11:
If **greater than**,
jump (go to)

When programming the function FN 11: "If greater than, jump", a jump to a program marker is only made if a certain parameter is **greater than** another parameter or to a numerical value.

(GT = abbreviation for **greater than**).

If $Q8 > 360$,
then jump to label 17!

Display:

28 FN 11: IF + Q8

GT + 360.000 GOTO LBL 17

FN 12:
If **less than**,
jump (go to)

When programming the function FN 12: "If less than, jump", a jump to a program marker is only made if a certain parameter is **less than** another parameter or to a numerical value.

(LT = abbreviation for **less than**).

If $Q6 < Q5$,
then jump to LBL 3!

Display:

24 FN 12: IF + Q6

LT + Q5 GOTO LBL 3

Parameters

Parameter functions

Angles from trigonometric functions

If the value of the trigonometric function $\sin \alpha$ is known, there are always two angles that can satisfy the comparison.

Example: $\sin \alpha = 0.5$
 $\rightarrow \alpha_1 = 30^\circ$
 $\rightarrow \alpha_2 = 150^\circ$

The second trigonometric function $\cos \alpha$ is needed to determine α . If the value of $\cos \alpha$ is also known, then there is a plain solution for:

$\sin \alpha = + 0.5$
 $\cos \alpha = + 0.866 \rightarrow \alpha = + 30^\circ$


accordingly:

$\sin \alpha = + 0.5$
 $\cos \alpha = - 0.866 \rightarrow \alpha = + 150^\circ$

The control system calculates the angle α using the tangent function


$$\tan \alpha = \frac{\sin \alpha}{\cos \alpha}, \text{ and therefore}$$

$$\text{arc tan } \frac{\sin \alpha}{\cos \alpha} = \alpha$$



Angles from the legs of a right angled triangle

Instead of the angle functions $\sin \alpha$ and $\cos \alpha$, the legs of a right angled triangle can also be used to determine an angle. The legs of a right angled triangle correspond to the angle functions $\sin \alpha$ and $\cos \alpha$ multiplied by the length R of the hypotenuse.



FN 13: Angle

The function FN 13: "Angle" assigns an angle to a parameter using the values from the sine and cosine functions.

In place of the angle functions the legs of a right triangle can also be entered.

If the value 0 is entered for $\cos \alpha$, the control system calculates the angle α from the pre-programmed $\sin \alpha$. When $\sin \alpha = 0$ and $\cos \alpha = 0$ are entered, the following error message will appear:
 = ARITHMETIC ERROR =



$\sin \alpha = + 0.5$
 $\cos \alpha = + 0.866$

Display:

25 FN 13: Q11 = + 0.5

ANG + 0.866

$k = 10$ $10 \times \sin \alpha = + 5$
 $10 \times \cos \alpha = + 8.660$

Display:

25 FN 13: Q11 = + 5

ANG + 8.660

Parameters

Parameter programming (Example)

Geometry


Programming with parameters will be demonstrated using an ellipse as an example.

The **ellipse** is described according to the following shape (mathematical parameter shape of the ellipse):

$$x = a \times \cos \alpha$$

$$y = b \times \sin \alpha$$

This means that every angle α has both an X-coordinate and a Y-coordinate. If you begin at $\alpha = 0^\circ$ and increase α in small increments to 360° , you will get a large number of points on an ellipse. A closed contour is formed when these points are connected by straight lines.



Parameter definition

The program essentially consists of four parts:

- parameter definition,
- positioning (linear interpolation) for milling the ellipse,
- increasing the angular increment
- parameter comparison and continued program execution until the ellipse is complete.

The following are defined as parameters:

- **Angular increment Q20:** the angle should increase in increments of 2° : $Q20 = + 2.000$
- **Starting angle Q21:** the first point on the contour has an angle of 0° : $Q21 = 0.000$
- **Semiaxis in X-direction Q23:** $Q23 = +50.000$
- **Semiaxis in Y-direction Q22:** $Q22 = +30.000$
- **X-coordinate Q25:** the numerical value of the X-coordinate is assigned to parameter Q25.
- **Y-coordinate Q24:** the numerical value of the Y-coordinate is assigned to parameter Q24.

Parameters Q25 and Q24 are defined according to the above formula:



$$(X) Q25 = Q23 \cos Q21;$$

$$(Y) Q24 = Q22 \sin Q21.$$

Both comparisons must be rewritten because they cannot be entered in this form, therefore:

first: $Q14 = \sin Q21$
 $Q15 = \cos Q21$


then: $Q24 = Q14 \times Q22$
 $Q25 = Q15 \times Q23$




Parameters

Parameter programming (Example)

Positioning block Milling of the ellipse is programmed in this block with linear interpolation.



Increasing the angular increment New angle Q21 = previous angle Q21 + angular increment Q20




Parameter comparison and program repetition

Program repetition requires that a jump marker (label) must be set prior to parameter definition for Q14 and Q15: LBL 1.

The following requirements must be met for program repetition:

If the angle Q21 is less than 360,1° (the angle must be larger than 360°, but less than 360° + angular increment), then jump (GOTO) LBL 1.

IF + Q21
LT + 360.100 GOTO LBL 1



Parameters

Special functions

FN 14: Error number

The parameter function FN 14: "Error number" is used to call up error messages and dialog from the PLC-Eprom. You call up by entering an error number from 0 to 499. The messages are allocated as follows:

Error number	On-screen display
0 ... 299	ERROR 0 ... ERROR 299
300 ... 399	PLC ERROR 01 ... PLC ERROR 99 (or dialog specified by machine tool manufacturer)
400 ... 499	Dialog 0 ... 99 for user cycles

Display:

28 FN 14: ERROR = 100

Q108 Tool radius

The control system stores the radius of the most recently activated tool under parameter Q108.

The radius can then be used for parameter calculations and comparisons.

The radius of the most recently activated tool is always assigned to parameter 108.




112 TOOL DEF 31 L = 0.700

R = 5.000

113 TOOL CALL 31 Z

S + 112.000



Q 108 = 5,000

Q109 Tool axis

On many machines, the X, Y or Z axis can be used as the tool axis. With these machines it is advantageous to be able to poll the current tool axis in the machining program; in this way, for example, program branching is possible during manufacturer cycles.

The control files the current tool axis under the parameter Q109:

Current tool axis	Parameter
No tool axis is called	Q109 = -1
X axis is called	Q109 = 0
Y axis is called	Q109 = 1
Z axis is called	Q109 = 2
IV axis is called	Q109 = 3

Parameters

Special functions

Q 110 Spindle on/off

The parameter Q 110 indicates the last M function issued for the direction of spindle rotation:

M function	Parameter
No M function	Q 110 = -1
M03 (spindle on clockwise)	Q 110 = 0
M04 (spindle on counterclockwise)	Q 110 = 1
M05, if M03 was previously issued	Q 110 = 2
M05, if M04 was previously issued	Q 110 = 3

Q 111 Coolant on/off

The parameter Q 111 indicates whether the coolant was switched on or off.

It means:

M08 coolant on	Q 111 = 1
M09 coolant off	Q 111 = 0

Q 112 Overlap factor

The parameter Q 112 contains the input value of the overlap factor during pocket milling (machine parameter 93). The overlap factor for pocket milling can be employed in Q parameter programs.

Q 113 mm/inch dimensions

The parameter Q 113 indicates whether the NC program contains mm or inch dimensions.

It means:

mm dimensions	Q 113 = 0
inch dimensions	Q 113 = 1

Parameters

Special functions


Transferring parameters to PLC-NC

The TNC 355 control system can transfer Q-parameter values from an integrated PLC to an NC program. Parameters Q100 to Q107 are used for transferring values.

A possible application is compensating for the effects of temperature on the machine.

Compensating for thermal displacement

During periods of extended machine use, thermal displacement of the machine and the workpiece effects machining precision. Devices that measure thermal displacement transfer compensation values to the control system to remedy the situation. These values can be used in a machining program, e.g. to shift the datum. This type of measuring device is available from Firma Testo-term in 7825 Lenzkirch/Schwarzwald in the Federal Republic of Germany.



Example

Thermal expansion of the machine should be offset with a datum shift.

Thermal compensation values for the machine axes are stored under parameter numbers Q100 (X-axis) and Q101 (Y-axis) and Q102 (Z-axis). The control system requests compensation values via the M-function **M70**.

Your machine tool manufacturer can tell you if your machine is capable of transferring parameters from an integrated PLC.

84	L			
		R	F	M70
85	CYCL	DEF	7.0	DATUM
86	CYCL	DEF	7.1	X + Q100
87	CYCL	DEF	7.2	Y + Q101
88	CYCL	DEF	7.3	Z + Q102

Parameters

Special functions

as of software version 05:

FN 15: PRINT

with the parameter function FN 15: PRINT current values of Q parameters can be output via the V.24 interface. A maximum of six parameters can be indicated depending on the PRINT command.

Instead of Q-Parameters, numerical values between 0 and 200 can also be entered. These numbers call error messages and dialog texts that are stored in the PLC-EPROM or the ASCII sign ETX. The allocation of numerical values to the texts is as follows:

Numerical value	Output via the V.24 interface
0 ... 99	stored error messages in the PLC
100 ... 199	Texts/Dialogs for the user cycles
200	"ETX"

Parameters for programmable touch probe function: Q115 ... Q118

The parameters Q115 to Q118 contain the measured values that have been determined via the programmable touch probe function "workpiece surface as reference surface":

Q115	measured value X axis
Q116	measured value Y axis
Q117	measured value Z axis
Q118	measured value 4 th axis

Display:

29 FN 15: PRINT Q1/Q2/Q3/Q4/Q5/Q6

Display:

120 FN 15: PRINT 12/18 8/4/10/55

Canned cycles


Introduction

Canned cycles

In order to simplify and speed up programming, frequently re-occurring machining procedures and certain coordinate transformations can be pre-programmed in the form of fixed or "canned" cycles. Examples are the milling of pockets or zero point offsets. Other programs can also be called up via cycles.

Cycle definition

Through cycle definition, the control system receives the data necessary to execute the cycle, e.g. the side length of the pocket etc. The dialogue for cycle definition is initiated by pressing the **CYCL DEF** key. The cycle is then selected with the **↓** and **↑** keys, or with the **GO TO** key.



Available cycles

Cycles 1 to 6 and 14 to 16 are **machining cycles**, i.e. they are used to carry out machining procedures on a workpiece. Cycle 9 can be used to program a dwell time and cycle 12 to call up a program. A specified spindle orientation can be programmed with cycle 13. The remaining cycles are used for various **coordinate transformations**.



Cycles for coordinate transformation terminate path compensation.

Manufacturer's cycles

Additional cycles can be stored at cycle numbers 68 to 99. Contact your machine-tool manufacturer or supplier for information.

Cycle call

A cycle call in a program causes the previously defined **machining cycle** to be run. **Coordinate transformations, dwell time** and the **contour** cycle do not require a separately programmed cycle call, they are active immediately following cycle definition.

Three programming options are available for calling a cycle:

- via a CYCL CALL block,
- via auxiliary function M99,
- via auxiliary function M89 (depending on specified machine parameters).

A call via M89 is modal, meaning that the previously defined machining cycle is called up in each subsequent positioning block. M89 is cancelled or deleted by entering M99 or by a CYCL CALL block.

CYCL DEF 1 Peck drilling	} Machining cycles
CYCL DEF 2 Tapping	
CYCL DEF 3 Slot milling	
CYCL DEF 4 Pocket milling	
CYCL DEF 5 Circular pocket	
CYCL DEF 7 Datum shift	} Coordinate transformation
CYCL DEF 8 Mirror image	
CYCL DEF 10 Rotation	
CYCL DEF 11 Scaling factor	
CYCL DEF 9 Dwell	} Cycles for machining pockets with various contours
CYCL DEF 12 Program call	
CYCL DEF 13 Spindle orientation	
CYCL DEF 6 Roughing out	} Cycles for machining pockets with various contours
CYCL DEF 14 Contour	
CYCL DEF 15 Pre-drilling	
CYCL DEF 16 Contour milling	




Only the last defined machining cycle can be accessed via a cycle call.

Canned cycles



Cycle definition


Cycle call


Defining a cycle


Operating mode _____ 
 Dialog initiation _____ 

CYCL DEF 1 PECKING


Look for name of cycle   Select cycle desired.

Select cycle by number  With GOTO.

 Enter cycle number.



 Transfer entry.


If the desired cycle is displayed, e.g.:


CYCL DEF 4 POCKET MILLING  Transfer cycle.

The first dialog prompt for the cycle selected appears on the display.
 (For the correct response see the cycle definition.)

Calling a cycle

Operating mode _____ 
 Dialog initiation _____ 

AUXILIARY FUNCTION M ?  Specify auxiliary function if required.

 Press ENT.

Sample display

95 CYCL CALL

M03

The last defined cycle is called.

The spindle rotates clockwise.

Canned cycles


Machining cycles

Preparations

Requirements

The following functions must be programmed **before a cycle is called**:

- **tool call**: to define **spindle axis** and **spindle speed**,
- **auxiliary function**: to indicate the **direction of spindle rotation**,
- **positioning block for starting position**: for the machining cycle.



Error messages

If **no tool call** is specified, the error message = **TOOL CALL MISSING** = is displayed.

If **no spindle direction** is specified, the error message = **SPINDLE ROTATES MISSING** = is displayed.


Fourth axis as spindle axis

If the fourth axis is employed as spindle axis (e.g. U, V, W) then this must be indicated in the tool call (the fourth axis is not displayed in the dialog).

Dimensions

Tool-axis dimensions in cycle definition are always based on the **starting position** of the tool and interpreted as incremental dimensions.

It is not necessary to press the **I** key.



Machining cycles (in contrast to cycles for coordinate transformation) must always be called up for execution.




Canned cycles

Coordinate transformation

General information

A coordinate transformation modifies the coordinate system defined by the "Workpiece datum" function. These cycles are active immediately after definition and do not have to be called separately.



Cancelling a cycle

Coordinate transformations remain in effect until cancelled. This is done by defining a new cycle, in which the original condition is programmed, by programming the auxiliary function M02, M30 or via the last block
END PGM ... MM (depending on specified machine parameters).

Canned cycles

Peck drilling

Input data

Set-up clearance: safety clearance between tool tip (at starting position) and workpiece surface.

Prefix sign:


- in positive axis direction +
- in negative axis direction –

Total hole depth: distance between workpiece surface and bottom of hole (tip of drill taper). See "Set-up clearance" for sign.

Pecking depth: infeed per cut, i.e. the amount by which the tool advances for each cut. See "Set-up clearance" for sign.

Dwell time: amount of time the tool remains at the total hole depth for chip breaking.

Feed rate: traversing speed of tool during machining operations.




Procedure

From its **starting position**, the tool penetrates the workpiece to the first **pecking depth**, advancing at the programmed **feed rate**. Upon reaching the first pecking depth, the tool is retracted at rapid rate to its starting position and again advanced to the first pecking depth, taking the advanced stop distance into account.

The tool then advances at the programmed feed rate to the next pecking depth, returns to the starting position etc.


The alternating drilling and retracting procedure is repeated until the programmed **total hole depth** is reached. At the end of the cycle, after the programmed dwell, the tool returns at rapid rate to the starting position.



Advanced stop distance

The advanced stop distance t is computed automatically by the control system:





- At a total hole depth of up to 30 mm:
 $t = 0,6 \text{ mm}$;
- At a total hole depth exceeding 30 mm, the following equation applies:
 $t = \text{total hole depth}/50$; however, the maximum advanced stop distance is limited to 7 mm:
 $t_{\text{max}} = 7 \text{ mm}$.








Canned cycles






Peck drilling






Cycle definition




Operating mode  _____
 Dialog initiation  or  **1**  _____




CYCL DEF 1 PECKING   Press ENT.

SET-UP CLEARANCE ?  Specify set-up clearance.
 with correct sign.
  Press ENT.


TOTAL HOLE DEPTH ?  Specify hole depth.
 with correct sign.
  Press ENT.


PECKING DEPTH ?  Specify infeed per cut.
 with correct sign.
  Press ENT.


DWELL TIME IN SECONDS ?  Specify dwell at hole bottom.
 Press ENT.


FEED RATE ? F =  Specify feed rate for pecking.
 Press ENT.




The set-up (safety) clearance, total hole depth and pecking depth (infeed per cut) must have the same sign, otherwise error message PREFIX CYCL-PARAMETER FALSE will appear on the display.

Canned cycles


Slot milling

Cycle

"Slot milling" is a combined roughing/finishing cycle.
The slot is parallel to an axis of the current coordinate system. The coordinate system may have to be rotated accordingly (see cycle 10: "Rotating the coordinate system").

Input data

Set-up clearance: see cycle 1.
Milling depth (= slot depth): distance between workpiece surface and bottom of slot. See "Set-up clearance" for sign.
Pecking depth: amount by which tool penetrates workpiece. See "Set-up clearance" for sign.
Feed rate for vertical feed: traversing speed of tool when penetrating workpiece.




1st side length: length of slot (finished size).
The programmed sign must correspond to the milling direction:
To mill from the starting position in the positive axis direction: positive sign.
To mill from the starting position in the negative axis direction: negative sign.
2nd side length: width of slot (finished size).
The sign is always positive.



The width of the slot must be larger than the diameter of the cutter.

Feed rate: traversing speed of the tool in the machining plane.




Starting position

The starting position for the "Slot milling" cycle must be approached accurately, taking the tool radius into account.

Contour approach with a linear interpolation block

The slot contour is approached at right angles to the longitudinal, with radius compensation RL/RR and auxiliary function M98.




Canned cycles

Slot milling


Contour approach with paraxial positioning blocks

The slot contour is approached in the longitudinal direction with radius compensation $R- / R+$.




Procedure

Roughing: The cutter penetrates the workpiece from the **starting position** and mills the slot in the longitudinal direction. After vertical feed at the end of the slot, milling is resumed in the opposite direction. The procedure is repeated until the programmed **milling depth** is reached.



Procedure

Finishing: The control system advances the cutter laterally, at the bottom of the slot, by the amount of the remaining finishing cut and machines the contour with **down-cut** milling. The tool then returns at rapid rate to the set-up clearance. If the number of infeeds was odd, the cutter moves along the slot to the starting position, maintaining the set-up clearance.




Notes:







Canned cycles




Slot milling




Cycle
definition




Operating mode  _____



Dialog initiation   or    _____





CYCL DEF 3 SLOT MILLING  Press ENT.

SET-UP CLEARANCE ?  Specify set-up clearance.
 with correct sign.
 Press ENT.

MILLING DEPTH ?  Specify milling depth.
 with correct sign.
 Press ENT.

PECKING DEPTH ?  Specify infeed per cut.
 with correct sign.
 Press ENT.

FEED RATE FOR PECKING ?  Specify feed rate for vertical feed.
 Press ENT.

FIRST SIDE LENGTH ?  Specify longitudinal axis of slot,
 e.g. X.
 Specify length of slot.
 with correct sign.
 Press ENT.

Notes:



Canned cycles

Slot milling

SECOND SIDE LENGTH ? ▶ **Y** Specify axis for slot width, e. g. Y.
 ▶ Enter width of slot with positive sign.
 ▶ **ENT** Press ENT.

FEED RATE ? F= ▶ Specify feed rate for slot milling.
 ▶ **ENT** Press ENT.



Enter set-up clearance, milling depth and infeed per cut (pecking depth) with the same sign.

Sample display

100 CYCL DEF 3.0 SLOT MILLING
101 CYCL DEF 3.1 SET-UP -2.000
102 CYCL DEF 3.2 DEPTH -40.000
103 CYCL DEF 3.3 PECKING -20.000
F 80
104 CYCL DEF 3.4 X -120.000
105 CYCL DEF 3.5 Y +21.000
106 CYCL DEF 3.6 F 100

Cycle definition "Slot milling" occupies 7 program blocks.

Set-up clearance

Milling depth

Infeed per cut

Feed rate for vertical feed

Length of slot

Width of slot

Feed rate

Canned cycles

Pocket milling

Cycle

The machining cycle "Pocket milling" is a **roughing cycle**.

The sides of the pockets are parallel to the axes of the current coordinate system. The coordinates system may have to be rotated accordingly (see cycle 10: "Rotating the coordinate system").




The radius on the corners of the pocket are determined by the tool. There is no circular movement in the corners of the pocket.

Input data

Set-up clearance: see cycle 1.

Milling depth (= pocket depth): distance between workpiece surface and pocket bottom. See "Set-up clearance" for sign.



Pecking depth: infeed per cut, i.e. amount by which tool penetrates workpiece. See "Set-up clearance" for sign.

Feed rate for vertical feed: traversing speed of tool when penetrating workpiece.

1st side length: length of pocket parallel to first main axis of machining plane. Sign is always positive.


2nd side length: width of pocket. The sign is also positive.

Feed rate: traversing speed of tool in machining plane.

Rotation: Direction of rotation of cutter path:

DR+: positive rotation (counterclockwise), down-cut milling;

DR-: negative rotation (clockwise), up-cut milling




Start position

The start position must be approached in a previous positioning block without tool radius compensation.

Procedure

The tool penetrates the workpiece from the **starting position** (pocket centre) and then follows the path indicated. The starting direction of the cutter path is the positive axis direction of the longer side, i.e. if this side is parallel to the X-axis, the cutter starts off in the positive X-direction. When milling square pockets, the cutter will always start in the positive Y-direction.




Canned cycles

Pocket milling

Procedure

The direction of rotation depends on the programmed **rotation** (in this case DR+). The maximum **stepover** is k .

The procedure is repeated until the programmed **milling depth** is reached; the tool then returns to the starting position.



Stepover

The control system calculates the stepover factor k according to the following equation:

$$k = K \times R$$

k : stepover

K : overlap factor determined by machine manufacturer (depends on specified machine parameters)

R : cutter radius

Notes:



Canned cycles

Pocket milling

Cycle
definition

Operating mode _____



Dialog initiation _____



or



4



CYCL DEF 4 POCKET MILLING



Press ENT to select cycle.

SET-UP CLEARANCE ?



Specify set-up clearance.



with correct sign.



Press ENT.

MILLING DEPTH ?



Specify milling depth.



with correct sign.



Press ENT.

PECKING DEPTH ?



Specify infeed per cut.



with correct sign



Press ENT.

FEED RATE FOR PECKING ?



Specify rate of vertical feed.



Press ENT.

FIRST SIDE LENGTH ?



Enter axis of side 1, e.g. X.



Specify first side length with positive sign.



Press ENT.

SECOND SIDE LENGTH ?



Enter axis of side 2, e.g. Y.



Specify second side length with positive sign.




Press ENT.

Notes:



Canned cycles

Pocket milling



Enter set-up clearance, milling depth and infeed per cut with same sign.

Sample display

250 CYCL DEF 4.0 POCKET MILLING
251 CYCL DEF 4.1 SET-UP -2.000
252 CYCL DEF 4.2 DEPTH -30.000
253 CYCL DEF 4.3 PECKING -10.000
F 80
254 CYCL DEF 4.4 X +80.000
255 CYCL DEF 4.5 Y +40.000
256 CYCL DEF 4.6 F 100 DR+

Cycle definition "Pocket milling" occupies 7 program blocks.

Set-up clearance

Milling depth

Infeed per cut

Feed rate for vertical feed

Length of 1st pocket side

Length of 2nd pocket side


Feed rate and cutter path rotation

Canned cycles

Milling a circular pocket


Cycle

"Circular pocket" is a **roughing cycle**.



Input data

Set-up clearance: see cycle 1.
Milling depth (= pocket depth): distance between workpiece surface and pocket bottom. See "Set-up clearance" for sign.
Pecking depth: infeed per cut, i.e. amount by which tool penetrates workpiece. See "Set-up clearance" for sign.
Feed rate for vertical feed: traversing speed of tool when penetrating workpiece.
Circle radius: radius of circular pocket.
Feed rate: traversing speed of tool in machining plane.
Rotation: Direction of rotation of cutter path:
 DR+: positive rotation (counterclockwise), down-cut milling;
 DR-: negative rotation (clockwise), up-cut milling




Start position

The start position has to be approached in a previous positioning block without radius compensation.

Procedure

The tool penetrates the workpiece from the **starting position** (pocket centre).



Canned cycles

Milling a circular pocket

Procedure


The cutter then follows the illustrated spiral path; its direction depends on the programmed **rotation** (in this case DR+). The starting direction of the cutter is:

- the Y+ direction for the X, Y plane,
- the X+ direction for the Z, X plane,
- the Z+ direction for the Y, Z plane.

The maximum **stepover** is the amount of k (see "Pocket milling" cycle).

The procedure is repeated until the programmed **milling depth** is reached.

The tool then returns to the starting position



Milling a circular pocket with the 4th axis

If the TNC's fourth axis controls an additional linear axis U, V or W, the fourth axis can also be used to mill a circular pocket.

To do this, the fourth axis must be programmed before the cycle call in the last positioning block.

Example:

```
15 L X+50.000 V+50.000
```

```
RO F M
```

```
16 CYCL CALL
```

```
M
```

Notes:



Canned cycles

Milling a circular pocket

Cycle
definition

Operating mode _____ 

Dialog initiation _____   or   

CYCL DEF 5 CIRCULAR POCKET



Press ENT.

SET-UP CLEARANCE ?



Specify set-up clearance.



with correct sign.



Press ENT.

MILLING DEPTH ?



Specify milling depth.



with correct sign.



Press ENT.

PECKING DEPTH ?



Specify infeed per cut.



with correct sign.



Press ENT.

FEED RATE FOR PECKING ?



Specify rate of vertical feed.



Press ENT.

CIRCLE RADIUS ?



Specify radius of circular pocket.



Press ENT.

FEED RATE ? F =



Specify feed rate for milling circular pocket



Press ENT.

Notes:



Canned cycles

Milling a circular pocket

ROTATION CLOCKWISE: DR- ?



Specify rotation of cutter path.



Press ENT.



Sample display

Enter set-up clearance, milling depth and infeed per cut with same sign.

40 CYCL DEF 5.0 CIRCULAR POCKET

Cycle definition "Circular pocket" occupies 6 program blocks.

41 CYCL DEF 5.1 SET-UP -2.000

Set-up clearance

42 CYCL DEF 5.2 DEPTH -60.000

Milling depth

43 CYCL DEF 5.3 PECKING -20.000

Infeed per cut

F80

Feed rate for vertical feed

44 CYCL DEF 5.4 RADIUS 120.000

Circle radius

45 CYCL DEF 5.5 F100 DR-

Feed rate and cutter path rotation


Canned cycles

Variable-contour pockets

Introduction

Four cycles are required for milling pockets with variable contours:

- **Cycle 14: CONTOUR GEOMETRY** (list of sub-routines containing subcontours)
- **Cycle 15: PILOT DRILL** (rough drilling to pocket depth for all partial contours)
- **Cycle 6: ROUGH-OUT** (rough-milling of contour and clearing of pocket)
- **Cycle 16: CONTOUR MILL** (finish-milling of contour pocket).




Contour

The contour consists of one or more **pockets** and **islands** within the pocket. A total of up to **12 subcontours** is possible. Each subcontour must be programmed as a closed loop of contour elements.

All contour function keys are permitted for programming. Subroutines, program part repetitions and Q parameter functions (FN) can also be programmed.

No coordinate conversions are allowed within contour definitions. Coordinate conversions can, however, be applied to the entire pocket.



Check the program with the help of the graphic display before machining. The control can not calculate all geometries for pockets with various contours.



Canned cycles

Variable-contour pockets

Pocket


Pockets can be defined in two ways:

Option 1:

- Clockwise sequence of contour elements
- Radius compensation RR

Option 2:

- Counterclockwise sequence of contour elements
- Radius compensation RL



Island


Islands can also be defined in two ways:

Option 1:

- Clockwise sequence of contour elements
- Radius compensation RL

Option 2:

- Counterclockwise sequence of contour elements
- Radius compensation RR




Canned cycles

Variable-contour pockets

Superimposing pockets and islands


Pockets and islands can be superimposed (overlaid) on one another. The TNC computes the resulting contour automatically from the starting point of the first subcontour.




For this reason, the starting point of the subcontour is the determining factor of the resulting contour pocket.

Superimposing pockets

The starting point of pocket contour 1 is located outside the area of pocket 2, the areas of both pockets will be cleared.



The starting point of pocket contour 1 is located within the area of pocket 2, only the common area of the two pockets will be cleared.




Canned cycles


Variable-contour pockets

Superimposing islands

The starting point of island contour 1 is located outside the area of island 2, neither of the areas of the two islands will be cleared.



The starting point of island contour 1 is located within the area of island 2, only the common areas of the two islands will remain.




Canned cycles

Variable-contour pockets

Superimposing pockets and islands

If pocket areas are reduced in size by superimposed islands, the starting point of pocket contour 1 must be located outside of island 1.


An island can also reduce several pocket areas. The starting points of the pocket contours must all lie outside of the island.



If island areas are reduced in size by superimposed pockets, the starting point of pocket contour 2 must be located outside of island 1.

A pocket can also reduce several island areas. The starting point of the overlapped pocket must lie within the first island. The starting points of the other intersected island contours must lie outside the pocket.


Pocket 2 must not intersect pocket 1, otherwise pockets 1 and 2 will be combined.



Canned cycles

Variable-contour pockets

Programming subcontours

Partial contours are saved and stored in **subroutines**. The first point of the subcontour is the **starting position**, where machining begins. The starting position of the first subcontour is also the penetration point for the cycle "Pilot drilling". The starting position is programmed via linear interpolation using the  key.




The first subcontour must be a pocket.



The starting position cannot be located on the contour of an island.



Radius compensation RL/RR should not be changed within a subcontour or a subroutine.



Canned cycles

Variable-contour pockets


Cycle 14: Contour geometry

Cycle

The label numbers (subroutines) of the subcontours are defined in cycle 14 "CONTOUR GEOMETRY". Up to 12 label numbers can be entered. The TNC computes the intersecting points of the resulting contour pocket from the programmed subcontours.

Cycle 14 "CONTOUR GEOMETRY" is active immediately following definition; no separate cycle call is necessary.

The first subcontour must be programmed as a pocket.



Canned cycles

Variable-contour pockets

Cycle 14: Contour geometry

Definition

Operating mode _____



Dialog initiation _____



or



CYCLE DEF 14 CONTOUR GEOM. ▶ Press ENT to select cycle

LABEL NUMBERS FOR CONTOUR ? ▶ Enter label number of first contour.
 ▶ Press ENT.
 ▶ Enter label number of second contour.
 ▶ Press ENT.
 .
 .
 .
 After entering final label number: ▶ Press ENT.
 ▶ Press END to transfer cycle definition.

Sample display

5 CYCL DEF 14.0 CONTOUR GEOM.
6 CYCL DEF 14.1 CONTOUR LABEL
 11 / 12 / 13 /

Cycle definition occupies up to 3 program blocks.

Subroutines with label numbers 11, 12 and 13 define the contour pocket.

Canned cycles

Variable-contour pockets


Cycle 15: Pilot drill

Cycle

Cycle 15 is used to drill pilot holes at cutter infeed points. The positions of the infeed points are identical to the starting positions of the subcontours. In the case of closed loops of contour elements, produced by superimposing several pockets and islands, the infeed point is the starting position of the first subcontour.



The cycle "Pilot drill" must be called separately.




Input data

Set-up clearance: see cycle 1.
Total hole depth: distance between workpiece surface and bottom of pocket. See "Set-up clearance" for sign.
Pecking depth: infeed per cut, i.e. the amount by which the tool penetrates the workpiece for each cut. See "Set-up clearance" for sign.
Feed rate: traversing rate of tool when penetrating workpiece.
Contour mill allowance: allowance for the finishing procedure (positive value). It is possible to enter a negative mill allowance under certain circumstances (see cycle 6: Rough-out).




The tool must be located at the set-up clearance before the cycle is called.



Procedure

The control system positions the tool above the first infeed point at the programmed **set-up clearance**. Positioning is dependent on **tool radius** and **contour mill allowance**. The tool, moving at the programmed **feed rate**, then penetrates to the first **pecking depth**. After drilling to this depth, the tool returns at rapid rate to the starting position and then plunges back to the first depth. The tool then advances again at the programmed feed rate by the amount of the infeed increment, returns to the starting position and so on. The alternating drilling/retracting action is repeated until the programmed **total hole depth** is reached. Finally, the control system positions the tool at the programmed set-up clearance above the second infeed point and repeats the drilling operation. The advanced halting distance corresponds to the set-up clearance.








Canned cycles


Variable-contour pockets

Cycle 15: Pilot drill

Definition

Operating mode  _____

Dialog initiation   or  **1** **5** 



Sample display

```

18 CYCL DEF 15.0 PILOT DRILL
19 CYCL DEF 15.1 SET-UP -2.000
    DEPTH -20.000
20 CYCL DEF 15.2 PECKG -10.000
    F40    ALLOW +1.000
  
```

Cycle definition occupies up to 3 program blocks.

Set-up clearance

Total hole depth

Infeed per cut

Rate of infeed and finishing allowance.

Canned cycles

Variable-contour pockets


Cycle 6: Rough-out

Cycle

Cycle 6 defines the roughing procedure for clearing the pocket




The cycle "Rough-out" must be called separately.



Input data


Set-up clearance: see cycle 1.
Milling depth: distance between workpiece surface and pocket bottom. See "Set-up clearance" for sign.
Pecking depth: infeed per cut, i.e. the amount by which the tool penetrates the workpiece for each cut. See "Set-up clearance" for sign.
Feed rate for pecking: traversing rate of tool when penetrating workpiece.
Contour mill allowance: allowance for the finishing procedure (positive numerical value).
Rough-out angle: direction for clearing pocket, based on angular reference axis of machining plane.
Feed rate: traversing speed of tool in machining plane.



The tool must be located at the set-up clearance before the cycle is called.

Procedure

The control system positions the tool automatically above the first infeed point, taking the programmed **contour mill allowance** into account.
Beware of collision with clamping devices!
The tool then penetrates the workpiece.
After reaching the first **pecking depth**, the tool mills the first subcontour at the programmed **feed rate**, taking the finishing allowance into account.
The direction of rotation for rough-milling is determined by a machine parameter defined by the machine manufacturer.



Canned cycles


Variable-contour pockets

Cycle 6: Rough-out

Procedure

At the infeed point, the control system advances the tool to the next pecking depth. The procedure is repeated until the programmed **milling depth** is reached.


The remaining subcontours are milled in the same manner.



The pocket is then cleared. The direction of feed corresponds to the programmed **rough-out angle**. The stepover per cut corresponds to the cutter radius.

The pocket can be cleared with multiple vertical feed motions.

At the end of the cycle, the control system retracts the tool to the set-up clearance.



Notes:









Canned cycles


Variable-contour pockets

Cycle 6: Rough-out

Definition

Operating mode _____ 

Dialog initiation _____   or   



Notes:



Canned cycles

Variable-contour pockets

Cycle 6: Rough-out

Sample display

16 CYCL DEF 6.0 ROUGH-OUT
17 CYCL DEF 6.1 SET-UP -2.000
DEPTH -20.000
18 CYCL DEF 6.2 PECKG -10.000
F40 ALLOW +1.000
19 CYCL DEF 6.3 ANGLE +0.000
F60

Cycle definition occupies 4 program blocks.

Set-up clearance

Milling depth

Infeed per cut

Feed rate for tool infeed and finishing allowance

Rough-out angle

Feed rate in machining plane.

Canned cycle

Variable-contour pockets

Cycle 16: Contour mill

Cycle


Cycle 16 "CONTOUR MILL" is used to finish-mill the contour pocket.



The cycle can also be used for general milling of contours that are made up of subcontours.

This provides the following advantages:

- contour intersections are calculated.
- collisions are prevented.



The cycle "Contour mill" must be called separately.

Input data

Set-up clearance: see cycle 1.

Milling depth: distance between workpiece surface and pocket bottom. See "Set-up clearance" for sign.

Pecking depth: infeed per cut, i.e. the amount by which the tool penetrates the workpiece for each cut. See "Set-up clearance" for sign.


Feed rate for pecking: traversing rate of tool when penetrating workpiece.

Direction of rotation for contour milling: cutting direction along the pocket contour (island contours: opposite cutting direction)

DR+: positive rotation,
down-cut milling for pocket and island

DR-: negative rotation,
up-cut milling for pocket and island.

Feed rate: traversing speed of tool in machining plane.



The tool must be located at the set-up clearance before the cycle is called.

Procedure


The control system positions the tool automatically above the first infeed point. **Beware of collision with clamping devices!**

Moving at the programmed **feed rate**, the tool then penetrates to the first **pecking depth**.

When this depth is reached, the tool mills the first contour, moving at the programmed **feed rate** and taking the specified **direction of rotation** into account.

At the infeed point, the control system advances the tool to the next pecking depth, repeating the procedure until the programmed **milling depth** is reached.

The remaining subcontours are milled in the same manner.



Canned cycles

Variable-contour pockets

Cycle 16: Contour mill




Definition




Operating mode _____ 




Dialog initiation _____



  or  **1** **6** 



CYCL DEF 16 CONTOUR MILL  Press ENT to select cycle.



SET-UP CLEARANCE ?  Specify set-up clearance.
 with correct sign.
 Press ENT.

MILLING DEPTH ?  Specify milling depth.
 with correct sign.
 Press ENT.

PECKING DEPTH ?  Specify infeed per cut.
 with correct sign.
 Press ENT.

FEED RATE FOR PECKING ?  Specify feed rate for vertical feed.
 Press ENT.

CW/CCW PATH FOR CONTOUR MILL ?  Specify cutting direction.
 Press ENT.

FEED RATE ? F =  Specify feed rate for milling pocket.
 Press ENT.

Notes:



Canned cycles

Variable-contour pockets

Cycle 16: Contour mill

Sample display

25 CYCL DEF 16.0 CONTOUR MILL
26 CYCL DEF 16.1 SET-UP -2.000
DEPTH -20.000
27 CYCL DEF 16.2 PECKG -10.000
F40 DR- F60

Cycle definition occupies 3 program blocks.

Set-up clearance

Milling depth

Infeed per cut

Feed rate for vertical feed,
cutting direction and feed rate in machining
plane.

Canned cycles


Variable-contour pockets

Program format and cycle sequence



The program format shown at the right is recommended for programming a variable-contour pocket.

Use the graphics feature to check the contour pocket before running the program on the machine.



Canned cycles

Variable-contour pockets

Example


Pocket contour

The pocket shown in the illustration is made up of three subcontours:

Subcontour 1: pocket

Subcontour 2: island within pocket

Subcontour 3: island superimposed over pocket (subcontour 1)



Beginning of program

The program for milling the pocket is program number 40. The blank workpiece dimensions for graphics simulation are defined in the BLK FORM blocks.

0	BEGIN	PGM 40	MM
1	BLK FORM 0.1	Z X+0.000	
		Y+0.000	Z-25.000
2	BLK FORM 0.2	X+80.000	
		Y+60.000	Z+0.000

Tool definition

The tools are defined at the beginning of the program. Three tools are required to mill the pocket.

Tool 11: for pilot drilling

Tool 12: for roughing and clearing

Tool 13: for finishing.

3	TOOL	DEF 11	L+0.000
			R+2.000
4	TOOL	DEF 12	L-4.900
			R+2.000
5	TOOL	DEF 13	L-2.500
			R+2.000

Canned cycles


Variable-contour pockets

Example

Contour definition

The label numbers of the subcontours are programmed during contour definition.

The TNC computes the intersecting points of the pocket contour from the programmed subcontours.



Tool change/ Set-up clearance

The tool change position is also programmed in a subroutine with the label number 1.

Tool No. 11 for pilot drilling is then called and positioned at the set-up clearance.

```

8 LBL 1
9 TOOL CALL 0          Z
                      S
10 L Z+100.000
                      R0 F15999 M
11 L X-50.000        Y-50.000
                      R F      M06
12 LBL 0
13 TOOL CALL 11      Z
                      S 140.000
14 L Z+2.000
                      R0 F15999 M

```

Pilot drilling

The cycle "Pilot drill" contains all the data required for vertical feed and penetration. The cycle "Pilot drill" must be called separately.

```

15 CYCL DEF 15.0 PILOT DRILL
16 CYCL DEF 15.1 SET-UP -2.000
                      DEPTH -20.000
17 CYCL DEF 15.2 PECKG -10.000
                      F40          ALLOW +0.500
18 CYCL CALL
                      M13

```

Canned cycles

Variable-contour pockets

Example

Tool change/ Set-up clearance

The next tool change takes place by calling the subroutine with the label number 1. Tool No. 12 is then called for rough-milling the pocket contour and positioned at the set-up clearance.

19 CALL LBL 1 REP
20 TOOL CALL 12 Z
S 140.000
21 L Z+2.000
R F M

Roughing-out

The cycle "Rough-out" contains all the data required for rough-milling the pocket. The cycle "Rough-out" must be called separately.

The TNC then mills the contour of the pocket, taking the finishing allowance into account. The pocket is then cleared at the programmed angle.

22 CYCL DEF 6.0 ROUGH-OUT
23 CYCL DEF 6.1 SET-UP -2.000
DEPTH -20.000
24 CYCL DEF 6.2 PECKG -10.000
F40 ALLOW 0.500
25 CYCL DEF 6.3 ANGLE +45.000
F140
26 CYCL CALL
M13

Tool change/ Set-up clearance

Again the tool change takes place by calling the subroutine with the label number 1. Tool No. 13 is then called for finishing the pocket contour and positioned at the set-up clearance.

27 CALL LBL 1 REP
28 TOOL CALL 13 Z
S 140.000
29 L Z+2.000
R F M

Canned cycles

Variable-contour pockets

Example

Contour milling

The cycle "Contour mill" contains all the data necessary for finish-milling the pocket contour. In addition, the milling direction can be specified, i.e. the pocket contour can be finished with down-cut or up-cut milling. In the example, DR- is programmed for down-cut milling. A cycle call is required for cycle contour milling.

```

30 CYCL DEF 16.0 CONTOUR MILL
31 CYCL DEF 16.1 SET-UP -2.000
    DEPTH -20.000
32 CYCL DEF 16.2 PECKG -10.000
    F80    DR-    F120
33 CYCL CALL
    M13
  
```

Tool change/ STOP


By calling the subroutine with the label number 1, the TNC moves the tool to the change position. The program is then interrupted with STOP; the auxiliary function M02 or M30 causes a return to the beginning of the program.

```

34 CALL LBL 1  REP
35 STOP
    M02
  
```

Subroutines

After the programmed STOP, the subroutines for the three subcontours are programmed according to the dimensions shown in the drawing.



Canned cycles

Variable-contour pockets

Example

Subcontour 1

Subcontour 1 "Pocket" is programmed in the sub-routine with the label number 11.

Because the contour elements are programmed clockwise, the radius compensation for the pocket contour is RR.

36 LBL 11
37 L X+60.000 Y+40.000
RR M
38 CC X+60.000 Y+25.000
39 CP IPA-180.000
DR- R F M
40 L X+20.000
R F M
41 CC X+20.000 Y+25.000
42 CP IPA-180.000
DR- R F M
43 L X+60.000
R F M
44 LBL 0

Subcontour 2

Subcontour 2 "Island" is programmed in the sub-routine with the label number 12.

Because the contour elements are programmed counterclockwise, the radius compensation for the island contour is RR.

45 LBL 12
46 L X+60.000 Y+25.000
RR M
47 L IX-15.000
R F M
48 CC IX+0.000 IY-4.500
49 CP IPA+180.000
DR+ R F M
50 L IX+15.000
R F M
51 CC IX+0.000 IY+4.500
52 CP IPA+180.000
DR+ R F M
53 LBL 0

Subcontour 3

Subcontour 3 "Island" is programmed in the sub-routine with the label number 13.

Because the contour elements are programmed counterclockwise, the radius compensation for the island contour is RR.

54 LBL 13
55 L X+40.000 Y+47.000
RR M
56 CC IX-6.000 Y+47.000
57 CP IPA+180.000
DR+ R F M
58 L IY-10.000
R F M
59 CC IX+6.000 IY+0.000
60 CP IPA+180.000
DR+ R F M
61 L X+40.000 Y+47.000
R F M
62 LBL 0

Canned cycles



Variable-contour pockets

Example

Modifying a pocket contour

In the preceding example, subcontour 3, with the sequence of contour elements and the radius compensation RR (block 55), is programmed as an island superimposed on the first subcontour.

By **changing the radius compensation** for subcontour 3 from RR to RL, the island becomes a pocket. The resulting pocket contour increases in size accordingly.



Notes:




[Faint, illegible text or markings, possibly bleed-through from the reverse side of the page.]

Canned cycles

Datum shift


Cycle

The datum (zero point) can be shifted to any location within a program. This feature allows you to carry out identical machining operations (e.g. milling slots or pockets) at various locations on a workpiece, without having to create and enter a new program for each job.



Datum shift


for a datum shift, also called a zero offset, you need only enter the coordinates of the new datum or zero point. The control then shifts the coordinate system, with the axes **X**, **Y**, **Z** and the **4th axis**, to the new, offset datum. All subsequent coordinate data are then based on the new datum.




Incremental – absolute

The coordinates can be entered as follows when defining the cycle:

- **Absolute:** the coordinates of the new datum are based on the original workpiece datum



- **Incremental:** the coordinates of the new datum are based on the previously valid datum, which may have already been shifted



Cancelling a datum shift

To cancel a programmed datum shift:

- Enter an absolute datum shift with **X 0.000/ Y 0.000/Z 0.000/IV. 0.000**;
- Enter the auxiliary function **M02**, **M30** or block **END PGM ... MM** (depending on specified machine parameters).

Canned cycles

Datum shift

Cycle definition

Operating mode _____



Dialog initiation _____



or



CYCL DEF 7 DATUM SHIFT ▶ Press ENT to select cycle.

DATUM SHIFT ? ▶ Select axis.

▶ Incremental – absolute?

▶ Enter coordinates of new datum.

▶ .

▶ .

▶ Press ENT.

Numerical values can be assigned to all axes X, Y, Z, IV. for datum shift.

After entering the coordinates of the new datum:



The cycle "Datum shift" is active immediately after cycle definition. The on-screen status display shows the shift, based on the work-piece datum.

Sample display

10 CYCL DEF 7.0 DATUM SHIFT

11 CYCL DEF 7.1 X + 20.000

12 CYCL DEF 7.2 Y + 10.000

13 CYCL DEF 7.3 Z + 10.000

14 CYCL DEF 7.4 C + 90.000


Cycle definition "Datum shift" occupies up to 5 program blocks.

Canned cycles

Mirror image

Cycle

Mirror-imaging an axis about the datum reverses the direction of the axis and changes the +/- sign of all coordinates of the axis. This produces a mirrored (reversed) image of a programmed contour or hole pattern. Mirror imaging is possible only in the machining plane, by reversing one or both axes simultaneously.




Mirror axis

The axis or axes to be mirrored are programmed for mirror imaging. When specifying coordinates in the program, the signs for the axes are reversed. If the tool axis is mirror-imaged, the error message: = MIRROR IMAGE ON TOOL AXIS = is displayed.

Machining direction

Mirror-imaging across one axis: The machining direction is reversed along with the signs of the coordinates. If a contour was originally milled counterclockwise, mirror-imaging will cause it to be machined clockwise. The milling direction does not change in canned cycles.

Mirror-imaging across two axis: The contour mirrored across one axis is reversed again across a second axis; the machining direction is also reversed a second time, maintaining the original direction.





Datum

When programming, make sure that the mirrored coordinate axis is located exactly between the mirrored contour and the contour to be produced by mirror-imaging. Program a datum shift prior to cycle definition if required.

Cancelling mirror-imaging

To cancel mirror-imaging:

- Program the cycle "Mirror-image", responding to the dialog prompt by pressing .
- Program the auxiliary function M02, M30 or the block END PGM ... MM (depending on specified machine parameters).






Canned cycles

Mirror image



Cycle definition

Operating mode  _____
 Dialog initiation   or    _____

CYCL DEF 8 MIRROR IMAGE  Press ENT to select cycle.

MIRROR IMAGE AXIS ?  Specify axis to mirror-image, e.g. X
 To mirror-image **across two axes simultaneously:**  Specify second axes to mirror-image, e.g. Y.
 Press END to select axes and terminate entry.



Always press  to terminate the entry of axis directions or axes without numerical values.
 If the entry of the axis or axes is concluded by pressing , the error message = WRONG AXIS PROGRAMMED = will be displayed.



The cycle "Mirror image" is active immediately after cycle definition. The mirrored axes are highlighted in the status display for datum shift.

Sample display

120 CYCL DEF 8.0 MIRROR IMAGE
121 CYCL DEF 8.1 X

Cycle definition "Mirror image" occupies 2 program blocks.
 Mirrored axis: X. Signs for X-coordinates are reversed in following program blocks.



If the fourth axis is to be mirrored as a linear axis (e.g. U-axis), then both parallel axes must be entered in the mirror cycle (e.g. CYCL DEF 8.1 x U).


Canned cycles

Rotating the coordinate system

Cycle

The coordinate system can be rotated about the datum in the machining plane within a program.

This feature makes it possible to mill pockets whose sides are not parallel to the original coordinate axes, without calculating effort.



Rotation angle


Only the **rotation angle ROT** need be programmed for rotation.

The rotation angle is always based on the datum of the coordinate system – the centre of rotation. The **reference axis** for programming in absolute dimension is:

- the + **X-axis** in the **X, Y plane**,
- the + **Y-axis** in the **Y, Z plane**,
- the + **Z-axis** in the **Z, X plane**.

All coordinate data following the rotation are based on the datum with the rotated coordinate system.

The rotation angle can also be entered in incremental dimensions.



Input range

The rotation angle is entered in degrees ($^{\circ}$). Input range: -360° to $+360^{\circ}$ (incremental and absolute).


Rotation and datum shift

The "Rotation" and "Datum shift" cycles can be combined by programming them one after another. This makes a simultaneous shift and rotation of the coordinate system possible.

Cancelling rotation

To cancel coordinate system rotation:

- Program rotation with rotation angle 0° (ROT 0.000).
- Program the auxiliary function M02, M30 or the block END PGM . . MM (depending on specified machine parameters).



Canned cycles

Rotating the coordinate system

Cycle definition

Operating mode _____



Dialog initiation _____



or



CYCL DEF 10 ROTATION ▶ Press ENT to select cycle.

ROTATION ANGLE ? ▶ Specify rotation angle.

 Incremental-Absolute?

 Press ENT.



The cycle for coordinate system rotation is active immediately after cycle definition. The absolute rotation angle is indicated in the status display by "ROT ...".

Sample display

184 CYCL DEF 10.0 ROTATION
185 CYCL DEF 10.1 ROT + 45.000

Cycle definition "Rotation" occupies 2 program blocks.

Rotation angle in degrees (°).



The "rotating the coordinate system" cycle is not effective in the fourth axis.

Canned cycles

Scaling factor


Cycle

Contours in the machining plane can be enlarged or reduced in size within a program.

This feature makes it possible to create similar geometrical contours without having to re-program them and to program shrinkage and over-size allowances.



Depending on the specified machined parameters, the scaling factor functions either in the machining plane or on the three main axes.
Contact your machine manufacturer or supplier for information.




Scaling factor

To enlarge or reduce the size of a contour, program the scaling factor SCL.
The control system multiplies by this factor all coordinates and radii of the machining plane or all three axes X, Y and Z (independent of a machine parameter), that are executed following the cycle.
Input range: 0 to 99.999999.


Location of datum

The position of the datum of the coordinate system does not change when the contour is enlarged or reduced in size.
To produce a geometrically similar contour at the intended location on the workpiece, it may be necessary to program a datum shift and/or a rotation of the coordinate system.



Cancelling the scaling factor

- To cancel the cycle "Scaling":
- Program "Scaling" cycle with factor 1.0.
 - Program the auxiliary function M02, M30 or the block END PGM ... MM (depending on specified machine parameters).



Canned cycles

Scaling factor

Cycle definition

Operating mode _____



Dialog initiation _____



or



CYCL DEF 11 SCALING



Press ENT to select cycle.

FACTOR ?



Specify scaling factor.



Press ENT.



The cycle "Scaling" is active immediately after cycle definition. The scaling factor is indicated in the status display by "SCL ...".

Sample display

12 CYCL DEF 11.0 SCALING

13 CYCL DEF 11.1 SCL 0.750000

Cycle definition "Scaling" occupies 2 program blocks.

All subsequent coordinate data are reduced by 0.75 by programming the scaling factor 0.75.

Canned cycles

Dwell time

Cycle


The cycle "Dwell time" can be used within a program to interrupt the feed motion for a specified period of time while the spindle is still running, e.g. for chip breaking with single-point boring operations. The cycle "Dwell time" is run immediately after cycle definition.

Input range

Dwell time is indicated in seconds.
Input range: 0.000 s to 19,999.999 s.



Entering 19,999.999 s results in an operating pause of 5.5 hours!



Canned cycles

Dwell time

Cycle definition

Operating mode _____



Dialog initiation _____



or



CYCL DEF 9 DWELL TIME ▶ Press ENT to select cycle.

DWELL TIME IN SEC. ? ▶ Specify required dwell.
▶ Press ENT.



The cycle "Dwell time" is run immediately after cycle definition.

Sample display

97 CYCL DEF 9.0 DWELL TIME
98 CYCL DEF 9.1 DWELL 10.000

Cycle definition "Dwell time" occupies 2 program blocks.

Canned cycles

Freely programmable cycles (Program call)

Cycle

The cycle "Program call" makes it more convenient to call programs, via CYCL CALL, M89 and M99, that were created with the aid of parameter functions, such as area clearance cycles. This gives these freely programmable (variable) cycles the same status as the pre-programmed canned cycles.

Canned cycles

Freely programmable cycles (Program call)

Cycle
definition

Operating mode _____



Dialog initiation _____



or



CYCL DEF 12 PGM CALL



Press ENT to select cycle.

PROGRAM NUMBER ?



Enter program number.



Press ENT.

Sample display

5 CYCL DEF 12.0 PGM CALL

6 CYCL DEF 12.1 PGM 23

The called cycle is programmed in program 23.

Canned cycles

Spindle orientation

Introduction	<p>Used as a 5th axis, the TNC 355 can control the main spindle of a machine tool and rotate it into a specified position.</p> <p>Applications of the spindle orientation feature include certain tool change systems that require the tool to be in a defined position relative to the changer, or for aligning the transmitter/receiver window of the HEIDENHAIN TS 511 infrared touch-probe system.</p>
Defining position	<p>Spindle positioning (orientation) is activated via an auxiliary function. The position can be defined by means of</p> <ul style="list-style-type: none">• machine parameters, or• cycle 13 "Spindle orientation". <p>Contact your machine manufacturer or supplier for more information on machine parameters and the auxiliary function.</p>
Cycle	<p>Cycle 13 "Spindle orientation" can be used to program a specified angular spindle position. An auxiliary function, defined by the machine manufacturer, must be programmed before spindle positioning is possible (not with CYCL CALL).</p> <p>If spindle orientation is called via an auxiliary function, without having programmed a cycle definition, the TNC will align the main spindle according to a value defined in the machine parameters.</p>
Input data	<p>Orientation angle: angle relative to angular reference axis of machining plane. Input range: 0 ... 360° Input resolution: 0.5°</p>
Spindle position display	<p>The spindle position actual value can be displayed instead of the fourth axis. This depends on a machine parameter and is set by the machine manufacturer.</p>

Canned cycles

Spindle orientation

Definition

Operating mode _____



Dialog initiation _____



or



CYCLE DEF 13 ORIENTATION



Press ENT to select cycle.

ORIENTATION ANGLE ?



Specify required angular spindle position.



Press ENT.

Sample display

5 CYCL DEF 13.0 ORIENTATION

6 CYCL DEF 13.1 ANGLE 90.000



Cycle definition occupies 2 program blocks.


Editing a program

Editing

Editing is the term used to describe the process of checking, modifying or expanding a program. The editing functions help you to search for and modify program blocks and words. They are activated by pressing a key.

Calling a block

Call a specified block by pressing the  key.  is the symbol for program block.




Paging through a program



You can "page" through a program block-by-block with the  and  keys.


 skip to next lower block number


 skip to next higher block number



Editing words

Pressing the  and  keys moves the **cursor** around within the current block. The cursor is an "editing pointer" in the form of a highlighted field on your screen. Use the two cursor movement keys to place the cursor on the program word you want to edit.



The cursor can be moved only in  mode.

Cursor movement must be started with the

 key.



Editing a program



Calling a block

Calling a block number

Operating mode _____    

Dialog initiation _____ 

GOTO: NUMBER =   Specify block number.



  Press ENT.



Editing words



Operating mode _____ 




To edit a word in the current program block:   Place cursor on word to be edited.

The dialog prompt for the word appears highlighted, e.g.:

COORDINATES ?   Edit entry data.


When all corrections are complete:   Press END to enter block (or move cursor off-screen to right or left).

To edit an additional word:    Place cursor on word to be edited.


Editing a program

Deleting and inserting blocks

Deleting a block

The current block within a program is deleted by pressing the  key.

DEL is an abbreviation for **DE**lete, which means to erase or take out.

Program blocks can be deleted only in  mode.


When deleting individual blocks, make sure the block you want to delete is the currently active block. To be on the safe side, call up the block by number.

After the block is deleted, the block with the next block number takes the place of the deleted block.

The blocks are re-numbered automatically.



Cycle definition or program part deletion

To delete cycle definitions or program sections, call up the last block of the cycle definition or program section. Then press the  key until all blocks in the definition or program section have been deleted.


Inserting a block


You can insert new blocks at any point in an existing program by calling up the block **preceding** the block you wish to insert. The subsequent blocks will be re-numbered automatically.

If the storage capacity of the program memory is exceeded, the following error message will appear when the dialog is initiated:
= PROGRAM MEMORY EXCEEDED =
This error message is also generated if you attempt to insert a block after the END block (end-of-program is displayed on current line).

Editing while programming

Incorrect entries made while programming can be corrected in two ways.

 Entered data are erased and a highlighted "0" appears.

 Entered data are erased completely.

Editing a program

Deleting blocks

Deleting
a block

Operating mode _____ 



To delete the current program block:   Press to delete block.





Editing a program


Search routines

Erasing a program


Searching for specified addresses





Blocks containing specified addresses can be found within a machining program by using the  and  keys.

To search for an address, use the  and/or  keys to move the cursor to the word with the searched address and the  and/or  keys to page through the program. Only those blocks which contain the searched address will be displayed.

Search routines can be carried out only in  mode.

Erasing a program

Press  to initiate the dialog for erasing (clearing) a program.

After pressing this key, a program overview appears together with a highlighted pointer. Move the pointer with the     keys.

Only the program whose number is currently highlighted can be erased.



Editing a program



Search routines/Parameter display


Erasing a program

Searching for specified addresses

Operating mode 


To display all blocks with the address M:


 Select a block with searched address.

 Move cursor to word with searched address.

AUXILIARY FUNCTION M ?   Call blocks containing searched address.



Always initiate cursor movement with the  key.





Erasing a program


Operating mode 

Dialog initiation 


CLEAR = ENT/END = NO ENT

To erase a program:




 Move cursor to program number.

 Press ENT to erase program.


If erase is not desired or to terminate erase function:




Test run


Parameter display


Testing a program

You can have the control system check a program for geometrical errors without machine movement before actually running the program. During a test run, the TNC calculates program sequences just like during an actual program execution. The test run will be interrupted if an error message is generated. The mode select key  also initiates the interactive input dialogue.









Stopping a test run

Interrupt and abort the test run at any desired location by pressing the  key.



The test run is interrupted automatically after each programmed STOP. The test run must be restarted to continue (see next page).

Displaying Q parameters

In "Program run-single block"  or "Program run full sequence"  modes, you can display the current values of Q parameters and change them if desired. You have to interrupt the program run at the desired location to do this. Press the  key and enter the parameter number to display the value on the screen on the dialogue line. You can then change the displayed value if you wish (e.g. for test runs). The TNC will retain the set value until another one is programmed to replace it. You can page through the parameter list with the  and  keys. The display is cleared with the  key.

Test run

Parameter display

Starting a
program
test run

Operating mode _____ 

TO BLOCK NUMBER =

To run test up to a specified block number:



Enter block number.



Press ENT.

To test run entire program:



Displaying and
setting
Q parameters

Operating mode _____  

Dialog initiation _____ 

Q0 =



Specify parameter number.



Press ENT.

Q55 = 1112



Enter parameter value if required.



Press ENT.

After the program starts, the TNC operates with the displayed or modified parameter value until it is replaced in the program by another value.

Graphics

Blank form definition


Graphic simulation

The machining of a workpiece can be simulated graphically on the screen, to check the program without machine-slide movement before it is actually executed.

The workpiece blank is always of cuboid shape. Other workpiece shapes may be programmed separately if desired.



Machining operations can be simulated on the three main axes, with constant tool axis and a cylindrical end mill. Helical interpolation as well as interpolation on the 4th axis (e.g. C-axis) cannot be simulated.



Defining a blank

The blank workpiece has to be defined for graphic simulation:

- its **position relative to the coordinate system** and
- its **dimensions** must be programmed.

It is necessary to specify only **corner points** when defining the cuboid. These points are identified as minimum point P_{MIN} and maximum point P_{MAX} (points with "minimum" and "maximum" coordinates).


P_{MIN} can only be entered in absolute dimensions. P_{MAX} can be entered in either absolute or incremental dimensions.

The blank workpiece data are saved in a corresponding machining program and are available when the program is selected.

It is advisable to define the cuboid at the beginning or at the end of the program. This makes it easier to find the BLK FORM blocks when blank form dimensions change.

The interactive dialog is initiated by pressing **BLK FORM**.

The **maximum dimensions** of the blank may not exceed 14,000 x 14,000 x 14,000 mm.







Graphics





Cuboid corner points – BLANK FORM

Entering corner points

Operating mode _____ 
 Dialog initiation _____ 

SPINDLE AXIS PARALLEL X/Y/Z ?  **Z** Specify spindle axis, e.g. Z.

DEF BLK FORM: MIN-CORNER ?  Enter numerical value for X-coordinate.
 Press ENT.
 Enter numerical value for Y-coordinate.
 Press ENT.
 Enter numerical value for Z-coordinate.
 Press ENT.

DEF BLK FORM: MAX-CORNER ?  **I** Incremental – absolute?
 Enter numerical value for X-coordinate.
 Press ENT.
I Incremental – absolute?
 Enter numerical value for Y-coordinate.
 Press ENT.
I Incremental – absolute?
 Enter numerical value for Z-coordinate.
 Press ENT.

Sample display

1 BLK FORM 0.1 Z X+ 0.000
Y+ 0.000 Z-15.000
2 BLK FORM 0.2 X+80.000
Y+100.000 Z+ 0.000


The blank is parallel to the main axes.
 The coordinates of P_{MIN} are X 0.000, Y 0.000 and Z -15.000.
 The coordinates of P_{MAX} are X 80.000, Y 100.000 and Z 0.000.

Graphics

Display options


Graphics mode

A machining program can be simulated graphically in operating modes:

 PROGRAM RUN – FULL SEQUENCE

 PROGRAM RUN – SINGLE BLOCK

The machining program must be stored in the main memory before it can be displayed. To call up the menu of display options on the screen, press **MOD** twice. Use **↑** and **↓** to move the highlighted pointer to the desired display option and press **ENT** to select.




Display modes

Four different types of display are available.

3D simulation

The program is run in 3D simulation. Use the **→** and **←** keys to rotate the workpiece about its vertical axis and the **↑** and **↓** keys to tilt it about the horizontal axis. The position of the coordinate system (machining plane) is indicated by an angle displayed at the upper left of the display.





Simulation in three planes

The program is run in plan view and two cross-sections, similar to a workpiece drawing. The sectional planes can be shifted by pressing the **→**, **←**, **↑**, **↓** keys.

The simulation in three planes can be switched from the standard German DIN display to the American standard third angle projection via machine parameters. Symbols conforming to the DIN 6 standard indicate the type of display:

DIN standard 

U.S. standard 



Graphics

Display options

Plan view 1

The program is simulated in a plan view with **five levels of depth shading**, the deeper the level, the darker the shading.




Plan view 2

Same as plan view 1, but features **17 levels of depth shading**. Image resolution on the other two axes is not as good.



Fast image generation

The finished workpiece can be displayed on the screen with the **fast image data processing** feature. The TNC "develops" the workpiece as configured in the machining program, without graphically simulating individual production steps. Only the current block number is displayed on the screen.



Graphics Operation

Starting graphic simulation



After selecting the desired graphics mode, start the program run by pressing **START**.

A TOOL CALL, defining the tool axis, must be programmed prior to the initial axis movement. Specifying the spindle axis during BLK FORM definition is not sufficient for running a program in graphics mode. If the tool axis is missing, the error message = PGM SECTION CANNOT BE SHOWN = appears after the graphics feature is started. This error message is also displayed if a fourth or fifth axis or helical interpolation was programmed.



Stopping graphic simulation

You can interrupt the graphic simulation at any time by pressing **STOP**. The current block will be completed.



Resetting the blank form



After interrupting the graphic simulation, reset the display to the blank workpiece (original cuboid shape) by pressing **BLK FORM**.

To restart the simulated machining of the workpiece, first return to the beginning of the program by pressing **GOTO**.






Graphics


Starting graphics mode

Starting graphics mode


Operating mode  or 


Select desired program.





Select graphics mode.








Call up graphics menu.







Move cursor to desired display option, e.g. "3D simulation".



Start graphic simulation.





Notes:



A series of horizontal lines for writing, consisting of solid top and bottom lines with a dashed midline. The lines are arranged in approximately 20 rows across the page, providing a guide for handwriting practice.

Graphics


Starting graphics mode

Graphics:
stop/start


To interrupt graphic simulation:



To restart graphic simulation:



Notes:




Graphics

Simulation in three planes

Shifting planes

Interrupt graphic simulation.



To shift horizontal sectional plane, e.g. up:


Press repeatedly (jog mode)



or continually shift sectional plane.



Press repeatedly to shift plane faster.



To stop shifting plane:



To shift vertical plane, e.g. to right:

Press repeatedly




or continually shift sectional plane.



Press repeatedly to shift plane faster.



To stop shifting plane:




Graphics

Simulation in three planes



Restart graphic simulation.


▶ **START** ▶

A screenshot of a 3D simulation interface. The main area is a light gray floor plan with yellow lines representing walls and furniture. There are several orange markers or icons scattered across the plan, possibly indicating specific points of interest or simulation parameters. The interface is contained within a rounded rectangular frame.

Graphics

3D simulation

Tilting and rotating



Graphics

Magnify

Magnify function



The magnify feature allows you to enlarge any desired detail of the workpiece.

The detail selected for magnification must be defined in the 3D graphics mode.

The simulation itself can be presented in all 4 modes.




Defining limits of workpiece detail

You can define the limits of the selected detail with a wireframe model of a cuboid that appears in the upper left corner of the screen when you press **MAGN**.

You can use the **→** key to move the hatched area one point at a time toward the centre of the

cuboid or, in conjunction with **ENT** to move it continuously. Press **STOP** to interrupt continuous movement.

Press **←** to move the area back toward the outer edge.



Defining next boundary surface

Press **↑** to select the next boundary (right-hand surface).

In this way, you can select and move the left-hand, right-hand, front, rear, top and bottom surfaces one at a time.

Press **↓** to return to the preceding surface.

Saving the detail


After the last boundary surface (top) has been defined, save the detail by pressing **↑** and then **ENT**. The blank is displayed on the screen in enlarged form. For a magnified detail of the actual contour, run a graphic simulation in any of the graphic display modes.

Graphics Magnify


Limiting and enlarging a detail

The control system is in 3D graphic display mode.

Select MAGN function.




To move left-hand boundary surface, e.g. to right:

Press  repeatedly (jog mode)



or continually shift boundary surface.


Press  repeatedly to shift boundary surface faster.




To stop shifting surface and save:



Select next boundary surface (right).



Move this and remaining surfaces as described above.



Graphics Magnify

When the final (top) surface has been moved:



TRANSFER GRAPHICS DETAIL



Start program run.



The workpiece machining operation is simulated. Only the defined detail is displayed on the screen.




Notes:




Program run


Operating modes


Program run – full sequence

In the operating mode  "Program run – full sequence", the TNC executes the program stored in memory up to a programmed stop or until the end of the program. After a programmed stop, the program run must be restarted to continue. The program run also stops automatically when an error message is displayed.




Program run – single block

In the operating mode  "Program run – single block", the TNC executes the program stored in memory block-by-block. The program must be restarted after each block is executed.



Feed rate

The programmed feed rate can be modified via the **internal feed rate override**, depending on how the control system was installed on the machine by the machine manufacturer.



Spindle speed

In the case of analogue output, the spindle speed can be modified via the **spindle override**.

Program run

Starting a program run



The workpiece datum must be set before machining the first workpiece.

Starting program run – single block

Operating mode _____ 

First program block displayed on current program line.



Run first program block.

Second program block displayed on current program line.



Run second program block.

⋮

Starting program run – full sequence

Operating mode _____ 

First program block displayed on current program line.





Run program.


The TNC executes the program continually, until it reaches a programmed stop or until the end of the program.

Program run

Interrupting and aborting a program run

Interrupt program run

While the TNC is in  (Program run – full sequence) or  (Program run – single block) modes, you can interrupt program execution at any time by pressing the external stop button. An interruption is indicated on the screen by a flashing * symbol (“*” means control system in operation).





Abort program run



Program execution must be interrupted and aborted before switching to another operating mode (except when running a program with background programming). To interrupt and abort a program run, press the external stop button and the stop button on the TNC. When a run is aborted, the * symbol will disappear from the screen.


After aborting a program run, the TNC saves the following data:

- the **tool** that was activated last,
- **coordinate transformations** (datum, mirror-image, coordinate system rotation, scaling factor),
- the last programmed **circle center/pole CC**,
- the last defined **canned cycle**,
- the current status of **program part repetitions**,
- the return jump address for **subroutines**.



If a program run is aborted during a **sub-routine** or a **program part repeat** sequence and a block is then selected with , the counter for the program part repeat is reset to the programmed number of repetitions. In the case of subroutines, the return jump address is erased.

To maintain the remaining number of repeats and/or the return jump address, use the   keys to select program blocks.



Program run

Interrupting and aborting a program run

Interrupting program execution

Operating mode _____  or 

To interrupt a running program:



Interrupt program run.

The "*" symbol (TNC in operation) flashes.

Aborting program execution

Operating mode _____  or 

To abort program execution:





Interrupt program run.



Abort program run.

The "*" symbol (TNC in operation) disappears.



When running a program in ISO format, the  key performs the function of the internal  key.

Notes:




Paraxial machining

Programming via axis address keys

Dialog initiation


The entry of paraxial positioning blocks can be somewhat simplified:
Like the combined point-to-point and straight-cut control models TNC 131/TNC 135, the input dialogue is initiated directly using the axis address keys **X** **Y** **Z** **IV**.



Nominal position value

Enter the coordinate for the appropriate axis as the **nominal position**. The numerical value can be entered in absolute (based on workpiece datum) or incremental (based on previous nominal position) dimensions.

In either case, the tool will move from its current actual position, parallel to the selected axis, to the programmed target position




Radius compensation

When programming via axis address keys, tool radius compensation has the following significance:

- To **decrease** distance traversed by the tool radius: press **R-**, screen displays R-.
- To **increase** distance traversed by the tool radius: press **R+**, screen displays R+.
- The tool moves to the programmed nominal position, screen displays R0.

If a radius compensation R+/R- is also programmed when positioning the **spindle axis**, no **compensation** will be active on this axis.

When the **4th axis** is used as a **rotary table axis**, no radius compensation will be taken into account.



Paraxial machining

Programming via axis address keys



Do not enter paraxial positioning blocks containing a radius compensation R+/R- before or after positioning blocks containing a radius compensation RR/RL.



WRONG

```
16 L X+15,000 Y+20,000  
    RR F M03
```

```
17 Y+40,000  
    R- F100 M
```

```
18 L X+50,000 Y+57,000  
    RR F M
```

Within a program, paraxial positioning blocks entered via an axis address key can be inserted between positioning blocks containing R0 (no radius compensation) that were programmed via a contouring function key

CORRECT

```
18 L X+15,000 Y+20,000  
    R0 F M
```

```
19 L X+10,000 Y+10,000  
    R0 F M
```






```
20 X+40,000  
    R+ F M
```



```
21 L X+50,000 Y+20,000  
    R0 F M
```

Paraxial machining


Programming via axis address keys


Entering
paraxial straight
lines

Operating mode  _____
 Dialog initiation  or  or  or  _____

POSITION VALUE ? ▶  Incremental - absolute?
 ▶ Enter numerical value for selected axis.
 ▶  Press ENT.

TOOL RADIUS COMP.: R+/R-/NO COMP. ? ▶   Specify radius compensation if required.

FEED RATE ? F = ▶ Specify feed rate if required.
 ▶  Press ENT.

AUXILIARY FUNCTION M ? ▶ Specify auxiliary function if required.
 ▶  Press ENT.

Sample display

119 IX+46.000
 R+ F60 M03


In block 119, the tool moves parallel to the X-axis by +46.000 plus the tool radius. The feed rate is 60 mm/min., spindle rotation is clockwise.

Paraxial machining Playback programming

Playback



If the tool has been moved in manual mode (via handwheel or axis address key), the actual position of the tool can be transferred to the machining program as a nominal position. This method of entering data is called "playback" programming.


Playback programming is only practical for paraxial machining operations. Programming complex contours with this technique is not recommended.



Procedure

Move the tool manually, via handwheel or axis address key, to the required position.


In  mode, within a positioning block, the actual value of the position is transferred as a nominal position value, by pressing the  key.



Radius compensation

The actual position value already contains the length and radius compensation data for the tool currently in use. For this reason, enter the compensation values $L = 0$ and $R = 0$ when defining this tool.

When programming positioning blocks in playback mode, enter the correct tool radius compensation $R+$ or $R-$. If a tool breaks or the original tool is replaced by another one, the new compensation values can then be taken into account.



Paraxial machining Playback programming

Tool compensation

The new compensation values are determined according to the following formula:


$$R = R_{NEW} - R_{OLD}$$

R radius compensation value for TOOL DEF

R_{NEW} radius of new tool


R_{OLD} radius of original tool.

The new compensation values are entered during tool definition of the original tool (R = 0, L = 0). The compensation value R may be **positive or negative**, depending on whether the radius of the new tool is larger (+) or smaller (-) than the radius of the original tool.



Length compensation

The compensation value for the new tool length is determined in the same way as for TOOL DEF. In this case, the zero tool is the one originally used.





Notes:




Paraxial machining Playback programming

Input
example

Operating mode _____ 
Dialog initiation _____  or  or  or 




Program input can be terminated prematurely
by pressing .

Paraxial machining


Positioning with MDI

Positioning


In  mode "Positioning with MDI", **paraxial** positioning blocks can be entered and executed (without saving). Each block must be run immediately after being entered by pressing the external start button.




If the positioning block contains data in incremental dimensions, the block can be run as often as required by pressing the external start button.



Tool call

If a tool definition TOOL DEF has been saved in the TNC's memory, a tool can be called via TOOL CALL in  mode. This also activates the new tool compensation values. The tool is called by pressing the external start button.




Feed rate

The programmed feed rate can be modified via the **internal feed rate override** on the machine, depending on how the control system was installed on the machine by the machine manufacturer.

Spindle speed






In the case of analogue output, the spindle speed can be modified via the **spindle override**.





Paraxial machining

Positioning with MDI

Input example:
position data

Operating mode  _____
Dialog initiation  or  or  or  _____



Program input can be terminated prematurely by pressing .

Notes:





Paraxial machining


Positioning with MDI

Input example:
tool call

Operating mode _____ 

Dialog initiation _____ 



If a central tool memory is not available, **the program with the corresponding tool definition** must be called in  mode.


Machine parameters

Machine parameters

To enable the machine to carry out the commands issued by the control system, the TNC must "know" specific machine data, e.g. traverse paths, acceleration data etc. These data are defined by the machine manufacturer via so-called machine parameters.

User parameters


You can access certain machine parameters easily while in **MOD** operating mode, e.g. switching from HEIDENHAIN plain-language programming to standard ISO format. The user parameters available via the **MOD** mode are defined by the machine manufacturer, who can also provide further details on this subject.



Programming

The machine parameters must be programmed in the control system during initial commissioning. This can be done via an external data medium (e.g. ME cassette or FE disk containing stored machine parameters) or manually from the keyboard.

The machine parameters must be re-entered following an **interruption of power with discharged or missing buffer batteries**. The control system prompts you for the data in interactive dialog.




Changing buffer batteries

The buffer battery is the power source for the machine parameter memory and for the TNC's program memory. It is located beneath the cover on the front panel of the control unit.

When the message = EXCHANGE BUFFER BATTERY = is displayed, it's time to replace the battery.

The batteries are located behind a screw cover in the power supply unit of the LE 355. The TNC 355 is equipped with additional rechargeable buffer batteries that are located on the PLC board. The mains voltage can be switched off to exchange batteries. The rechargeable batteries retain the memory contents without batteries for about 2 weeks. The rechargeable batteries are only charged when the mains voltage is on.





Battery type

Mignon cells, leak-proof
IEC designation: "LRG"



Recommended: VARTA type 4006

Machine parameters

Input from
external
data medium




For data input from magnetic tape:




Machine parameters

For data input from disk:



When all parameters have been entered:




After traversing the reference points, the control system is ready for operation.

Machine parameters

Manual input

Switch on power.



MEMORY TEST

The control system checks the internal electronic controllers. Display is cleared automatically.

EXCHANGE BUFFER BATTERY

Insert new battery.



Clear message.

OPERATING PARAMETERS ERASED



Clear error message

MACHINE PARAMETER PROGRAMMING

MACHINE PARAMETER MP 0 ?

MP 0: 0



Enter machine parameter MP 0 from table.



Press ENT.

After each machine parameter is entered, the screen display advances automatically to the next parameter. Press  after entering each parameter.

When all parameters have been entered:

POWER INTERRUPTED



Clear message.

NC: PROGRAM MEMORY ERASED



Clear message.

RELAY EXT. DC VOLTAGE MISSING



Switch on control voltage.

After traversing the reference points, the control system is ready for operation.

Machine parameters

Machine parameter number	Input value	Machine parameter number	Input value	Machine parameter number	Input value
MP 00					
MP 01		MP 51		MP 101	
MP 02		MP 52		MP 102	
MP 03		MP 53		MP 103	
MP 04		MP 54		MP 104	
MP 05		MP 55		MP 105	
MP 06		MP 56		MP 106	
MP 07		MP 57		MP 107	
MP 08		MP 58		MP 108	
MP 09		MP 59		MP 109	
MP 10		MP 60		MP 110	
MP 11		MP 61		MP 111	
MP 12		MP 62		MP 112	
MP 13		MP 63		MP 113	
MP 14		MP 64		MP 114	
MP 15		MP 65		MP 115	
MP 16		MP 66		MP 116	
MP 17		MP 67		MP 117	
MP 18		MP 68		MP 118	
MP 19		MP 69		MP 119	
MP 20		MP 70		MP 120	
MP 21		MP 71		MP 121	
MP 22		MP 72		MP 122	
MP 23		MP 73		MP 123	
MP 24		MP 74		MP 124	
MP 25		MP 75		MP 125	
MP 26		MP 76		MP 126	
MP 27		MP 77		MP 127	
MP 28		MP 78		MP 128	
MP 29		MP 79		MP 129	
MP 30		MP 80		MP 130	
MP 31		MP 81		MP 131	
MP 32		MP 82		MP 132	
MP 33		MP 83		MP 133	
MP 34		MP 84		MP 134	
MP 35		MP 85		MP 135	
MP 36		MP 86		MP 136	
MP 37		MP 87		MP 137	
MP 38		MP 88		MP 138	
MP 39		MP 89		MP 139	
MP 40		MP 90		MP 140	
MP 41		MP 91		MP 141	
MP 42		MP 92		MP 142	
MP 43		MP 93		MP 143	
MP 44		MP 94		MP 144	
MP 45		MP 95		MP 145	
MP 46		MP 96		MP 146	
MP 47		MP 97		MP 147	
MP 48		MP 98		MP 148	
MP 49		MP 99		MP 149	
MP 50		MP 100		MP 150	

Machine parameters

Machine parameter number	Input value	Machine parameter number	Input value	Machine parameter number	Input value
MP 151		MP 201		MP 251	
MP 152		MP 202		MP 252	
MP 153		MP 203		MP 253	
MP 154		MP 204		MP 254	
MP 155		MP 205		MP 255	
MP 156		MP 206		MP 256	
MP 157		MP 207		MP 257	
MP 158		MP 208		MP 258	
MP 159		MP 209		MP 259	
MP 160		MP 210		MP 260	
MP 161		MP 211		MP 261	
MP 162		MP 212		MP 262	
MP 163		MP 213		MP 263	
MP 164		MP 214		as of software-version 05:	
MP 165		MP 215		MP 264	
MP 166		MP 216		MP 265	
MP 167		MP 217		MP 266	
MP 168		MP 218		MP 267	
MP 169		MP 219		MP 268	
MP 170		MP 220		MP 269	
MP 171		MP 221		MP 270	
MP 172		MP 222		MP 271	
MP 173		MP 223		MP 272	
MP 174		MP 224		MP 273	
MP 175		MP 225		MP 274	
MP 176		MP 226		MP 275	
MP 177		MP 227		MP 276	
MP 178		MP 228		MP 277	
MP 179		MP 229		MP 278	
MP 180		MP 230		MP 279	
MP 181		MP 231		MP 280	
MP 182		MP 232		MP 281	
MP 183		MP 233		MP 282	
MP 184		MP 234		MP 283	
MP 185		MP 235		MP 284	
MP 186		MP 236		MP 285	
MP 187		MP 237		MP 286	
MP 188		MP 238		MP 287	
MP 189		MP 239		MP 288	
MP 190		MP 240		MP 289	
MP 191		MP 241		MP 290	
MP 192		MP 242		MP 291	
MP 193		MP 243		MP 292	
MP 194		MP 244		MP 293	
MP 195		MP 245		MP 294	
MP 196		MP 246		MP 295	
MP 197		MP 247		MP 296	
MP 198		MP 248		MP 297	
MP 199		MP 249		MP 298	
MP 200		MP 250		MP 299	

Machine parameters

Machine parameter number	Input value
MP 300	
MP 301	
MP 302	
MP 303	
MP 304	
MP 305	
MP 306	
MP 307	
MP 308	
MP 309	
MP 310	
MP 311	
MP 312	
MP 313	
MP 314	
MP 315	
MP 316	
MP 317	
MP 318	
MP 319	

} at present without function

Additionally on TNC with 5th axis

MP 320	
MP 321	
MP 322	
MP 323	
MP 324	
MP 325	
MP 326	
MP 327	
MP 328	
MP 329	
MP 330	
MP 331	
MP 332	
MP 333	
MP 334	
MP 335	
MP 336	
MP 337	

General information	Introduction	D1
	Changing programming modes	D2
	Control system operation	D4
Program entry	Program management	D5
	G-functions	D6
	Dimensions	D8
	Erase/edit protection	D8
	Tool definition/Tool call	D9
	Dimensions	D10
	Straight lines	D12
	Circles	D14
	Helix	D18
	Tool path compensation	D19
	Chamfers/Rounding corners	D20
	Contour approach and departure	D21
	Canned cycles	D22
	· Machining cycles	D23
	· Coordinate conversions	D30
	· Other cycles	D31
	Subroutine and program part repetition	D34
	Program jump	D35
	Parameter programming	D36
	Graphics: Defining the workpiece blank dimensions	D38

Programming in ISO format

Introduction


Snap-on keyboard



With the TNC 151/TNC 155 you can enter programs either in HEIDENHAIN format, featuring operator prompting in plain-language interactive dialog, or in standard ISO 6983 format. Programming in ISO format can be an advantage when creating programs with external computer systems.

A snap-on overlay keyboard, with standard address keys, is available for ISO programming on the control unit. The keyboard is simply placed over the control unit keyboard and held in place magnetically.

The internal **STOP** key is assigned to the **D** key; for ISO programming, the **DEL** key performs the function of the internal **STOP** key.



Program input

The key assignment of the overlay keyboard is functional after **switching** from HEIDENHAIN plain-language dialog prompting to standard programming.

Program input in ISO format is dialog-prompted to some extent. Individual commands (words) can be entered into a block in any sequence. The control system sorts the programmed commands automatically when a block is complete and displays any errors made while programming or executing the program with plain-language error messages.

Block format: positioning blocks

Positioning blocks may include:

- 8 **G-codes** (preparatory functions) of various groups (see "G-codes") plus an additional G90 or G91 for each coordinate;
- 3 **coordinates** (from X, Y, Z, IV) plus two circle centre/pole coordinates (from I, J, K);
- 1 **feed rate** F (max. 5 digits);
- 1 **auxiliary function** M;
- 1 **spindle speed** S (max. 4 digits);
- 1 **tool number** of various groups (see "G-codes") (max. 3 digits).

Block format: canned cycles

Blocks with canned cycles may include:

- all **individual data** for the cycle (cycle parameter P);
- 1 **auxiliary function** M;
- 1 **spindle speed** S;
- 1 **tool number** of various groups (see "G-codes") (Tool call);
- 1 **positioning block**;
- 1 **feed rate** F;
- **cycle call**.

Error messages

The TNC displays block format errors while the block is being entered, e. g.
 = G-CODE GROUP ALREADY ASSIGNED =
 or after block entry is complete, e. g.
 = BLOCK FORMAT INCORRECT =

Programming in ISO format

Changing programming modes

External programming

Changing from HEIDENHAIN to ISO programming

The changeover from HEIDENHAIN to ISO programming format is made via a machine parameter. This parameter can be modified by means of the MOD function "User parameters". User parameters are defined by the machine manufacturer, who can also provide you with further information.

Remarks on external programming

- At program start, CR LF or LF or CR FF or FF must be programmed before the % sign and after each program block.
- After program end CR LF or LF or CR FF or FF and additionally ETX (control C) must be programmed. A replacement sign for ETX can be set via machine parameter (see interface description TNC 355).
- Empty spaces between the individual words are not necessary.
- Zeros after the period are not necessary.
- When entering DIN blocks the "*" sign is not necessary at the end of the block.
- The "*" sign is not issued by the control during output of DIN blocks.
- During entre of NC programs, commentaries that are marked with the "*" or ";" signs are ignored.

Programming in ISO format

Changing programming modes

Operating mode _____ any

Dialog initiation _____ **MOD**

VACANT BLOCKS: 1638 ▶ **MDD** **↑** Select MOD function "User parameters".

USER PARAMETERS ▶ **ENT**
↓ **↑** Select desired user parameter.

Dialog defined by machine manufacturer:

Program input in HEIDENHAIN format: ▶ **0**
 or ▶ **DEL** Exit supplementary mode.

Program input in ISO format: ▶ **1**
 ▶ **DEL** Exit supplementary mode

POWER INTERRUPTED ▶ **CE** Clear error message.

RELAY EXT. DC VOLTAGE MISSING ▶ **I** Switch on control voltage.

After traversing the reference points, the control system is ready for operation.

After switching programming modes, plain-language programs are automatically converted to ISO format and vice versa.



Please note the following when switching from ISO format to plain-language format:

- Modal functions (e.g. G01) are converted to the plain-language symbol (e.g. L) only in the block in which the function was programmed. The symbol * then appears in subsequent blocks written in plain-language format.
- K stands for Cartesian coordinates.
- P stands for polar coordinates.
- F MAX signifies rapid traverse.

Programming in ISO format


Control system operation

Entering single commands


Single commands consist of an **address** and **additional data**.

To enter a single command, first press the alpha address key and then enter the additional data from the numeric keypad.






Conclude the entry for the single command by pressing the alpha address key to enter the next command.



To conclude the block, press .



SINGLE COMMAND:







Editing


You can make changes to a program immediately while entering the block or later after program input is complete. The      keys are provided for this purpose (see "Editing").


In contrast to HEIDENHAIN plain-language format, you can move the cursor in ISO format with the  and  keys.


When the **highlighted pointer** is located on a single command within a block, you can start a search routine by pressing the   keys.


When you are finished editing, use the  key to move the highlighted pointer beyond the beginning of the block, the  key to move it beyond the end of the block, or press .


Press  to delete incorrectly entered **additional data**.




A zero, which can be overwritten, will appear in the pointer when you press .

Delete incorrectly entered **address letters** or **entire single commands** by pressing .



To do this, the highlighted pointer must be located over the command you wish to delete. If no pointer is visible in the current block, pressing  will cause the entire block to be deleted!




Programming in ISO format

Program management

Program management


The TNC's memory can accommodate up to **32 programs** with a total of **3,100 program blocks**. A program may contain up to 1,000 blocks. You can create a new program or call up an existing one by pressing **PGM NR** (see "Program call").

The number of characters (bytes) contained in the program is indicated after the program number in the program library, e.g. 400/2592.



Block number

The block number consists of the **address N** and the actual block number. It can be entered **manually** via the **N** key or set **automatically** by the control system. The interval between individual block numbers is defined with the MOD function "Block number increment". The TNC executes the program in the sequence in which the blocks were entered. The block number itself has no effect on the sequence in which the program is executed. When **editing a program**, blocks with any block number may be inserted between two existing program blocks.



Programming in ISO format

G-codes

Categories

G-codes, also known as preparatory functions, mainly represent path characteristics for tool movement. They consist of the **address G** and a two-digit code number. The G-codes are subdivided into the following groups:

G-codes for positioning

Target position in Cartesian coordinates:

G00 – G07

Target position in polar coordinates: G10 – G16

G-codes for cycles

Machining cycles:

Drilling cycles G83 – G84

Milling cycles G37/G56 – G59/G74 – G78

Cycle call G79

Cycles for coordinate transformations:

Cycles G28/G54/G72/G73

Dwell time cycle: G04

Spindle orientation cycle: G36

Freely programmable (variable) cycle:

(Program call) G39

G-codes for selecting machining plane

G17 Plane selection XY, tool axis Z,
angular reference axis X

G18 Plane selection ZX, tool axis Y,
angular reference axis Z

G19 Plane selection YZ, tool axis X,
angular reference axis Y

G20 Tool axis IV

G-codes for milling and rounding corners and tangential contour approach


G24 – G27

G-codes for path compensation

G40 – G44

Miscellaneous G-codes

G29	Transfer of last nominal position value as pole
G30	Blank form definition for graphics, min. point
G31	Blank form definition for graphics, max. point
G38	Corresponds to STOP block in HEIDENHAIN format
G50	Erase/edit protection (at beginning of program)
G51	Next tool number when central tool memory is used
G55	Touch-probe function, workpiece surface as reference plane
G70	Dimensions in inches (at beginning of program)
G71	Dimensions in millimetres (at beginning of program)
G90	Absolute dimensions
G91	Incremental dimensions
G98	Set label number
G99	Tool definition



Programming in ISO format

G-codes

Entering G-codes

All the G-codes in a program block must be from different groups, e.g.:

```
N101 G01 G90 ... G41.
```

Multiple G-codes programmed from the same group would contradict each other, e.g.:

```
N105 G02 G03 ...
```

The TNC indicates this situation during program input by generating the error message
= G-CODE GROUP ALREADY ASSIGNED =

If a code number that is unrecognized by the control system is assigned to the address G, the error message
= ILLEGAL G-CODE =
is displayed.



The initial positioning block must include one G-code from each of the following groups:

G17, G18, G19, G20
G00, G01, G02, G03, G06 etc.
G40, G41, G42, G43, G44
G90, G91

There is **no standard default value!**

Programming in ISO format


Dimensions in inch/mm

Erase/edit protection

Dimensions in inch/mm

G70 Dimensions in inch (dialog-prompted)

G71 Dimensions in mm (dialog-prompted)

After dialog initiation via  and response to the prompt

PROGRAM NUMBER

the following dialog prompt appears:

MM = G71/INCH = G70

Respond to the prompt by entering G71 or G70.



Block format (example)

```
% 2 G71
```

% Beginning of program
2 Program number
G71 Dimensions in mm

Erase/edit protection

G50 Erase/edit protection (dialog-prompted)

If the   keys are used in the initial program block (e.g. %2 G71), after program input is complete, to select the dialog prompt

PGM PROTECTION ?

the program can be safeguarded from being erased or altered by entering G50.

Block format (example)

```
% 2 G71 G50
```

% Beginning of program
2 Program number
G71 Dimensions in mm
G50 Erase/edit protection.

The erase/edit protection is cancelled by entering the code number 86357.

Please see "Erase/edit protection" for explanation.

Programming in ISO format

Tool definition/Tool call

Tool definition

G99 Tool definition (dialog-prompted)


Block format (example)

G99 T1 L+0 R+20

G99 Tool definition
 T... Tool number
 L... Tool length compensation
 R... Tool radius compensation

Please see "Tool definition" for explanation.

Tool definition occupies one program block.



Tool call

T Tool call


The machining plane (G17/G18/G19/G20) and the spindle speed S must be defined in addition to the tool call. Because G17/G18/G19/G20 automatically terminates path compensation, it should not be programmed within a contour.

Block format (example)

T1 G17 S1000

T... Tool call + tool number
 G17 Selection of plane XY, tool axis Z
 S... Spindle speed

Please see "Tool definition" for explanation.



Next tool

G51 Next tool when central tool storage is used.

Block format (example)


G51 T1

G51 Next tool
 T... Tool number

Programming in ISO format Dimensions

Cartesian coordinates

Cartesian coordinates are programmed via the **X** **Y** **Z** **I** keys. Up to 3 target point coordinates can be specified for linear interpolation and up to 2 point target coordinates for circular interpolation.




Incremental/absolute dimensions

The G-code G90 "Absolute dimensions" and G91 "Incremental dimensions" are **modal** commands, i.e. each remains in effect until cancelled by the other G-code (G91 or G90).

To specify **coordinates in absolute dimensions**, the G-code **G90 – Absolute dimensions** must be entered before the coordinate or already be active.


To specify **coordinates in incremental dimensions**, the G-code **G91 – Incremental dimensions** must be entered before the coordinate or already be active.



G90 or G91 must be programmed before the first coordinate at the beginning of the machining program. Otherwise, this error message is displayed:
= PROGRAM START UNDEFINED =

Polar coordinates

Polar coordinates are programmed via the **H** key (polar coordinate angle H) and the **R** key (polar coordinate radius R). The pole must be defined before entering the polar coordinates.



Programming in ISO format

Dimensions

Pole/circle centre


The pole/circle centre is always defined by two Cartesian coordinates. The axis designations for these coordinates are:

- I for the X-axis
- J for the Y-axis
- K for the Z-axis

The pole/circle centre must be located in the appropriate machining plane:

Machining plane	Coordinates of pole/circle centre
X, Y plane	I, J
Y, Z plane	J, K
Z, Y plane	K, I

Use the **I** **J** **K** keys to enter the coordinates.




Pole definition G29

To transfer the last nominal position value as a pole, simply enter the code G29.

Example:

```
N30 G01 G90 X+30 Y+50
```

```
N40 G29 G11 R+50 H-45
```



Programming in ISO format

Linear interpolation

Target position
in Cartesian
coordinates


G00 Linear interpolation, Cartesian, in rapid traverse.

Block format (example)

G00 G90 X+80 Y+50 Z+10

G00 Linear interpolation, Cartesian, in rapid traverse
 G90 Absolute dimensions
 X... X-coordinate of target position
 Y... Y-coordinate of target position
 Z... Z-coordinate of target position

Simultaneous movement of three machine axes in a straight line is not available on the export versions of the TNC 355 (see inside front cover).




G01 Linear interpolation, Cartesian.

Block format (example)

G01 G90 X+80 Y+50 Z+10 F150

G01 Linear interpolation, Cartesian
 G90 Absolute dimensions
 X... X-coordinate of target position
 Y... Y-coordinate of target position
 Z... Z-coordinate of target position
 F... Feed rate



Paraxial
positioning

G07 Traverse in paraxial straight line.


Block format (example)

G07 G90 X+40 F190

G07 Paraxial positioning block
 G90 Absolute dimensions
 X... Coordinate of target position
 F... Feed rate

G07 is active only in the block in which it is programmed (non-modal).

Beginning with software version 10:
 In the "Positioning with manual data input"
 operating mode G07 is set automatically.



Programming in ISO format

Linear Interpolation


Target position
in polar
coordinates

G10 Linear interpolation, polar, in rapid traverse.

Block format (example)

G90 I+20 J+10 G10 R+30 H+45

G90 Absolute dimensions
 I ... X-coordinate of pole
 J ... Y-coordinate of pole
 G10 Linear interpolation, polar, in rapid traverse
 R ... Polar coordinate radius to end position
 H ... Polar coordinate angle to end position




G11 Linear interpolation, polar.

Block format (example)

G91 I+10 J-30 G11 G90 R+30 H+45 F150

G91 Incremental dimensions
 I ... X-coordinate of pole
 J ... Y-coordinate of pole
 G11 Linear interpolation, polar
 G90 Absolute dimensions
 R ... Polar coordinate radius to end position
 H ... Polar coordinate angle to end position
 F ... Feed rate



Programming in ISO format

Circular interpolation

Target position
in Cartesian
coordinates


G02 Circular interpolation, Cartesian,
clockwise, defined via **centre point**
and **target position**.

Block format (example)

Preceding block: Approach to starting point of
arc

G90 I+30 J+30 G02 X+69 Y+23 F150

G90 Absolute dimensions
I ... X-coordinate of circle center
J ... Y-coordinate of circle center
G02 Circular interpolation, Cartesian,
clockwise
X ... X-coordinate of target position
Y ... Y-coordinate of target position
F ... Feed rate




G03 Circular interpolation, Cartesian,
counterclockwise, defined by
center point and **end position**.

Block format (example)

Preceding block: Approach to starting point of
arc

G90 I+30 J+28 G03 X+12 Y+32 F150

G90 Absolute dimensions
I ... X-coordinate of circle center
J ... Y-coordinate of circle center
G03 Circular interpolation, Cartesian,
counterclockwise
X ... X-coordinate of target position
Y ... Y-coordinate of target position
F ... Feed rate




G05 Circular interpolation, Cartesian,
no specified rotation direction,
defined by **centre point** and **end**
position.

Block format (example)

Preceding block: Approach to starting point of
arc

G90 I+22 J+20 G05 X+5 Y+30 F150

G90 Absolute dimensions
I ... X-coordinate of circle center
J ... Y-coordinate of circle center
G05 Circular interpolation, Cartesian,
no specified rotation
X ... X-coordinate of target position
Y ... Y-coordinate of target position
F ... Feed rate



If circular interpolation with specified rotation
has not already been executed before circular
interpolation with G05/G15, this message
will appear:
= PROGRAM START UNDEFINED =



Programming in ISO format

Circular interpolation

Target position
in Cartesian
coordinates


G02 Circular interpolation, Cartesian,
clockwise, defined by radius and
end position.

Block format (example)

Preceding block: Approach to starting point of
arc

G02 G90 X+69 Y+23 R-20 F150

G02 Circular interpolation, Cartesian,
clockwise
G90 Absolute dimensions
X... X-coordinate of end position
Y... Y-coordinate of end position
R-... Circle radius, central angle greater than
180°
F... Feed rate




G03 Circular interpolation, Cartesian,
counterclockwise, defined by
radius and end position.

Block format (example)

Preceding block: Approach to starting point of
arc

G03 G90 X+12 Y+32 R+20 F150

G03 Circular interpolation, Cartesian,
counterclockwise
G90 Absolute dimensions
X... X-coordinate of end position
Y... Y-coordinate of end position
R+... Circle radius, central angle less than 180°
F... Feed rate




G05 Circular interpolation, Cartesian,
no specified rotation defined by
radius and end position.

Block format (example)

Preceding block: Approach to starting point of
arc

G05 G90 X+5 Y+30 R+20 F150

G05 Circular interpolation, Cartesian,
no specified rotation
G90 Absolute dimensions
X... X-coordinate of end position
Y... Y-coordinate of end position
R+... Circle radius, central angle less than 180°
F... Feed rate



Programming in ISO format

Circular interpolation

End position
in polar
coordinates


G12 Circular interpolation, polar,
clockwise.

Block format (example)

Preceding block: Approach to starting point of arc

G90 I+50 J+40 G12 H-45 F150

G90 Absolute dimensions
I ... X-coordinate of pole/circle center
J ... Y-coordinate of pole/circle center
G12 Circular interpolation, polar, clockwise
H ... Polar coordinate angle to end position
F ... Feed rate




G13 Circular interpolation, polar,
counterclockwise.

Block format (example)

Preceding block: Approach to starting point of arc

G90 I+30 J+25 G13 G91 H-180 F150

G90 Absolute dimensions
I ... X-coordinate of pole/circle center
J ... Y-coordinate of pole/circle center
G13 Circular interpolation, polar, counter-clockwise
G91 Incremental dimensions
H ... Polar coordinate angle to end position
F ... Feed rate




G15 Circular interpolation, polar,
no specified rotation
(also see function G05).

Block format (example)

Preceding block: Approach to starting point of arc

G90 I+50 J+40 G15 G91 H+120 F150

G90 Absolute dimensions
I ... X-coordinate of pole/circle center
J ... Y-coordinate of pole/circle center
G15 Circular interpolation, polar, no specified rotation
H ... Polar coordinate angle to end position
F ... Feed rate



Programming in ISO format

Circular interpolation

Tangential transition arc


End position
in Cartesian
coordinates

G06 Circular interpolation, Cartesian,
tangential transition to contour,
defined by end position.

Block format (example)

G06 G90 X+50 Y+10

G06 Circular interpolation, Cartesian,
tangential transition to contour
G90 Absolute dimensions
X ... X-coordinate of end position
Y ... Y-coordinate of end position




End position
in polar
coordinates

G16 Circular interpolation, polar,
tangential transition to contour,
defined by end position.

Block format (example)

G90 I+50 J+30 G16 R+15 H-60

G90 Absolute dimensions
I ... X-coordinate of pole
J ... Y-coordinate of pole
G16 Circular interpolation, polar,
tangential transition to contour
R ... Polar coordinate radius to end position
H ... Polar coordinate angle to end position



Programming in ISO format


Helical interpolation

Helical interpolation



Helical interpolation is the combination of a circular interpolation in the machining plane and superimposed linear motion on the tool axis. Please see "Helical interpolation" for further information.

Helical interpolation is not available on the export versions of TNC 355 (see inside front cover).




G12 ... Z Helical interpolation, clockwise.

G13 ... Z Helical interpolation, counterclockwise.

Block format (example)

G90 I+15 J+45 G12 G91 H+1080 Z-5

G90 Absolute dimensions
 I ... X-coordinate of pole/circle center
 J ... Y-coordinate of pole/circle center
 G12 Circular interpolation, polar, clockwise
 G91 Incremental dimensions
 H ... Polar coordinate angle = angle of rotation
 Z ... Height coordinate of helix




Programming in ISO format

Tool path compensation

Compensated tool path

Tool path compensation means that the tool moves to the left or right of the programmed contour, with the cutter axis offset by the amount of the **tool radius**, thus producing the actual programmed contour. A **transition arc K** is inserted into the tool path automatically on **outer corners**. On **inner corners** the TNC automatically calculates a **path intersection S** to prevent back-cutting on the contour.




Tool path compensation

Tool path compensation is programmed via G-codes, which are **modal commands**, i.e. they remain active until cancelled or replaced by another G-code.

You can enter a tool path compensation in any **positioning block**.


- G40** The tool moves precisely on the programmed contour. (Cancel path compensation with G41/G42/G43/G44).
- G41** The tool moves on a path to the **left** of the contour.
- G42** The tool moves on a path to the **right** of the contour.



Tool radius compensation with paraxial positioning blocks

In the case of paraxial positioning blocks, the tool path can be shortened or extended by the amount of the tool radius.

- G43** Tool path is extended
- G44** Tool path is shortened



Programming in ISO format

Chamfers/Rounding corners

Chamfers

G24 Chamfers

Program format


N25 G01 X ... Y ... (position P1)

N26 G24 R ... (chamfer)

N27 X ... Y ... (position P2)

The function G24 can also be programmed in the positioning block for the corner P1 to be chamfered.

Please see "Chamfers" for further explanation.



Rounding corners

G25 Rounding corners

Program format


N15 G01 X ... Y ... (position P1)

N16 G25 R ... (corner radius)

N17 X ... Y ... (position P2)

The function G25 can also be programmed in the positioning block for the corner P1 to be rounded.

Please see "Rounding corners" for further explanation.



A positioning block with both coordinates of the machining plane must be programmed before and after the rounding corners/ chamfer function.

Programming in ISO format

Tangential contour approach and departure

Tangential contour approach

G26 Contour approach on an arc with tangential transition to first contour element (dialog-prompted).


Program format

N25 G40 G01 X ... Y ... (position PS)

N26 G41 X ... Y ... (position P1)

N27 G26 R ... (arc)

The function G26 can also be programmed in the positioning block for the first contour position P1. See "Contour approach on an arc" for explanation.



Tangential contour departure

G27 Contour departure on an arc with tangential transition to the previously finished contour element (dialog-prompted).


Program format

N35 G41 G01 X ... Y ... (position P)

N36 G27 R ... (arc)

N37 G40 X ... Y ... (position PE)

The function G27 can also be programmed in the positioning block for the last contour position P. See "Contour departure on an arc" for explanation.



Programming in ISO format

Canned cycles

Categories

Cycles are subdivided into the following categories:

- **Machining cycles** (for workpiece machining).
- **Coordinate transformations** (for altering the coordinate system).
- **Dwell time**
- **Freely programmable (variable) cycles**
- **Spindle orientation**

Machining cycles are defined via the G-codes and must be called up separately following cycle definition via G79 – “Cycle call” or M99 – “Cycle call” or M89 – “Modal cycle call”. This also applies to the **freely programmable (variable) cycles** and **spindle orientation**.

Coordinate transformations are effective immediately following cycle definition via G-codes and do not require a separate cycle call. This is also true of the **Dwell time** and **Contour** cycles.

Programmable **machining cycles** (dialog-prompted):

- G83** Peck drilling
- G84** Tapping

- G74** Slot milling
- G75** Rectangular pocket milling, clockwise
- G76** Rectangular pocket milling, counterclockwise

- G37** Definition of pocket contour
- G56** Pilot drilling of contour pocket
- G57** Rough-out contour pocket
- G58** Contour milling (finish), clockwise
- G59** Contour milling (finish), counterclockwise

Programmable **coordinate transformations** (semi-dialog-prompted)

- G28** Mirror image
- G54** Datum shift
- G72** Scaling factor
- G73** Coordinate system rotation

Additional cycles (dialog-prompted)

- G04** Dwell time
- G36** Spindle orientation
- G39** Freely programmable cycle (Program call)

Programming in ISO format

Machining cycles

Peck drilling

G83 Peck drilling (dialog-prompted)

Block format (example)


G83 P01 -2 P02 -20 P03 -10

P04 0 P05 150

G83 Peck drilling
 P01 Set-up clearance
 P02 Total hole depth
 P03 Pecking depth
 P04 Dwell
 P05 Feed rate

See "Peck drilling" for explanation of cycle parameters and cycle procedure.

The cycle parameters P01/P02/P03 must have the same sign.



Tapping

G84 Tapping (dialog-prompted)


Block format (example)

G84 P01 -2 P02 -20 P03 0 P04 80

G84 Tapping
 P01 Set-up clearance
 P02 Total hole depth (thread length)
 P03 Dwell
 P04 Feed rate

See "Tapping" for explanation of cycle parameters and cycle procedure.

The cycle parameters P01/P02 must have the same sign.



Programming in ISO format

Machining cycles

Slot milling

G74 Slot milling (dialog-prompted)


Block format (example)

G74 P01 -2 P02 -20 P03 -10 P04 80


P05 X+50 P06 Y+10 P07 150

G74 Slot milling
P01 Set-up clearance
P02 Milling depth
P03 Pecking depth
P04 Feed rate for vertical feed
P05 Longitudinal axis and length of slot
P06 Transverse axis and width of slot
P07 Feed rate

See "Slot milling" for explanation of cycle parameters and cycle procedure.



Cycle parameters P01/P02/P03 must have the same sign.



Programming in ISO format

Machining cycles

Milling rectangular pockets

G75 Rectangular pocket milling, **clockwise** (dialog-prompted)

G76 Rectangular pocket milling, **counterclockwise** (dialog-prompted)

Block format (example G76)

G76 P01 -2 P02 -20 P03 -10 P04 80



P05 X+90 P06 Y+50 P07 150

G76 Rectangular pocket milling, counterclockwise
 P01 Set-up clearance
 P02 Milling depth
 P03 Pecking depth
 P04 Feed rate for vertical feed
 P05 1st axis and side length of pocket
 P06 2nd axis and side length of pocket
 P07 Feed rate

See "Pocket milling" for explanation of cycle parameters and cycle procedure.



Cycle parameters P01/P02/P03 must have the same sign.
 Cycle parameters P05 and P06 must have a positive sign.



Programming in ISO format

Machining cycles

Milling circular pockets

G77 Circular pocket milling, **clockwise** (dialog-prompted)

G78 Circular pocket milling, **counter-clockwise** (dialog-prompted)



Block format (example G78)

G78 P01 -2 P02 -20 P03 -10 P04 80

P05 90 P06 150

G78 Circular pocket milling, counterclockwise
 P01 Set-up clearance
 P02 Milling depth
 P03 Pecking depth
 P04 Feed rate for vertical feed
 P05 Circle radius
 P06 Feed rate

See "Circular pocket" for explanation of cycle parameters and cycle procedure.



Cycle parameters P01/P02/P03 must have the same sign.

Programming in ISO format

Machining cycles

Contour

G37 Definition of pocket contour (dialog-prompted)


Block format (example)

G37 P01 41 P02 42 P03 43 P04

P05 P06 P07 P08 P09 P10 P11 P12

G37 Definition of pocket contour
 P01 First subcontour (must be programmed as pocket)
 P02 Second subcontour
 .
 .
 P12 Twelfth subcontour

See "Contour cycle" for explanation of cycle.



Pilot drilling

G56 Pilot drilling of contour pocket (dialog-prompted)


Block format (example)

G56 P01 -2 P02 -18 P03 -10

P04 40 P05 1,5

G56 Pilot drilling of contour pocket
 P01 Set-up clearance
 P02 Total hole depth
 P03 Pecking depth
 P04 Feed rate
 P05 Finishing allowance

See "Pilot drilling" for explanation of cycle parameters and cycle procedure.



Cycle parameters P01/P02/P03 must have the same sign.

Programming in ISO format

Machining cycles

Rough-out

G57 Rough-out contour pocket
(dialog-prompted)


Block format (example)

G57 P01 -2 P02 -18 P03 -10


P04 40 P05 2 P06 +45 P07 120

P01 Set-up clearance
P02 Milling depth
P03 Pecking depth
P04 Feed rate for vertical feed
P05 Finishing allowance
P06 Rough-out angle
P07 Feed rate

See "Rough-out" for explanation of cycle parameters and cycle procedure.



Cycle parameters P01/P02/P03 must have the same sign.



Programming in ISO format

Machining cycles

Contour milling

G58 Contour milling (finish), clockwise (dialog-prompted)

G59 Contour milling (finish), counter-clockwise (dialog-prompted)


Block format (example G58)

G58 P01 -2 P02 -18 P03 -10


P04 80 P05 120

G58 Contour milling, clockwise
 P01 Set-up clearance
 P02 Milling depth
 P03 Pecking depth
 P04 Feed rate for vertical feed
 P05 Feed rate

See "Contour milling" for explanation of cycle parameters and cycle procedure.



Cycle parameters P01/P02/P03 must have the same sign.



Programming in ISO format

Coordinate transformations

Mirror image

G28 Mirror image


Block format (example)

G28 X

G28 Mirror image cycle
X Mirrored axis

Two axes can also be mirror-imaged simultaneously; the tool axis cannot be mirror-imaged.

See "Mirror image" for explanation of cycle.



Datum shift


G54 Datum shift

Block format (example)

G54 G90 X+50 G91 Y+15 Z-10

G54 Datum shift cycle
G90 Absolute dimensions
X ... Shift of X-axis
G91 Incremental dimensions
Y ... Shift of Y-axis
Z ... Shift of Z-axis

See "Datum shift" for explanation of cycle.



Scaling factor


G72 Scaling factor (dialog-prompted)

Block format (example)

G72 F1.7

G72 Scaling factor (cycle)
F .. Scaling factor

See "Scaling factor" for explanation of cycle.



Programming in ISO format

Coordinate transformations

Dwell time cycle, freely programmable cycle

Coordinate system rotation


G73 Rotation of coordinate system (dialog-prompted)

Block format (example)

G90 G73 H+120 G17

G90 Absolute dimensions
G73 Coordinate system rotation (cycle)
H... Angle of rotation
G17 Selection of plane for angular reference axis

See "Rotation of coordinate system" for explanation of cycle.



Dwell time cycle


G04 Dwell time (dialog-prompted)

Block format (example)

G04 F5

G04 Dwell time (cycle)
F... Dwell time in seconds

See "Dwell time" for explanation of cycle.



Freely programmable cycle (Program call)

G39 Freely programmable cycle (dialog-prompted)


Block format (example)

G39 P01 12

G39 Freely programmable cycle (Program call)
P01 Program number

See "Freely programmable (variable) cycle" for explanation of cycle.

Notes:



Programming in ISO format

Touch-probe function

Spindle orientation cycle

Spindle orientation

G36 Spindle orientation (dialog-prompted)

Block format (example)

G36 S+45

G36 Spindle orientation cycle
S ... Angular position of spindle

See "Spindle orientation" for explanation of cycle.

Workpiece surface as reference plane

G55 Touch-probe function, workpiece surface as reference plane (dialog-prompted)


Block format (example)

G55 P01 10 P02 Z- P03 G90

X+50 Y+50 Z-20

G55 Workpiece surface as reference plane
P01 Parameter number for measurement
P02 Approach axis and direction
P03 Probing point

See chapter "Touch-probe" for explanation of probe function.



Programming in ISO format

Subroutines and program part repeats

Label number

A **label number** (program marker) is programmed with the command G98 L... This label number can be included in any desired program block that does not contain a **label call**.



A **jump command** is programmed with the address "L" followed by the label number.

A jump command with G98 L... should not be programmed in the same block as a label call "L...".

Program label:

```
N35 G98 L15 G01 ...
```

Label number 15

Label call:

```
N45 L15 ...
```

Program part

The program part is identified by G98 L... (label number) at the beginning of the program.

The label call "L... ." forms the end of a program part repeat. When programming a **program part repeat**, enter the number of repetitions after the label number. Separate the label number from the number of repetitions with a decimal point **.**, e.g.:

L 15.8: call label 15
repeat program part 8 times.

Program part:

```
N35 G98 L15 G01 ...
```

⋮

Program part repeat:

```
N70 L15.8
```

Subroutine

The beginning of a subroutine is identified by G98 L... (label-number). The end is formed by entering G98 L0 (label number 0).

A **subroutine call** is also programmed by entering the address L followed by the label number.

Do not program repetitions together with a subroutine call.

Subroutine:

```
N75 G98 L19 G00 ...
```

⋮

```
N90 G98 L0
```

Subroutine call:


```
N150 L19,0
```



Programming in ISO format

Program jump/STOP block

Jump to another program

Use the  key to program a jump to another program.

Block format (example)

```
% 29
```

% ... Program call

See "Program call" for further information.

STOP block

G38 Corresponds to STOP block in HEIDENHAIN format.


Block format (example)

```
G38
```

Programming in ISO format

Parameter programming

Setting parameters



Parameters are markers for numerical values that are based on units of measurement. They are identified by the letter "Q" and a number and are entered (set) using the  key.

D00:	Assignment
D01:	Addition
D02:	Subtraction
D03:	Multiplication
D04:	Division
D05:	Square root
D06:	Sine
D07:	Cosine
D08:	Root sum of squares
D09:	IF equal, THEN jump
D10:	IF not equal, THEN jump
D11:	IF greater than, THEN jump
D12:	IF less than, THEN jump
D13:	Angle
D14:	Error number

Defining parameters

Parameter definition is the process of assigning a given numerical value or allocating a numerical value via mathematical or logical functions. Parameter definition consists of the **address D** and a code number (see table at right). Parameter definition is dialog-prompted.

Block format

Program definition requires a program block. The individual **block components** of parameter definition are identified by the **letter P** and a **number** (also see cycle parameters for machining cycles). The significance of these components depends on their sequence in the block, which in turn, depends on the input dialog. To **check** this, we recommend moving the highlighted pointer in the block with the  and  keys.

The corresponding dialog prompt for each block component will be displayed.

Programming in ISO format

Parameter programming

Example 1: $Q98 = \sqrt{+2}$

D05 Q98 P01 +2

D05 Square root
Q98 Parameter to which result is assigned
P01 Parameter or numerical value in square root

Example 2: $Q12 = Q2 \times 62$

D03 Q12 P01 +Q2 P02 +62

D03 Multiplication
Q12 Parameter to which result is assigned
P01 Factor 1 (parameter or numerical value)
P02 Factor 2 (parameter or numerical value)

Example 3: IF Q6 less than Q5, THEN jump to LBL 3

D12 P01 +Q6 P02 +Q5 P03 3


D12 IF less than, THEN jump
P01 First comparative value or parameter
P02 Second comparative value or parameter
P03 Label number

Programming in ISO format

Graphics – Blank form definition

Definition of blank

The blank workpiece (BLANK FORM) is defined by points P_{MIN} und P_{MAX} – see "Blank form" (Graphics).
 The tool axis must be specified via G17/G18/G19, in addition to P_{MIN} .
 Otherwise, this error message will appear:
 = BLK FORM DEFINITION INCORRECT =



Entering P_{MIN}

G30 Definition of point P_{MIN} (input in absolute dimensions only)

Block format (example)

G30 G17 X+5 Y+5 Z-10

G30 Definition of P_{MIN}
 G17 Plane selection and tool axis
 X ... X-coordinate of P_{MIN}
 Y ... Y-coordinate of P_{MIN}
 Z ... Z-coordinate of P_{MIN}



The function G90 (absolute dimensions) can be omitted if G30 is programmed.

Entering P_{MAX}


G31 Definition of point P_{MAX} (input in absolute or incremental dimensions)

Block format (example)

G31 G91 X+95 Y+95 Z+10

G31 Definition of P_{MAX}
 G91 Incremental dimensions
 X ... X-coordinate of P_{MAX}
 Y ... Y-coordinate of P_{MAX}
 Z ... Z-coordinate of P_{MAX}




You can interrupt the graphic simulation of the machining procedure by pressing .

General information	Introduction	A1
	Calibrating effective length	A3
	Calibrating effective radius	A7
Touch probe functions for manual operation	Basic rotation	A11
	Workpiece surface = datum	A14
	Corner = datum	A17
	Circle center = datum	A23
Programmable touch-probe function	Workpiece surface as reference plane	A26

Touch-probe Introduction

Touch-probe

Operated in conjunction with a HEIDENHAIN touch-probe system, the **TNC control systems** can automatically detect misalignment in clamped workpieces. The misalignment is computed, stored and automatically compensated for when the workpiece is machined. This makes accurate alignment of the workpiece during set-up unnecessary. The programmable probing function permits workpiece inspection before or during the machining procedure. In the case of castings with varying elevations, for example, the surface can be probed before machining, allowing the correct depth to be reached when machined later. In the same way, changes in position caused by a rise in machine temperatures can be monitored at specified intervals and compensated for.



Versions


The touch-probe system is available in two versions:

Touch-probe 111 system with cable; probe signal transmission and power supply via cable connector. The touch-probe 111 system consists of the TS 111 probe head and APE 110 interface electronics.

Touch-probe 511 system featuring infrared transmission and battery power supply.

The touch-probe 511 system consists of the TS 511 probe head, APE 510 or APE 511 (for the connection of two SE 510) interface electronics and the transmitter/receiver unit SE 510.


Both versions feature a standard tool shank and can be clamped in the spindle like an ordinary tool. The stylus can be replaced. The batteries of the TS 511 probe head with infrared transmission have a service life of 8 hours in probing operation and 1 month in standby mode.



The TS 511 probe head features a transmitter/receiver window on one side (for the triggering signal) and a transmitter window offset by 180°. The side with the transmitter/receiver window must face the SE transmitter/receiver unit when probing the workpiece. The transmitter window on the other side is not required for use with the HEIDENHAIN control systems.

Operation

The probe head moves to the side or upper surface of the workpiece. The feed rate for probing and the maximum stylus overtravel are determined by the machine parameters defined by the machine manufacturer. The probe signals the control system when it contacts the workpiece and the TNC saves the coordinates of the probed points. With the touch-probe function, workpiece surfaces, corners and circle centers can be easily determined and set for use as reference surfaces or reference points.



Touch-probe



Dialog initiation/Error messages

Dialog initiation



The touch-probe system operates in the following modes.

 Electronic handwheel



 Manual mode


  single block/full sequence program run.

Initiate the input dialog by pressing .


If you are currently in  "Electronic handwheel" or  "Manual" mode, the menu of **touch-probe functions** shown at the right will be displayed. Select the desired touch-probe

function with the   keys and press .

In  "Programming/editing" mode, the interactive dialog for programming the touch-probe function "workpiece surface = datum" appears after the dialog is initiated with .



Exiting touch-probe functions

You can exit the touch-probe functions at any time by pressing . The control system will return to the previously selected operating mode.

Error messages

If the probe cannot locate a probing point within the gauging distance defined by the machine parameters, the following error message is displayed:

= TOUCH POINT INACCESSIBLE =.

If the probing point has already been reached when the touch-probe function is initiated, the following error message is displayed:

= STYLUS DEFLECTED =

When using touch-probe systems featuring **infrared transmission**, the transmitter/receiver window (the side with two windows) must be aligned with the evaluator electronics. If it is poorly aligned or if the transmission gap is obstructed (e.g. by the splash shield), the following error message is displayed:

= PROBE SYSTEM NOT READY =.

If the battery voltage in touch-probe system with infrared transmission drops below a specified value, this error message appears:

= EXCHANGE TOUCH PROBE BATTERY =

Touch-probe

Calibrating effective length


Introduction

The effective length of the stylus and the effective radius of the stylus tip can be determined with the aid of the TNC.

The control system automatically computes the necessary data via the touch-probe functions "CALIBRATION EFFECTIVE LENGTH" and "CALIBRATION EFFECTIVE RADIUS".

The length and radius data are saved and stored and taken into account when gauging the work-piece.

The compensation data can also be entered at any time from the control unit keyboard.



Calibrating aids

A ring gauge of known height and internal radius is required for calibrating the effective radius of the ball tip. The ring gauge is clamped to the machine table.

Effective length

When gauging the effective length of the stylus, the probe moves to a reference plane. After touching the surface, the probe is retracted in rapid traverse to its original position. The effective length of the stylus is displayed when calibration is selected again.



Before calibrating the effective length of the stylus tip ball, set the reference plane with the zero tool.

Touch-probe

Calibrating effective length

Input


Operating mode _____  or 

Dialog initiation _____  

CALIBRATION EFFECTIVE LENGTH   Press ENT to select probe function.

CALIBRATION EFFECTIVE LENGTH





Z+ Z-

TOOL AXIS = Z   Specify tool axis if required.

DATUM + 0.000


EFFECTIVE PROBE RADIUS = 0.000


EFFECTIVE LENGTH = 0.000


CALIBRATION EFFECTIVE LENGTH     Move probe system to vicinity of reference plane.

Y+ Y-

TOOL AXIS = Y




DATUM + 0.000  Enter datum if required: Select "Datum".

EFFECTIVE PROBE RADIUS = 0.000  Enter datum in tool axis, e.g. + 5.0 mm.

EFFECTIVE LENGTH = 0.000  Press ENT.

CALIBRATION EFFECTIVE LENGTH

Y+ Y-


TOOL AXIS = Y    Select traverse direction of probe if required, here Y-.

DATUM + 5.000

EFFECTIVE PROBE RADIUS = 0.000

EFFECTIVE LENGTH = 0.000

Touch-probe Calibrating effective length



After contacting the surface, the touch probe returns in rapid traverse to its original position.



The TNC switches automatically to the display "Manual operation" or "Electronic handwheel".

The gauged length is displayed when calibration is selected again.

Notes:



Touch-probe


Calibrating effective radius

Effective radius

The probe must be located within the bore of the ring gauge. The effective radius of the ball tip is determined by probing four points on the bore. The directions of traverse are specified by the control system, e.g. X+, X-, Y+, Y- (tool axis = Z).

After contacting each point, the probe moves in rapid traverse back to its original position; the TNC displays the coordinates of the contact points.





The effective radius is displayed when calibration is selected again.





Touch-probe


Calibrating effective radius



Input

Operating mode _____  or 
 Dialog initiation _____  

CALIBRATION EFFECTIVE RADIUS   Select touch-probe function.

CALIBRATION EFFECTIVE RADIUS   Select "Radius ring gauge".

X+ X- Y+ Y-  Enter radius of ring gauge, e.g. 10.0 mm.





TOOL AXIS = Z   Press ENT.



RADIUS RING GAUGE = 0.000

EFFECTIVE PROBE RADIUS = 0.000

EFFECTIVE LENGTH = 8.455

Enter another tool axis if required (see "Effective length").

CALIBRATION EFFECTIVE RADIUS     Move to approximate center of ring gauge.



X+ X- Y+ Y-   Select probe traverse direction, e.g. X+.

TOOL AXIS = Z

RADIUS RING GAUGE = 10.000

EFFECTIVE PROBE RADIUS = 0.000

EFFECTIVE LENGTH = 8.455

CALIBRATION EFFECTIVE RADIUS   Move probe in positive X-direction.

X+ X- Y+ Y-

TOOL AXIS = Z

RADIUS RING GAUGE = 10.000

EFFECTIVE PROBE RADIUS = 0.000

EFFECTIVE LENGTH = 8.455

Touch-probe

Calibrating effective radius

After probing the ring gauge, the probe returns in rapid traverse to its original position.

CALIBRATION EFFECTIVE RADIUS

X+ X- Y+ Y- ▶ ◀ ▶ Select next probe traverse direction, e.g. X-

X (probe point) Y (probe point)

Z (probe point) C (probe point)

CALIBRATION EFFECTIVE RADIUS ▶ **START** Move probe in negative X-direction

X+ X- Y+ Y-

X (probe point) Y (probe point)

Z (probe point) C (probe point)

After probing the ring gauge, the probe returns in rapid traverse to its original position.

The TNC displays the actual values of the second probe point below the values of the first contact point.

Then probe the ring gauge in the positive and negative Y-directions.


When the procedure is completed:

MANUAL OPERATION

The TNC switches automatically to "Manual operation" or "Electronic handwheel".

The radius of the measured probe tip is displayed on the appropriate line when calibration is selected again.

Notes:



Touch-probe

Basic rotation


Description

The touch-probe function "Basic rotation" can be used to determine the amount of angular misalignment of a clamped workpiece.

The TNC compensates for the angular deviation by means of a basic rotation of the coordinate system



The **basic rotation** must be carried out **in advance** if you want to set the datum using the functions
= CORNER = DATUM = or
= CIRCLE CENTER = DATUM =




Procedure

The touch-probe moves to the side face of the workpiece from two different starting positions. The directions of traverse are specified e.g. X+, X-, Y+, Y- (tool axis = Z). After contact with the side faces, the probe returns in rapid traverse to the respective original position.

The TNC saves the coordinates of the contact points and uses them to compute the angular deviation. In order to compensate for the deviation, the control system must know the "nominal angle" of the side face.





Enter the nominal angle on the line after
= ROTATION ANGLE =



Touch-probe

Basic rotation



Input




Operating mode _____  or 
 Dialog initiation _____  



BASIC ROTATION  Press ENT to select touch-probe function.

BASIC ROTATION


X+ X- Y+ Y-

ROTATION ANGLE = 0.000  Specify angular position of probed side face, e.g Y-axis: + 90°.
 Press ENT

BASIC ROTATION    Move to first starting position

X+ X- Y+ Y-   Select direction of traverse, e.g. X+.



ROTATION ANGLE = + 90.000

BASIC ROTATION  Move probe in positive X-direction.

X+ X- Y+ Y-

ROTATION ANGLE = + 90.000

After touching the side face, the probe returns in rapid traverse to the first starting position.

BASIC ROTATION   Move to second starting position.

X+


X (probe point) Y (probe point)

Z (probe point) C (probe point)

ROTATION ANGLE = + 90.000

Touch-probe

Basic rotation



After touching the side face, the probe returns in rapid traverse to the second starting position.



The TNC switches automatically to the previously selected operating mode "Manual operation" or "Electronic handwheel".

The measured angle of rotation is displayed when "Basic rotation" is selected again.




ROT appears highlighted in the on-screen status display if "Basic rotation" has been programmed and remains displayed as long as a basic rotation is stored in memory. A "Basic rotation" is not cancelled by turning off the power supply. To cancel the command, select the touch-probe function "Basic rotation" and enter the angle of rotation 0° from the keyboard.

Touch-probe

Workpiece surface = datum


Description

In the case of workpieces clamped paraxially to the table, you can use the touch-probe function "Surface = datum" to define the workpiece surface or side face on any axis as datum. The TNC then bases all nominal position values for subsequent machining on that surface.



Procedure




The probe moves to the surface of the workpiece. After contact with the surface, the probe is retracted in rapid traverse to its original position. The TNC saves the coordinates of the contact point on the traversed axis and displays the value on the line "DATUM". Any desired value can be assigned to the contact point by entering it from the keyboard.








Touch-probe


Workpiece surface = datum

Input

Operating mode _____  or 
Dialog initiation _____ 



SURFACE = DATUM  Press ENT to select probe function.

SURFACE = DATUM    Move to starting position.
X+ X- Y+ Y- Z+ Z- C+ C-   Select direction of traverse, e.g. Z-.


SURFACE = DATUM  Move probe in negative Z-direction.
X+ X- Y+ Y- Z+ Z- C+ C-

After contacting the surface, the touch probe returns in rapid traverse to its original position.

X (probe point) Y (probe point)
Z (probe point) C (probe point)
DATUM Z – 18.125

 Enter any desired datum if required
 Press ENT.

Notes:




Touch-probe Corner = datum

Description

With the touch-probe function "Corner = datum", the TNC computes the coordinates of a corner point of the clamped workpiece. The computed value can be used as the reference point for the subsequent machining procedure; all nominal position values will be based on this point.




The function
= BASIC ROTATION =
must be carried out before
= CORNER = DATUM =.




Procedure

The touch-probe moves to two side faces of the workpiece from two different starting positions per face. The directions of traverse are specified. X+, X-, Y+, Y- (tool axis = Z). After contact with the surface, the probe is retracted in rapid traverse to its original position. The TNC saves the coordinates of the contact points and uses them to calculate two straight lines. The missing corner point is the intersection of these lines.



The screen displays the coordinates of the corner point. The computed lines are displayed beneath them by a point on each line and the corresponding angle PA.

You can enter any desired datum from the input keyboard, instead of the calculated corner point. If "Basic rotation" was defined before the touch-probe function "Corner = datum", the straight line computed for "Basic rotation" may be used for the touch-probe function "Corner = datum" as well.








Touch-probe


Corner = datum

Input



Operating mode _____  or 
 Dialog initiation _____  


CORNER = DATUM  Press ENT to select probe function.

CORNER = DATUM    Move to first starting position.
 X+ X- Y+ Y-   Select direction of traverse, e.g. X+.

CORNER = DATUM  Move probe in positive X-direction.
 X+ X- Y+ Y-

After contacting the side surface, the touch probe returns in rapid traverse to its original position.

CORNER = DATUM   Move probe to next starting position.
 X+
 X (probe point 1) Y (probe point 1)
 Z (probe point 1) C (probe point 1)

CORNER = DATUM  Move probe in positive X-direction.
 X+
 X (probe point 1) Y (probe point 1)
 Z (probe point 1) C (probe point 1)

After contacting the side surface, the touch probe returns in rapid traverse to its original position.


The control system displays the actual values of the second probe point beneath the values of the first point. The first line is also indicated by a random point on the line and the angle of direction.

Touch probe

Corner = datum

The second side face is then probed from two different starting positions.

When this procedure is complete:



CORNER = DATUM

X (corner point) Y (corner point)

X (line 1) Y (line 1)

PA (angle of line 1)

X (line 2) Y (line 2)

PA (angle of line 2)

DATUM X (corner point)

DATUM Y (corner point)

Specify any corner point coordinates for X and Y if required.



Press ENT.

Notes:



Touch-probe Corner = datum

Input immediately following "Basic rotation"

Operating mode _____  or 
 Dialog initiation _____  


CORNER = DATUM  Press ENT to select probe function.


CORNER = DATUM

TOUCH POINTS OF BASIC ROTATION ?


X (line 1) Y (line 1)


PA (angle of line 1)

To transfer probe points used for basic rotation:  Press ENT.


If you do not wish to transfer probes points used for basic rotation:  Press NO ENT.

Then probe the second side face as described above.

CORNER = DATUM 

X+ X- Y+ Y- 

Notes:




Touch-probe

Circle center = datum

Description

In the case of clamped workpieces with cylindrical features (bore, circular pocket or external cylinder), the touch-probe function "Circle center = datum" can be used to determine the coordinates of the circle center. The calculated circle center can be used as the datum for the subsequent machining procedure. All nominal position values will be based on this point.



The function
= BASIC ROTATION =
must be carried out before
= CIRCLE CENTER = DATUM =.

Procedure



In the case of bores and circular pockets, the probe must be located within the bore or pocket.

To determine the circle center, probe four points of the external cylinder or bore. The directions of traverse are specified, e.g. X+, X-, Y+, Y- (tool axis = Z).

After each contact, the probe is retracted in rapid traverse to its original position. The TNC saves the coordinates of all computed contact points and uses them to calculate the circle center.

The coordinates of the circle center are displayed on the screen with the specified radius PR.

You can enter any desired values from the input keyboard, instead of the calculated circle center coordinates.






Touch-probe


Circle center = datum


Input


Operating mode  or 

Dialog initiation  

CIRCLE CENTER = DATUM  Press ENT to select probe function.


CIRCLE CENTER = DATUM  Move to first starting position.

X+ X- Y+ Y-  Select direction of traverse, e.g. X+.

CIRCLE CENTER = DATUM  Move probe in positive X-direction.

X+ X- Y+ Y-


After touching the cylindrical surface, the probe is retracted in rapid traverse to its starting position.

CIRCLE CENTER = DATUM  Select next direction of traverse, e.g. X-.

X+ X- Y+ Y-

X (probe point 1) Y (probe point 1)

Z (probe point 1) C (probe point 1)

CIRCLE CENTER = DATUM  Move probe in negative X-direction.

X+ X- Y+ Y-

X (probe point 1) Y (probe point 1)

Z (probe point 1) C (probe point 1)

After touching the cylindrical surface, the probe is retracted in rapid traverse to its starting position.

The TNC displays the actual values of probe point 2.

Touch-probe

Circle center = datum


Then probe two additional points on the cylindrical surface, in positive and negative Y-direction.


When this procedure is complete:


CIRCLE CENTER = DATUM

X (midpoint) Y (midpoint)

PR (circle radius)

DATUM X (midpoint) 

DATUM Y (midpoint) 

 Press ENT.

Specify any circle centre coordinates for X and Y if required.

Touch-probe

Programmable touch-probe function: "Surface = datum"


Description

You can probe a surface of a workpiece with program control, both before and while machining the part. In the case of castings with varying elevations, for example, the TNC can probe the surface before machining, allowing the correct depth to be reached during the subsequent machining procedure. In the same way, changes in position caused by a rise in machine or workpiece temperatures can be monitored and compensated for.

Programming

Initiate programming with the **TOUCH PROBE** key.

The TNC will then prompt you for the parameter number at which the results of the measurement will be saved. After entering the probe axis and direction, specify the nominal position for the touch-probe cycle. The programmed touch-probe cycle requires two program blocks.




Procedure

Travelling at rapid rate, the probe moves to the advanced stop distance above the programmed nominal position (probe point). The advanced stop position is determined by the machine manufacturer via a machine parameter.

The probe then moves to the workpiece, on the probe axis and in the probing direction, travelling at the feed rate specified for measuring and touches the surface. After contact, the probe is retracted in rapid traverse to its original position.

To compensate for deviations in the position of the workpiece surface, the datum must be shifted on the probe axis, using the "Datum shift" cycle, by the amount of the value saved under Q. The gauged value can also be used in a tool definition as a length compensation factor, for example.



Output of measured value via Q parameter (as of software version 05)

The parameters Q115 to Q118 contain the following measured values after execution of the programmed touch probe functions (see also "Parameter-Special functions"):

Q115 measured value X axis

Q116 measured value Y axis


Q117 measured value Z axis


Q118 measured value 4th axis



Touch-probe


Programmable touch-probe function:
"Surface = datum"

Input

Operating mode _____ 
 Dialog initiation _____ 

PARAMETER NUMBER FOR RESULT ▶ Specify parameter number.
 ▶  Press ENT.

PROBE AXIS/PROBING DIRECTION ? ▶ **Z** Specify probe axis, e.g. Z.
 ▶  Specify probing direction.
 ▶  Press ENT.

POSITION VALUE ? ▶ **X** Specify coordinates of probe point: select axis, e.g. X.
 ▶ **I** Incremental – absolute?
 ▶ Enter numerical value.
 ▶ **Y** Select next axis, e.g. Y.
 .
 .
 .
 After all coordinates have been entered: ▶  Press ENT.

Sample display

32 TCH PROBE 0.0 REF. PLANE
Q10 Z-
33 TCH PROBE 0.1 X + 10.000
Y + 20.000 Z + 0.000

The X, Y plane is probed in the negative Z-direction. The gauged value is saved at parameter Q10. The coordinates of the nominal probe point are X 10.000/Y 20.000/Z 0.000.

Notes:



TNC data interface	Interface operating modes	V1
	Floppy disk unit/magnetic tape unit	V2
	Interface definition	V3
	Cables and connector pin assignment	V4
Data transfer	General information	V6
	Operating procedure for FE and ME	V7
	Blockwise transfer	V14
	Printer	V17
	Transfer of TNC 145 programs	V18

External data transfer


The TNC data interface

V.24/RS-232-C interface

The TNC control system is equipped with a **V.24 (RS-232-C) data interface** for input and output of programs in plain-language or ISO formats. This means that you can use the interface to transfer programs from the TNC's memory to an **external storage unit**, e.g. a magnetic tape unit or floppy disk unit, or to some other **peripheral device**, such as a printer. You can also transfer data from an external storage unit to the control unit.

The interface port is located at the rear of the control unit.

The interface operating mode (ME magnetic tape, FE floppy disk or operation with other external devices) must be specified in advance.



Operating mode

The TNC's V.24 interface can be switched to three different **interface operating modes**:

- ME mode:** for connecting a HEIDENHAIN ME magnetic tape unit or a HEIDENHAIN FE floppy disk unit. Commands are entered from the keypad of the external unit.
- FE mode:** for connecting a HEIDENHAIN FE floppy disk unit. Commands are entered via TNC menu.
- EXT mode:** for connecting other peripheral equipment.

The interface operating mode is defined via the supplementary operating mode (MOD) **V.24 INTERFACE** (see "Interface definition").

Baud rate

The **data transmission speed** (baud rate) at the TNC interface depends on the interface operating mode:

- ME-mode:** 2400 baud
- FE-mode:** 9600 baud
- EXT-mode:** 2400 baud; the baud rate can be set to one of the values shown in the table at the right via the supplementary operating mode (MOD) **BAUD RATE** (see "Interface definition").

Transfer blockwise

The TNC 355 can load machining programs in plain-language or ISO format from an external programming station or floppy disk unit via the V.24 data interface and simultaneously execute these programs (see "Transfer blockwise").

Operating mode: EXT

Possible baud rates:

110 baud
150 baud
300 baud
600 baud
1 200 baud
2 400 baud
4 800 baud
9 600 baud

1 baud = 1 bit per sec

External data transfer


Floppy disk unit/Magnetic tape unit

Disk and magnetic tape units

HEIDENHAIN offers a floppy disk unit or magnetic tape unit for saving and storing machining programs or transferring programs that have been created at an external programming station.

FE 401: Portable floppy disk unit for use with multiple machines.

ME 101: Portable magnetic tape unit for use with multiple machines.




Connection options

Each of the external storage units is equipped with two V.24 data interfaces identified by **TNC** and **PRT**.

TNC port: for connection to the control unit.

PRT port: for connection to a peripheral device.

These ports make it possible to connect a second device to the external storage unit, in addition to the TNC.



Operating modes

The **FE 401** can transfer data either in ME mode or in FE mode. The mode can be defined via a switch located on the unit.

The **ME 101** can transfer data in ME mode only.


Baud rate

The baud rate at the **TNC port** is defined as follows:

ME mode: 2400 baud
 FE mode: 9600 baud



The baud rate at the **PRT port** can be adjusted with the aid of a switch located at the rear of the external unit.

ME 101: 110/150/300/600/1200/2400 bd
 FE 401: 110/150/300/600/1200/2400/4800/9600 bd.



External data transfer Interface definition

V.24
interface
definition

Operating mode _____ any except 
Dialog initiation _____ 

VACANT BLOCKS = 1112



Page through supplementary mode menu until V.24 INTERFACE appears.

V.24 INTERFACE = ME

To define for ME mode:



Press DEL to confirm ME mode.

To select FE interface or operation with other external unit:





Page until FE or EXT appears.



Press DEL to confirm and exit supplementary mode.

The V.24 interface can be defined via machine parameters for operation with other external devices.
For further information, see "TNC 355 Mounting and interface description".

Baud rate
definition
for EXT

Operating mode _____ any except 
Dialog initiation _____ 

VACANT BLOCKS = 1112



Page through supplementary mode menu until BAUD RATE appears.




BAUD RATE = 2400



Enter desired baud rate from table.

Press ENT.




You can also save the new baud rate by pressing  or using the   keys.

External data transfer

Cables and connector pin assignment


ME 101 magnetic
tape unit/
FE 401 disk unit
↔ TNC



External data transfer

Cables and connector pin assignment

Magnetic tape
unit/floppy disk
unit/TNC ↔
peripheral device



External data transfer

General information


Data media

The ME 101 **magnetic tape unit** uses **mini-cassettes** for data storage. It can store up to 32 different programs with a total of 1,000 program blocks (approx. 35 kilobytes) per tape side. The FE 401 **floppy disk unit** uses 3.5" **disks** (double-sided, 135 TPI), with a storage capacity of maximum 256 different programs with a total of 25,000 program blocks (approx. 790 kilobytes). The FE 401 is equipped with two disk drives. Simultaneous disk access via the "TNC" and "PRT" interfaces is possible, e.g. for running a program and printing out hardcopy on a printer at the same time. The second disk drive is designed for data back-up (disk copy).


Write protection

The minicassettes and disks can be safeguarded against accidental erasure or write-over.

The **write-release tabs** must be inserted in the magnetic tape cassette for transferring data.





The small **sliding tab** on the reverse side of the disk must cover the opening at the corner of the disk for transferring data.



External data transfer

Procedure for ME, FE and EXT operation

Data transfer

Data can be transferred between the TNC and an external unit in  PROGRAMMING/EDITING mode. In addition, you can transfer a program to the TNC and run it simultaneously in  PROGRAM RUN mode (see "Transfer blockwise"). The TNC interface must be adapted to the external unit (ME, FE or other peripheral, e.g. printer) with respect to operating mode.

ME mode

In **ME mode**, commands are entered from the keypad of the magnetic tape unit or disk unit (switch in ME position) and via the TNC menu (see illustration).

FE mode

In **FE mode**, commands are entered only from the TNC menu. You do not need to press any keys on the FE unit.

EXT mode

For information on entering commands in **EXT mode**, please refer to the manufacturer's instructions for the external unit in question.

Desired data transfer option

Press ME or FE keys (red lamp must light)

TNC → ME



ME → TNC








TNC → FE



FE → TNC






Dialog initiation

The dialog for transferring data in any direction (tape/disk → TNC or TNC → tape/disk) is initiated by pressing . The transfer mode options shown at the right are displayed on the screen. Use the   keys to move the highlighted pointer to the desired mode and press  to select and start the operating mode. To exit the menu, press .



Interrupting data transfer

Once data transfer has begun, it can be interrupted by pressing  on the TNC or  on the ME/FE unit. If data transfer is interrupted, the error message = ME: PROGRAM INCOMPLETE = appears. After this message is cleared with the  key, the menu of operating mode options for data transfer is displayed.

External data transfer



External data storage unit → TNC

Program
directory

Operating mode  _____
Dialog initiation   _____

PROGRAM DIRECTORY   Press ENT to select mode.

EXTERNAL DATA INPUT
Magnetic tape/disk starts.

END = NOENT
10 600
All programs stored on the tape or disk are displayed but not transferred.
To exit the operating mode:   Press NO ENT to exit mode.

PROGRAMMING AND EDITING
The TNC is now in PROGRAMMING AND EDITING mode.

External data transfer

External data storage unit → TNC

Read-in
all programs

Operating mode _____



Dialog initiation _____



READ-IN ALL PROGRAMS  Press ENT to select mode.

EXTERNAL DATA INPUT
Magnetic tape/disk starts.

PROGRAMMING AND EDITING




0 BEGIN PGM 24	MM
1 ...	
2 ...	

All programs stored on the tape/disk are now in the TNC's memory. The program with the highest number is displayed.

External data transfer



External data storage unit → TNC

Read-in
program
offered

Operating mode _____ 
Dialog initiation _____  

READ-IN PROGRAM OFFERED  Press ENT to select mode.

EXTERNAL DATA INPUT
Magnetic tape/disk starts.

ENTRY = ENT/OVERREAD = NOENT
22
To transfer offered program:  Press ENT to transfer program.
To **skip** offered program:  Press NO ENT to skip to next program.

ENTRY = ENT/OVERREAD = NOENT
24
The TNC displays all programs stored on the tape or disk, one after another. After displaying the program with the highest number, the TNC automatically returns to PROGRAMMING AND EDITING mode.



External data transfer

External data storage unit → TNC

Read-in
selected
program

Operating mode _____ 
Dialog initiation _____  

READ-IN SELECTED PROGRAM   Press ENT to select mode

PROGRAM NUMBER =  Specify desired program number.
 Press ENT.

EXTERNAL DATA INPUT
Magnetic tape/disk starts.

PROGRAMMING AND EDITING

0 BEGIN PGM 24 MM

1 ...

2 ...

The selected program is in the TNC's memory and is displayed.

External data transfer





TNC → external data storage unit

Read-out
selected
program


Operating mode _____ 
Dialog initiation _____  

READ-OUT SELECTED PROGRAM  Press ENT to select mode.

EXTERNAL DATA OUTPUT
Magnetic tape/disk starts, then stops after leader output.

OUTPUT = ENT/END = NOENT     Move cursor to desired program number.

1	13
14	24


 Press ENT to transfer selected program to tape/disk.

EXTERNAL DATA OUTPUT
Magnetic tape/disk starts, then stops after program transfer is complete.

OUTPUT = ENT/END = NOENT

1	13
14	24

Cursor positioned at next program number.


To exit operating mode:  Press NO ENT to exit mode.

PROGRAMMING AND EDITING
The TNC is now in PROGRAMMING AND EDITING mode.

External data transfer

TNC → external data storage unit

Read-out
all programs

Operating mode _____ 
Dialog initiation _____  

READ-OUT ALL PROGRAMS  Press ENT to select mode.

EXTERNAL DATA OUTPUT
Magnetic tape/disk starts and data transfer begins.

After data transfer is complete, the TNC returns to PROGRAMMING AND EDITING mode.

External data transfer

Transfer blockwise


Program run from external storage unit

In "Transfer blockwise" mode, machining programs can be transferred via the V.24 (RS-232-C) serial interface from an external storage unit or the FE unit and executed simultaneously. This makes it possible to run machining programs that exceed the TNC's RAM memory capacity.


Data interface

The data interface can be programmed via machine parameters. Please refer to the "TNC 355 Mounting Instructions and Interface Description" for a detailed description of interface signals of the transfer protocol and the software installation required by your computer. The V.24 interface of the TNC must be defined for external data transfer or FE mode.

Starting "Transfer blockwise"

You can start the transfer of data from an external storage unit in "Single block" and "Full sequence" modes by pressing . The TNC loads the program blocks in available memory and interrupts data transfer when memory capacity is reached.

No program blocks are displayed on the screen until available memory is full or the program has been completely transferred.

Although program blocks are not displayed, program execution can be started by pressing the external  button.


Short positioning blocks are usually run when transferring data from an external storage medium. To avoid unnecessary interruption of a program run after it has started, a large number of program blocks should be saved as a buffer. For this reason, it is a good idea to wait until available memory space is full.

After the program run has started, the executed blocks are deleted as further blocks are called from the external storage unit.

External data transfer

Transfer blockwise

Skipping program blocks

If you press the  key in "Transfer blockwise" mode before initiating the start, and enter a block number, all blocks preceding the specified block number will be skipped.

Interrupting program execution

To interrupt a program run.

- press the external STOP button and the internal STOP key.

The display "TRANSFER BLOCKWISE" remains on the screen even after execution has been interrupted. The message disappears when you

- call up a new program number
- or
- switch from program run "Single block" or "Full sequence" to another operating mode.

Program format

The following conditions apply to program format in "Transfer blockwise" mode:

- Program calls, subroutine calls, program part repeats and conditional program jumps cannot be executed.
- Only the last defined tool can be called (except for operation with central tool storage).

Block number

The program destined for transfer may contain blocks numbered higher than 999. The block need not be numbered consecutively, but must not exceed 65,534. Four-digit block numbers in plain-language programs are displayed on two lines on the screen.

Graphics (as of software version 05)


The TNC can graphically simulate on the screen programs that are transferred blockwise from an external memory. It is only necessary to program the workpiece definition BLK FORM behind the BEGIN PGM block.


External data transfer


Transfer blockwise

Starting
"Transfer
blockwise"

Operating mode _____  


Dialog initiation _____ 


PROGRAM NUMBER  Enter desired program number.

 Press ENT.

TRANSFER BLOCKWISE


Wait until initial program blocks are displayed on screen.


Start machining  Press START to run program.



Start graphic simulation (as of software version 05)  Graphically simulate program.

Interrupting
"Transfer
blockwise"

TRANSFER BLOCKWISE

To interrupt the program run:  Press STOP to interrupt run.


 Press STOP to abort program run

In  mode, you can also abort program execution by switching to  mode.

External data transfer

TNC 355 graphics output to a printer

You can check a machining program on the TNC 355 with the aid of the graphics feature. The image displayed on the screen can be output via the V.24 interface (EXT mode) and sent to a printer for hardcopy print-out.

The external printer is interfaced to the TNC 355 via machine parameters 226 to 233. To start printing, press  while the graphic image is displayed on the screen.

The following input values for machine parameters 226 to 233 apply to the **Texas Instruments OMNI 800/Model 850 printer:**

Parameter No.	Input value
226	1 819
227	17 200
228	6 977
229	2 060
230	1 290
231	6 990
232	2
233	0

The following input values apply to the **EPSON matrix printer:**

Parameter No.	Input value
226	795
227	13 080
228	0
229	0
230	1 805
231	2 587
232	10 757
233	2

To print the graphic image, the TNC automatically switches to the interface operating mode "EXT", if "ME" or "FE" operation has been set via the MOD function.

External Data Transmission

Transfer of TNC 145 programs

TNC 145 C program management

The TNC 145 can manage only one program at a time in the main memory. Unlike the TNC 150-/TNC 151-/TNC 155- and TNC 355 programs, this program has no program number and can therefore not be managed by the above-mentioned control.


Remedy



A **remedial program number** must be given before transferring TNC 145 C programs. The TNC stores the transferred TNC 145 C program under this number.


External data transfer

Transfer of TNC 145 C programs

Entry of all programs


Operating mode TNC _____ 


Operating mode of the ME _____  


Dialog initiation _____ 

PROGRAM SELECTION


PROGRAM NUMBER =

 Enter remedial program number. (maximum of 8 digits).


 Transfer to memory.



MM = ENT / INCH = NO ENT  for **dimensions in mm.**

or

 for **dimensions in inch.**

0 BEGIN PGM 12345678 MM  External data transfer.



  Select "Enter in all programs."

ENTER IN ALL PROGRAMS  Start transfer.

The cassette contents with the TNC 145 C programs are now stored in the main memory of the TNC under the remedial program number 12345678.

Anmerkungen



A large, faint grid of lines covering the central and right portions of the page, intended for handwritten notes. The grid consists of vertical and horizontal lines forming a series of small squares.

Specifications	Control specifications	T1
	Electronic handwheel specifications	T4
	Floppy-disk unit specifications	T5
	3D Touch-probe system specifications	T6
	Dimensions	T8
Index	Subject index	T14
	Error messages	T24

Technical data

Specifications

Control versions	<p>TNC 355 with BE 412B Visual Display Unit (12 inch, monochrome) including stored-program machine interface control (PLC)</p> <p><i>TNC 355 for 4 axes and oriented spindle stop</i> TNC 355B = without PL 300 power board TNC 355Q = additional inputs and outputs on PL 300 power board</p> <p><i>TNC 355 for 5 axes and oriented spindle stop</i> TNC 355C = without PL 300 power board TNC 355S = additional inputs and outputs on PL 300 power board</p>
Control type	<p><i>Contouring control for 4 or 5 axes, with oriented spindle stop</i> Linear interpolation in 3 of 4 axes (3 of 5 axes), circular interpolation in 2 of 4 axes (2 of 5 axes) (only if the 4th and 5th axes are parallel to a linear axis; contour programming with the 4th and 5th axis is possible under certain conditions), <i>Helical interpolation</i></p> <p><i>Program input and output</i> per HEIDENHAIN plain-language dialog concept or ISO 6983 standard mm/inch conversion for input values and displays Display step 0.005 mm or 0.0002 in. or 0.001 mm/0.0001 in. Nominal positions (absolute or incremental dimensions) in Cartesian or polar coordinates Entry step down up 0.001 mm or 0.0001 in. or 0.001°</p>
Operator-prompting and displays	<p>Plain language dialogs and error messages (in 8 languages) Display of current, previous and next two program blocks Status indicator for all major program data including actual value/nominal value/distance to go/trailing error</p>
Program memory	<p>Semiconductor memory with battery backup for 32 NC-programs, total 3100 blocks Programmable read/write protection</p>
Central tool memory	<p>Up to 99 tools. Suitable for toolchanger with random select or fixed pocket coding system</p>
Operating modes	<p><i>Manual/Electronic handwheel:</i> control functions as a conventional digital readout Traverse of machine axes either per electronic handwheel or in jog positioning</p> <p><i>Positioning with manual data input:</i> each positioning block is run after being entered; block data is not stored</p> <p><i>Program run in single block:</i> program entered is run block-by-block after individual press of START-key</p> <p><i>Program run "automatic":</i> program run started by press of key, runs to programmed STOP or program end</p> <p><i>Programming:</i> (also in background mode) a) for linear or circular interpolation. <i>manually</i> per program list or drawing or <i>externally</i> via RS-232-C/V.24 data interface (e.g. via FE 401 Floppy disk unit or ME 101/102 Magnetic tape unit from HEIDENHAIN; or other peripheral devices) b) for single-axis operation additionally by transfer of position data (actual values) with conventional workpiece machining (playback mode)</p> <p><i>Transfer blockwise.</i> program transfer from a host computer or floppy disk unit. Programs exceeding control memory capacity can be transferred and run simultaneously on-line</p> <p><i>Additional selectable operating modes:</i> mm/inch, character height for position display, safety working limits, user parameters (defined by machine tool builder) Displays: vacant blocks, actual value/nominal value/distance to go/trailing error, RS-232-C/V.24 interface: ME/FE/EXT, Baud rate ISO: also with block number increment</p>

Technical data

Specifications



Programmable functions	<p>Straight line, chamfer Circle (entry: center and endpoint of circular arc or radius and endpoint of circular arc) Circle connected tangentially to preceding contour (entry: of arc endpoint) Rounded corners (entry: transitional radius) Tangential contour approach and departure Tool number/tool length and radius compensation Spindle orientation Spindle speed Rapid traverse Feed rate Program nesting Subprograms/program part repeats Canned cycles for peck-drilling, tapping, slot milling, rectangular pocket milling, circular pocket milling Cycles for milling pockets with variable contours (with up to 12 subcontours; intersections computed by control) Coordinate system rotation and datum shift Mirror-imaging, scaling factor Dwell time/Auxiliary functions/Program STOP Customized macros</p>
Variable parameter programming	<p>Mathematical functions (=+/-/x/÷/sin/cos/angle α from $r \cdot \sin \alpha$ and $r \cdot \cos \alpha / \sqrt{a^2 + b^2}$) Parameter comparison (=+/>/<)</p>
Program test without machine movement	<p>Analytical program test and graphic simulation of machining program Display modes: in 3 planes, plan view with depth shading, 3D simulation, magnify function</p>
Program editing	<p>Editing of program words, insertion of program blocks, deletion of program blocks; search routine for finding program blocks with particular characteristics within a program</p>
Program continuation after interruption	<p>Control facilitates resumption of program after interruption by retaining all important program data</p>
Touch probe functions	<p>Programmable: Actual position definition of axis-perpendicular workpiece surface. For setting up in "Manual" and "Electronic handwheel" modes: calibration, definition of angular clamping attitude of workpiece, definition of workpiece corner and circle center, definition of workpiece surface as datum. Measured values can be output through the data interface</p>
Data interface	<p>Standard interface per CCITT recommendation V.24 or EIA standard RS-232-C; Baud rates: 110, 150, 300, 600, 1200, 2400, 4800, 9600 Baud Expanded interface with control characters and block check characters (BCC) for "Transfer blockwise"</p>
Fault/Error diagnosis and monitoring	<p>Control displays programming and operating errors in plain language. It monitors the functioning of major electronic assemblies, positioning systems and important machine functions. If an error is detected, a plain language error message is generated and the machine shut down via emergency STOP.</p>
Reference mark evaluation	<p>Datum values are transferred automatically following power failure by crossing encoder reference marks (also applies to distance-coded reference marks)</p>
Max. traversing distance	<p>± 30000 mm or 1181 in.</p>
Max. traversing speed	<p>30 m/min. or 1181 in./min.</p>
Feed rate and spindle override	<p>0 . 150 % via two potentiometers on the control panel</p>
Encoders for position feedback	<p>HEIDENHAIN incremental linear encoders or rotary encoders, linear encoders also with distance-coded reference marks, grating period 0.01/0.02 mm or 0.1 mm</p>

Technical data

Specifications

Limit switches	Software-controlled limit switch for machine slides (X+/X-/Y+/Y-/Z+/Z-/IV+/IV- and V+/V-); respective traverse range is specified as machine parameter; additional programmable traverse range limits
Positioning with Hirth-type serration	Positioning pattern programmable via machine parameter
Axis error compensation	<i>.linear</i> (via machine parameter) <i>.sectional</i> (e.g. lead screw error compensation) via editable correction tables
Control inputs	Linear or rotary encoders X/Y/Z/IV/V/spindle Electronic handwheel (HR 150 or HR 250) Touch probe systems (TS 511/TS 111)
Control outputs	One analog output each for X/Y/Z/IV/V (with automatic offset-adjustment), one analog output for spindle
Power supply	BE 412B: selectable 100/120/140/200/220/240 V, -15 ... 10%, 48 ... 62 Hz NC-Component for LE 355: 24 V-, I max = 1.5 A PLC-Component for LE 355: 24 V-, I max = 1.8 A with a coincidence factor of 0.5
Power consumption	NC-Component for LE 355: approx. 36 W PLC-Component for LE 355: approx. 43 W with a coincidence factor of 0.5 PL 300: depending on connected consumers BE 412B: approx. 40 W
Ambient temperature	Operation 0 ... 45° C (32 ... 118° F), Storage -30 ... 70° C (-22 ... 158° F)
Weight	Logic unit: LE 355B = 9.4 kg (21 lb), LE 355Q = 11.5 kg (25 lb) Keyboard unit: TE 355A/TE 355C = 1.6 kg (4 lb), TE 355B/TE 355D = 1.5 kg (4 lb) Visual display unit: BE 412B (12 in.): 11.7 kg (26 lbs)

Special characteristics of the 5-axis contouring control TNC Keyboard

Instead of the  key, the keyboard for the 5-axis contouring control (TE 355C [D]) has a key for programming the axis V. The  key on the 5-axis contouring controls initiates the dialog for programming the Q parameter functions. The position of the 5th axis is displayed on the screen under the 4th axis. The display of datum shifts and mirrored axes was simplified.

Example:

N XY

S X

This display indicates that in the X and Y axes a datum shift was programmed and in addition the X axis was mirrored. The datum shift is calculated in the position display.

Limitations to the V axis

- .The V axis reference mark is always traversed last.
- .The V axis is not to be programmed as the tool axis.
- .Contour programming and cycles are possible only under certain conditions.

Technical description

Specifications

Electronic handwheels

For connection to TNC 355	HR 150: for installation in machine control console (only one handwheel possible) HR 250: portable unit with 1 handwheel Attaches magnetically to machine.
Traverse per handwheel revolution	10/5/2.5/1.25/0.625/0.313/0.156/0.078/0.039/0.02 mm (selectable via TNC keyboard)
Maximum traversing rate	2.4 m per min. (\approx 4 rps) if not limited by TNC parameters
Power supply	from TNC
Cable length	HR 150: 1 m (3 ft), max. 10 m (33 ft) HR 250: 3 m (10 ft), max. 10 m (33 ft)
Enclosure	IP 64 (HR 250 only)
Ambient temperature	Operation: 0 to 45° C (0 to 118° F) Storage: -30 to 70° C (-22 to 158° F)
Weight	HR 150: 0.3 kg (0.66 lb) (without rotary knob/handwheel) HR 250: 1.1 kg (2.4 lb)

Technical description

Specifications

Floppy-disk unit

FE 401: compact portable unit for use on multiple machines
(can also be used with TNC 131/TNC 135/TNC 145/TNC 150 and TNC 151/TNC 155)

Data interfaces	2 interfaces per CCITT recommendation V.24 or EIA standard RS-232-C Baud rates: with 1 interface: 2400/9600 baud with 1 interface: 110/150/300/600/1200/2400/4800/9600 baud
Disk drives	2 disk drives, including one for copying Panasonic JU 343
Floppy disks	BASF 3 1/2 inch, double-sided 135 TPI Storage capacity: approx. 790 kilobyte (approx. 25,000 program blocks), max. 256 different programs
Supply voltage	Multirange 100/120/140/200/220/240 V +10% to -15%, 48 to 62 Hz
Power input	Max. 18 W
Ambient temperature	Operation: 15 to 45° C (59 to 113° F) (approx. 10 min. after starting: 10 to 45° C [50 to 113° F]) Storage: -40 to +60° C (-40 to 140° F)
Weight	4.9 kg (11 lb)

Technical description

Specifications

3D Touch-probe systems

Triggering 3D-touch probe

Probing reproducibility better than 1 µm (40 µin.)
Probing speed max. 3 m/min. (9.8 ft per min.)
Stylus with predetermined break point
Ruby ball tip
Shank and stylus shape available according to customer specifications

Applications.

.Acquisition of workpiece length
.Acquisition of workpiece datum points for compensation of chucking errors and reduction of set-up time
.Measurement of finished part
.Measurement of machine datum points for compensation of thermal expansion/contraction of the machine

For manual changing (cable connection)

TS 111

Connection possibilities:
The TS 111 Touch Probe System can be connected via cable and evaluator electronics to the TNC 355B* and TNC 355C controls.
Interface to CNC control unit:
.Cable adapter (depending on the control)
.APE 110 Evaluator electronics

For manual changing (cable connection)

TS 120

Connection possibilities:
The TS 120 Touch Probe System has an internal evaluator electronics and can be directly connected via cable to the TNC 355 control.
Interface to the CNC control unit:
.Cable adapter

For automatic changing (infrared transmission)

TS 511

Connection possibilities:
The TS 511 Touch Probe System features cable-free infrared transmission and can be directly connected to the TNC 355B* and TNC 355C* controls.

Power supply:
4 "micro-sized" NiCd storage batteries
Maximum operating time per charge:
measuring mode 8 hr, standby mode 1 month
Delivery includes: spare set of batteries and external charging unit (220 V, 50 Hz)

Interface to CNC control unit:
.Cable adapter (depending on the control)
.SE 510 Transmitter/receiver unit
.APE 510 and 511 Evaluator electronics
APE 511 for the connection of two SE 510

* including export versions (see inside front cover)

Notes:




A large grid of small squares, typical of graph paper, intended for writing notes. The grid covers most of the page below the 'Notes:' header.

Dimensions

Logic unit

LE 355 B





Dimensions


Logic unit

LE 355 Q

Dimensions mm/inch





Freiraum Belüftung
FREE SPACE FOR AIR VENTILATION
encadrement pour aération




Dimensions Keyboard unit

TE 355 and TE 355 C

Dimensions mm/inch




View A



Dimensions Keyboard unit

TE 355 B





Dimensions



Video display unit

BE 412 B (12")

Dimensions mm/inch



View A






Dimensions

PLC input/output board

PL 300

Dimensions mm/inch



Index

A

Absolute dimensions	K10, P24
–, ISO format	D10
–, plain language	P19
Advance stop distance t	P98
Angle (parameter function)	P87
Angle reference direction	K2
Approach command M95	P69
Approach command M96	P68
Arc with tangential connection (see Tangential Arc)	P54
Auxiliary functions (M)	P32
–, affecting program run	P34
–, list	P34
–, variable	P35

B

Basic rotation	A11
–, entry	A12
Baud rate	E14
–, entry	V3
Baud rate	V2
Blank form (BLK FORM)	P172, P176
Blank form (Graphics)	P172
Block call	P164
Block number	P2
Block number increment	E14, D5
Block, deleting	P166
Block, inserting	P166
Buffer battery	E3, P208

C

C (see circular path C)	P44
Cable connection (ME, FE and EXT)	V4
Calibration	A3
–, effective length	A3
--, entry	A4
–, effective radius	A7
--, entry	A8
CC (see circle center and pole)	P22, P44
CE key	P4
Central angle	P50
Central tool memory	D9, P12
Chamfers	P42
–, ISO format	D20
–, plain language	P43
Changeover mm/inch	E12
Changing programming modes	D3
Circle center	P20
–, ISO format	D11
–, plain language	P23

Index

C continued

Circle center = Datum	A23
–, entry	A24
Circular interpolation	P44
–, ISO format	D14, D15, D16, D18
–, plain language	P47, P49
Circular path C	P44
–, ISO format	D14, D16
–, plain language	P47, P49
Circular path CR	P50
–, ISO format	D15
–, plain language	P51
Circular pocket	P116
–, ISO format	D26
–, plain language	P119
Code number	E18
Conditional jump	P84
–, ISO format	D31
–, plain language	P85
Contour approach in a straight line	P64
–, path angle α equal to 180°	P65
–, path angle α greater than 180°	P66
–, path angle α less than 180°	P67
Contour approach on an arc	P62
–, ISO format	D21
–, plain language	P63
Contour departure in a straight line	P64
–, path angle α equal to 180°	P65
–, path angle α greater than 180°	P66
–, path angle α less than 180°	P67
Contour departure on an arc	P62
–, ISO format	D21
–, plain language	P63
Contour geometry (cycle)	P128
–, ISO format	D27
–, plain language	P129
Contour mill	P138
–, ISO format	D29
–, plain language	P139
Contour pocket	P122
–, example	P143
–, program format	P142
Contouring key	P20
Control unit, switching on	E4
Coordinate axes	K1
Coordinate system	K1
Coordinate transformations	P94
Coordinates	K1, P19
–, cartesian	K1, P20
–, polar (see Polar coordinates)	K2, P24
–, programming	P21, P25
Corner = Datum	A17
–, entry	A18
Cosine (parameter definition)	P82
CR (see circular path CR)	P50
CT (see tangential arc)	P54

Index

C continued

Cycle	P94
- , call	P94
- , cancel	P97
- , define	P94
- , delete	P166
- , parameter	D23

D

D (Address)	D30
Data transfer	V1
Datum shift	P150
- , ISO format	D30
- , plain language	P151
Departure command M98	P68
Dialog prompting	P2
Directory (program management)	P6, D5
DR (Direction of rotation)	P44
- , angle	K2, P154
- , circular interpolation	P44
- , circular pocket milling	P116
- , pocket milling	P110
Dwell time	P158
- , ISO format	D31
- , plain language	P159
- , in machining cycle	P98

E

Editing	P8, P164 ff
- , during execution	P195
Editing words	P164
Electronic handwheel	M2
Ellipse (programming example)	P88
Emergency STOP	P192
END key	P3
Enlargement	P156
- , graphics	P184
ENT key	P3
Erase/edit protection	P6
- , ISO format	D8
- , plain language	P9, P11
Error messages	T24
Error number (Parameter function)	P9
EXT (V.24 Interface)	V3

F

F (Address)	D30, D31
F (see Feed Rate)	P32, D12
Fast image data processing	P175
FE (see Floppy Disk Unit)	V3

Index

F continued

Feed rate	P32, D12
–, in machining cycle	P98
–, override	M1, P188, P204
Floppy disk unit (FE)	V3
FN (see Parameter function)	P78
Freely programmable cycles (program call)	P160
–, ISO format	D31
–, plain language	P161

G

G (Address)	D6
G-codes	D6
GOTO (see Block Call and Conditional Jump)	P164
Graphics	P172
–, starting	P176, P179
–, stopping	P176, P177

H

H (Address)	D13
Helical interpolation	P60
–, ISO format	D18
–, plain language	P61

I

I (Address)	D11
IF equal, THEN jump	P84
IF greater than, jump	P86
IF less than, jump	P86
IF unequal, jump	P86
IF-THEN jump (see Conditional jump)	P84
Incremental dimensions	K10, P19, P24, D10
–, ISO format	D10
–, plain language	P19
Infeed per cut	P110
Input all programs	V9
Interpolation, 3D (see Linear interpolation)	P36
Interpolation factor	M2

J

J (Address)	D11
-------------	-----

Index

K

K (Address)	D11
k (see "Stepover")	P111

L

L (see Linear Interpolation)	P36
Labels	P70
- , call	P70
- , number	P70
- , setting	P70
LBL	P71
LBL CALL	P71
LBL SET	P71
Linear interpolation	P36
Linear interpolation, 2D (see linear interpolation)	P36
Linear interpolation, 3D (see linear interpolation)	P36

M

M (Address)	P32
- , tables (see also back cover)	P34
Machine axes	K3
Machine parameters	P208
- , table	P212
Machining cycles	P94, P96
- , ISO format	D22
- , plain language	P95
MAGN key	P184
Magnetic tape unit	V2
Magnify function (graphics)	P184
Manual operation	M1
Manufacturer cycles	P94
ME (see Magnetic Tape Unit)	V2
Measuring system	K5
Milling depth	P104, P110, P116
Mirror image	P152
- , ISO format	D30
- , plain language	P153
MOD-Function	E10
MP (see Machine Parameters)	P208

N

N (Address)	D5
NC: Software number	E18
Nesting	P74
NO ENT key	P3

Index

O

Operating modes, on-screen display	E6
Output all programs	V13
Overlap factor (see steppover)	P111

P

P (Address) (see Cycle parameters and Parameter definition)	D23, D30
Paging	P164
- , in cycle definitions	P95
- , in parameter definitions	P79
- , in a program	P164
Parameter	P78
- , definition	P78
- , display	P170, P171
- , ISO format	D30
- , plain language	P79
- , function	P78
- , output via interface	P93
- , setting	P78
- , ISO format	D30
- , plain language	P79
- , special functions	P90
Paraxial machining	P197
- , ISO format	D12
- , plain language	P199
Path angle	P64
Peck drilling	P98
Pecking depth	P98
Peripheral device	V1
Pilot drill (cycle)	P130
- , ISO format	D27
- , plain language	P131
Plan view (graphics)	P175
Playback mode	P200
PLC: Software number	E18
Pocket milling (rectangular pocket)	P110
Polar coordinates	K2, P24
- , angle	P24
- , ISO format	D10
- , plain language	P25
- , radius	P24
- , ISO format	D10
- , plain language	P25
Pole	P22
- , ISO format	D13, D16
- , plain language	P23
Position display	E9
Position display, large/small	E14
Positioning with MIDI	P204
Power interruptions	E4
Program	P1
- , call	P6, P76
- , call (cycle)	P160
- , ISO format	D31
- , plain language	P161

Index

P continued

- , editing	P164
- , editing protection	P6, P8
- , entry	P6
-- , ISO format	D1
-- , plain language	P1
Program, erasing a	P168
- , erase protection	P6, P8
- , label	P70
-- , ISO format	D34
-- , plain language	P71
- , jump	P70, P76, P84
-- , ISO format	D29
-- , plain language	P77
- , number	P6
- , protection	P6, P8
Program part repetition	P72
-- , ISO format	D34
-- , plain language	P72
Program run	P188
- , aborting	P190
- , full sequence	P188, P192
- , interrupting	P190
- , resuming	P193, P194
- , single block	P188, P192
Program STOP	P17
- , checking (see Program test and Search routines)	P170, P168
- , editing (see Editing a program)	P164
- , length	P6
Program test run	P170
- , directory	V8
- , management	P6
-- , ISO format	D5
-- , plain language	P7, P9

Q

Q DEF key	P78
Q key	P78, D30
Q-Parameters, displaying	P169

R

R (Address)	D10, D20
Radius compensation	P26
- , in continuous operation	P26
- , for paraxial machining	P197
Read-in program offered	V10
Read-in selected program	V11
Read-out selected program	V12
Rectangular pocket (see Pocket milling)	P110
Reduction	P156

Index

R continued

Reference point	K5
–, traversing	E4
Reference position	K5
Reference signal	K5
Relative tool movement	K3
REP (see Programm part repetition)	P72
Repetition	P72, P75
RND (see Rounding corners)	P59
ROT (see Rotation angle)	P155
Rotating the coordinate system	P154
Rotation angle (ROT)	P154
–, ISO format	D31
–, plain language	P155
Rough-out cycle	P132
–, ISO format	D28
–, plain language	P132
Rounding corners	P58
–, ISO format	D20
–, plain language	P59
Rounding radius	P58

S

S (Address)	P17, D9
Scaling factor	P156
–, ISO format	D30
–, plain language	P157
SCL (see Scaling factor)	P157
Search routines	P168
Set-up clearance	P98
Simulation in 3 planes, graphics	P174
Simulation, 3D	P174
Sine (Parameter definition)	P82
Slot milling	P104
Snap-on keyboard	D1
Software limits	E14
Special tool	P14
Spindle axis	P16
Spindle orientation (cycle)	P162
–, ISO format	D33
–, plain language	P163
Spindle rotation (M-function)	P34, P96
Spindle speeds	P16, P18
Square root (Parameter definition)	P80
–, from root sum of squares	P83
–, from square number	P80
Standard programming (see Programming in ISO format)	D1
Step positioning	M4
Stepover k	P111
STOP	P17
Straight lines	P36
–, ISO format	D12, D13
–, plain language	P37, P41

Index

S continued

Subroutine _____	P73
-, repetition _____	P75
Supplementary operating modes _____	E10

T

T (Address) _____	P9
t (see Advance stop distance) _____	P98
Tangential arc _____	P54
-, ISO format _____	D17
-, plain language _____	P55, P57
Tapping _____	P102
-, ISO format _____	D23
-, plain language _____	P103
Tool _____	P12
-, call _____	P16
---, ISO format _____	D9
---, plain language _____	P17
-, change _____	P16
-, compensation _____	P12
---, ISO format _____	D9
---, plain language _____	P15, P17
---, in playback mode _____	P15, P201
-, definition _____	P12
---, ISO format _____	D9
---, plain language _____	P15
-, length _____	P12
---, ISO format _____	D9
---, plain language _____	P15
-, number _____	P12, P16
---, ISO format _____	D9
---, plain language _____	P15, P17
-, radius _____	P13
---, ISO format _____	D9
---, plain language _____	P15, P17
TOOL CALL _____	P16
TOOL CALL 0 _____	P16
TOOL DEF _____	P12
Tool path compensation _____	P26
-, ISO format _____	D19
-, plain language _____	P28
-, contour intersection compensation with M97 _____	P28
-, on external corners _____	P28
-, on internal corners _____	P199
-, termination with M98 _____	P30, P68
-, with paraxial positioning blocks _____	P197
---, ISO format _____	D19
---, plain language _____	P199
Total hole depth _____	P98
TOUCH PROBE key _____	A2
Touch-probe _____	A1
Touch-probe function, general information _____	A2

Index

T continued

Transfer blockwise	V14
Traversing speed (see also Feed rate)	P32
-, constant, on external corners	P29
Trigonometric functions	P82, P87

U

User parameters	E18, P208
-----------------	-----------

V

V.24 Interface	V1
-, definition	V3
Vacant blocks	E8

W

Workpiece	P19
-, axis (see also spindle axis)	P16, P90
-, contour	P19
-, datum (setting)	K6, K9
Workpiece datum, setting	K9
Workpiece surface = Datum	A14, A26
-, ISO format	D33
-, plain language	A15, A27
Write protection	V7

X

Y

Z

Zero tool	P12
-, ISO format	D24
-, plain language	P107

Error messages

A

ANGLE REFERENCE MISSING _____ P48, P54
ARITHMETICAL ERROR _____ P87

B

BLOCK FORMAT INCORRECT _____ D1

C

CIRCLE END POS. INCORRECT _____ P46, P54
CYCLE INCOMPLETE _____ P194
CYCLE PARAMETER SIGN FALSE _____ P99

D

DEFINITION BLK FORM INCORRECT _____ D32

E

EMERGENCY STOP _____ P192
EXCESSIVE SUBPROGRAMMING _____ P72, P73, P74
EXCHANGE BUFFER BATTERY _____ E3, P208
EXCHANGE TOUCH PROBE BATTERY _____ A2

G

G-CODE GROUP ALREADY ASSIGNED _____ D1, D7

I

ILLEGAL G-CODE _____ D2

J

JUMP TO LABEL 0 NOT PERMITTED _____ P70

L

LABEL NUMBER ALREADY ALLOCATED _____ P70

Error messages

M

ME: PROGRAM INCOMPLETE _____ V7
MIRROR IMAGE ON TOOL AXIS _____ P152

P

PATH OFFSET INCORRECTLY STARTED _____ P44
PGM SECTION CANNOT BE SHOWN _____ P176
PLANE INCORRECTLY DEFINED _____ P42, P58
POWER INTERRUPTED _____ D3, E4, E8
PROBE SYSTEM NOT READY _____ A2
PROGRAM MEMORY EXCEEDED _____ P166
PROGRAM START UNDEFINED _____ P194, D10, D15

R

RELAY EXT. DC VOLTAGE MISSING _____ D3, E4
ROUNDING RADIUS TOO LARGE _____ P58

S

SELECTED BLOCK NOT ADDRESSED _____ P193
SPINDLE ? _____ P96
STYLUS DEFLECTED _____ A2

T

TOOL CALL MISSING _____ P96
TOOL RADIUS TOO LARGE _____ P28, P29
TOUCH POINT INACCESSIBLE _____ A2

W

WRONG AXIS PROGRAMMED _____ P153
WRONG RPM _____ P16

Auxiliary functions M

{List of standard miscellaneous functions. These functions can be changed by the machine tool manufacturer

M	Function	Active beginning	at block end
M00	Stop program run/Spindle STOP/Coolant OFF		•
M02	Stop program run/Spindle STOP/Coolant OFF/if required: clearing the status display (independent of machine parameters)/Return to block 1		•
M03	Spindle ON: clockwise	•	
M04	Spindle ON: counterclockwise	•	
M05	Spindle STOP		•
M06	Tool change/Stop program run (if req'd., depends on specified machine parameters)/Spindle STOP		•
M08	Coolant ON	•	
M09	Coolant OFF		•
M13	Spindle ON: clockwise/Coolant ON	•	
M14	Spindle ON: counterclockwise/Coolant ON	•	
M30	same as M02		•
M89	Variable auxiliary function	•	
M89	- or - Cycle call, modal (depends on machine parameters)		•
M90	Constant tool path feed rate at external and internal corners	•	
M91	within positioning block: coordinates refer to the reference point (Reference point substituted for workpiece datum)	•	
M92	within positioning block: coordinates refer to a position defined by machine manufacturer via machine parameter, e.g. tool change position (workpiece zero is replaced)	•	
M93	M-function assignment reserved by HEIDENHAIN	•	
M94	Reduction of displayed value for rotary table axis to below 360° (programmed setting of actual value)	•	
M95	Changed approach behavior for start in internal corners: no calculation of point of intersection		•
M96	Changed approach behavior for start at external corners: inserting a tangential circle		•
M97	Contour compensation on external corners: point of intersection instead of tangential circle		•
M98	End of contour compensation active blockwise: radius compensation RL/RR is cancelled only for the next positioning block		•
M99	Cycle call active blockwise		•

Address codes (ISO)

Address code	Function	Input range	
		Numbers	Parameter
%	Program start or call	0 – 99999999	–
A-axis	(rotation about X-axis)	± 30000.000	Q0 – Q99
B-axis	(rotation about Y-axis)	± 30000.000	Q0 – Q99
C-axis	(rotation about Z-axis)	± 30000.000	Q0 – Q99
D	Parameter definition (Program parameter Q)	0 – 15	–
F	Feed rate	0 – 29.999	Q0 – Q99
F	Dwell with G04	0 – 19999.999	Q0 – Q99
F	Scaling factor with G72	0 – 99.999	–
G	G-code	0 – 99	–
H	Polar coordinate angle in incremental dimensions	± 5400.000	Q0 – Q99
	in absolute dimensions	± 360.000	Q0 – Q99
H	Angle of rotation with G73	± 360.000	Q0 – Q99
I	X-coordinate of circle centre/pole	± 30000.000	Q0 – Q99
J	Y-coordinate of circle centre/pole	± 30000.000	Q0 – Q99
K	Z-coordinate of circle centre/pole	± 30000.000	Q0 – Q99
L	Set label number with G98	0 – 254	–
L	Jump to label number	1 – 254.65534	–
L	Tool length with G99	± 30000.000	Q0 – Q99
M	Auxiliary functions	0 – 99	–
N	Block number in “Transfer blockwise” mode	1 – 9999 1 – 65534	– –
P	Cycle parameter in machining cycles	01 – 12	–
P	Parameter in parameter definitions	01 – 03	–
Q	Program parameter “Q”	0 – 99	–
R	Polar coordinate radius	± 30000.000	Q0 – Q99
R	Circle radius with G02/G03/G05	± 30000.000	Q0 – Q99
R	Rounding-off radius with G25/G26/G27	0 – 19999.999	Q0 – Q99
R	Chamfer length with G24	0 – 19999.999	Q0 – Q99
R	Tool radius with G99	± 30000.000	Q0 – Q99
S	Spindle speed	0 – 99999.999	Q0 – Q99
S	Angular spindle position with G36	0 – 360.000	Q0 – Q99
T	Tool definition with G99	1 – 254	–
T	Tool call	0 – 254	Q0 – Q99
U-axis	(linear movement parallel to X-axis)	± 30000.000	Q0 – Q99
V-axis	(linear movement parallel to Y-axis)	± 30000.000	Q0 – Q99
W-axis	(linear movement parallel to Z-axis)	± 30000.000	Q0 – Q99
X	X-axis	± 30000.000	Q0 – Q99
Y	Y-axis	± 30000.000	Q0 – Q99
Z	Z-axis	± 30000.000	Q0 – Q99
*	End of block	–	–

Program entry in ISO format

G-codes			
G00	Linear interpolation, Cartesian, rapid traverse	● G24	Chamfer with R
G01	Linear interpolation, Cartesian	● G25	Corner rounding with R
G02	Circular interpolation, Cartesian, clockwise	● G26	Tangential contour approach with R
		● G27	Tangential contour departure with R
G03	Circular interpolation, Cartesian, counterclockwise	● G29	Designate current position value as pole
G05	Circular interpolation, Cartesian, no direction specified	G30	Blank workpiece definition for graphics: min. point
G06	Circular interpolation, Cartesian, tangential transition from previous contour	G31	Blank workpiece definition for graphics: max. point
● G07	Paraxial positioning block	● G38	Corresponds to STOP block in HEIDENHAIN format
G10	Linear interpolation, polar, rapid traverse	G40	No tool compensation
G11	Linear interpolation, polar	G41	Tool path compensation, left of contour
G12	Circular interpolation, polar, clockwise	G42	Tool path compensation, right of contour
G13	Circular interpolation, polar, counterclockwise	● G43	Paraxial compensation, extension R+
G15	Circular interpolation, polar, no direction specified	● G44	Paraxial compensation, reduction R–
G16	Circular interpolation, polar, tangential transition from previous contour	G50	Program protection (at start of program)
● G04	Dwell	● G51	Next tool number (when using central tool memory)
G28	Mirror image	● G55	Touch-probe function with workpiece surface as datum plane
G36	Spindle orientation	G70	Dimensions specified in inches (at start of program)
G37	Pocket contour definition	G71	Dimensions specified in millimetres (at start of program)
● G39	Designates program, call via G79	● G79	Call cycle
G54	Datum shift	G90	Absolute dimensions
G56	Pre-drilling	G91	Incremental dimensions
G57	Roughing out	● G98	Set label number
G58	Contour milling clockwise	● G99	Tool definition
G59	Contour milling counterclockwise		
G72	Scaling factor		
G73	Coordinate system rotation		
G74	Slot milling		
G75	Rectangular pocket milling clockwise		
G76	Rectangular pocket milling counterclockwise		
G77	Circular pocket milling clockwise		
G78	Circular pocket milling counterclockwise		
G83	Peck drilling		
G84	Tapping		
G17	Plane selection XY, tool axis Z		
G18	Plane selection ZX, tool axis Y		
G19	Plane selection YZ, tool axis X		
G20	Tool axis = 4 th axis		

● = Non-modal G-code

Operating Manual

This Operating Manual is valid for all currently available versions of the TNC 355 for **four axes**. The special characteristics of the TNC 355 5-axis contouring control are described in the chapter "Technical Data T". The following is a list of the various TNC 355 versions:


TNC 355 Version without supplementary PLC Power Board PL 300	TNC 355 Version with supplementary PLC Power Board PL 300	Number of Axes	Encoder Inputs Sinusoidal signals (∩) Square-wave signals(□)
TNC 355B TNC 355F*	TNC 355Q TNC 355W*	four	4 ∩ 1 □
TNC 355C TNC 355G*	TNC 355S TNC 355Y*	five	4 ∩ 2 □
TNC 355CR TNC 355GR*	TNC 355SR TNC 355YR*	five	1 ∩ 5 □

* Export version without 3D interpolation and without "blockwise transfer" function and simultaneous execution.



Because HEIDENHAIN is constantly striving to further develop its TNC control systems, details of a given control version may deviate from the version described in this Operating Manual

HEIDENHAIN TNC 355 Contouring Control



Manufacturer's certificate

We hereby certify that the above device is radio-interference-suppressed in compliance with the provisions of the West German Official Register Decree No. 1046/1984. The West German postal authorities have been notified of the deployment of this device and have been granted permission to inspect the series for compliance with said provisions.

Note:

If the device is incorporated by the user into an installation, the entire system must comply with the above-mentioned provisions.