







FUSES ON DINRAIL

F1	SPINDLE DRIVE	6.3 AMP
F2	CONTROL TRANS	3.15 AMP
F3	ATC MOTOR AND SPRAYMIST	3.15 AMP
F4	110v AC CIRCUIT	3.15 AMP

FUSES ON COMPONENTS

F5	DENSTEP BOARD	6.3 AMP	(SEE SHEET 4)
F6	SPINDLE DRIVE	16 AMP	(SEE SHEET 6)

LINK 61 + 91 IF GUARD INTERLOCK IS NOT FITTED

NOVAMILL RELAY WIRING DETAILS

SHEET 5
NOVAMILL
DENSTEP

DENFORD MACHINE TOOLS LTD BRIGHOUSE WEST YORKSHIRE | DRN BY A McHENRY | DATE 5-1-2004 | NVM-D5 J