

# Moving the Control Panel in VR Turning

## Article #3005

If the Control Panel window in the VR CNC Turning software appears off screen and you cannot get it back into position, follow the steps in this article.

- 1.) Open the VRTurn.ini file in Notepad. This file is located in the \program files\denford\vrturning folder. If you need instructions on opening an .INI file, please refer to "1010 Opening Files in Windows Notepad"
- 2.) Locate the section of the file that begins with [ControlPanelStd]. This section will most likely be located at the very end of the file.
- 3.) A Top and Left value will be shown under this section as shown below. Your numbers will be different.  
[ControlPanelStd]  
Top=-210  
Left=590
- 4.) The Top value should be a positive value. Change the Top value to read **220**. (For example, Top=220).
- 5.) Save the file in Notepad by clicking File > Save on the menu bar.
- 6.) Exit Notepad by clicking File > Exit.
- 7.) Open the VR Turning software to see if the problem has been rectified.