


110v FROM CONTROL TRANSFORMER
SEE SHEET 1




PIN	COLOUR	WIRE	SOLENOIDS
A1	BLACK	40	CAROUSEL IN
A2	BLACK	41	DRAWBAR
A3	BLACK	42	VICE OPEN
A4	BLACK	43	GUARD OPEN
A5	BLACK	44	GUARD CLOSE
B1	BLACK	31	COMMON
B2	RED	77	GUARD CLOSED SWITCH
B3	BLUE	78	
B4	RED	105	GUARD FULLY OPEN SWITCH
B5	BLUE	106	
C1	RED	108	AIR PRESSURE SWITCH
C2	BLUE	107	
C3			
C4			
C5			

0.5mm
SINGLES

2 CORE
SCREEN

2 CORE
SCREEN

2 CORE
SCREEN



4 WAY CONNECTOR FOR SPRAYMIST

1	BLACK	10
2	BLACK	N
3		
E	EARTH	E

HOUSING (362 NN)
FEMALE INSERT (362 SS)
HOOD (362 KK)
MALE INSERT (362 RR)


PANEL END

HOOD (356 HC)
INSERT (356 HB)
(FEMALE PINS)
REDUCER (356 HE)

PG11 CONDUIT (411 B)
2 GLANDS (411 E)
LOCKNUT (411 N)

MACHINE END

HOUSING (356 HD)
INSERT (356 HA)
(MALE PINS)



NOTE:

IF POWER GUARD IS FITTED
THE TWO SWITCHES IN THE PNEUMATIC CYLINDER
ARE USED INSTEAD OF THE USUAL GUARD SWITCHES

NOVAMILL
SOLENOID AND
SPRAYMIST OPTIONS

SHEET 12
NOVAMILL
DENSTEP